

## Contents

<b>01 - Self-diagnosis</b> .....	<b>1</b>
<b>1 Self-diagnosis of Motronic system</b> .....	<b>1</b>
1.1 Self-diagnosis of Motronic system .....	1
1.2 Technical data of self-diagnosis .....	1
1.3 Safety precautions .....	1
1.4 Connecting vehicle diagnostic, testing and information system VAS 5051 and selecting functions .....	1
<b>2 Interrogating and erasing fault memory</b> .....	<b>5</b>
2.1 Interrogating and erasing fault memory .....	5
2.2 Interrogating fault memory .....	5
2.3 Erasing fault memory .....	7
2.4 End of output .....	8
2.5 Fault table .....	8
2.6 Fault codes 00281 - 00537 .....	9
2.7 Fault codes 00540 - 65535 .....	15
<b>3 Final control diagnosis</b> .....	<b>20</b>
3.1 Final control diagnosis .....	20
<b>4 Basic setting</b> .....	<b>24</b>
4.1 Basic setting .....	24
<b>5 Encoding control unit</b> .....	<b>28</b>
5.1 Encoding control unit .....	28
<b>6 Reading measured value block</b> .....	<b>30</b>
6.1 Reading measured value block .....	30
6.2 Display group overview .....	32
6.3 Specified display values .....	34
<b>7 Checking diagnostic connector wiring connections</b> .....	<b>42</b>
7.1 Checking diagnostic connector wiring connections .....	42
7.2 Checking voltage supply to "black" diagnostic connector .....	43
7.3 Checking wiring between "white" diagnostic connector and engine control unit .....	43
7.4 Checking cable connection of coding connector .....	47
<b>24 - Mixture preparation, Injection</b> .....	<b>48</b>
<b>1 Servicing Motronic injection system</b> .....	<b>48</b>
1.1 Servicing Motronic injection system .....	48
1.2 Safety precautions .....	48
1.3 Rules for cleanliness .....	48
1.4 Technical data .....	49
1.5 Fitting locations overview .....	50
1.6 Removing and installing injection system components .....	56
1.7 Checking wiring and components with test box V.A.G 1598 A and adapter 1598/5 .....	59
1.8 Replacing engine control unit .....	60
1.9 Checking idling speed .....	63
1.10 Checking system pressure, fuel pressure regulator and holding pressure .....	64
1.11 Checking injectors .....	67
1.12 Removing and installing injectors .....	71
1.13 Checking injection quantity, leak tightness and spray pattern of injectors .....	73
1.14 Checking fuel pump relay -J17 and relay actuation .....	75
1.15 Checking idling stabilisation valve -N71 .....	80
1.16 Checking air mass meter -G70 .....	84
1.17 Checking altitude sender -F96 .....	88
1.18 Checking intake air system for leaks (unmetered air) .....	92
<b>2 Checking lambda control</b> .....	<b>93</b>
2.1 Checking lambda control .....	93



2.2	Checking lambda probe signal wiring and actuation . . . . .	94
2.3	Checking lambda probe heater -Z19 . . . . .	95
2.4	Removing and installing lambda probe . . . . .	97
<b>3</b>	<b>Checking fuel tank breather . . . . .</b>	<b>98</b>
3.1	Checking fuel tank breather . . . . .	98
3.2	Checking activated charcoal filter system solenoid valve 1 -N80 . . . . .	99
<b>4</b>	<b>Checking throttle valve potentiometer -G69 . . . . .</b>	<b>103</b>
4.1	Checking throttle valve potentiometer -G69 . . . . .	103
4.2	Checking and adjusting idling speed switch -F60 . . . . .	106
4.3	Checking and adjusting closing damper . . . . .	109
<b>5</b>	<b>Checking auxiliary signals . . . . .</b>	<b>110</b>
5.1	Checking auxiliary signals . . . . .	110
5.2	Checking signals from/to air conditioner . . . . .	110
5.3	Checking engine speed signal . . . . .	113
5.4	Checking consumption signal for on-board computer . . . . .	113
5.5	Checking boost pressure signal for onboard computer . . . . .	113
5.6	Checking vehicle speed signal . . . . .	114
<b>6</b>	<b>Vacuum diagram . . . . .</b>	<b>116</b>
6.1	Vacuum diagram . . . . .	116
<b>28</b>	<b>- Ignition system . . . . .</b>	<b>118</b>
<b>1</b>	<b>Checking ignition system . . . . .</b>	<b>118</b>
1.1	Checking ignition system . . . . .	118
1.2	Safety precautions . . . . .	118
1.3	Technical data . . . . .	118
1.4	Checking ignition coils and output stages . . . . .	119
1.5	Checking ignition timing sender -G4 . . . . .	128
1.6	Checking engine speed sender -G28 . . . . .	130
1.7	Checking intake air temperature sender -G42 . . . . .	132
1.8	Checking coolant temperature sender -G62 . . . . .	135
1.9	Checking control unit power supply . . . . .	138
1.10	Checking knock sensors . . . . .	140
1.11	Checking Hall sender -G40 . . . . .	142
1.12	Basic setting of Hall sender - vehicles of model year 1991 . . . . .	145