

Contents

00 - Technical data	1
1 Technical data	1
1.1 Engine number	1
1.2 Engine data	1
10 - Removing and installing engine	2
1 Removing and installing engine	2
1.1 Removing engine	3
1.2 Separating engine and gearbox	15
1.3 Securing engine to assembly stand	17
1.4 Installing engine	19
2 Adjusting assembly mountings	24
2.1 Checking	24
2.2 Adjusting assembly mountings	24
13 - Crankshaft group	28
1 Dismantling and assembling engine	28
1.1 Poly V-belt drive - exploded view of components	28
1.2 Removing and installing poly V-belt	29
1.3 Removing and installing crankshaft pulley	31
1.4 Removing and installing bracket for ancillaries	32
1.5 Toothed belt drive - exploded view of components	36
1.6 Removing and installing toothed belt	39
1.7 Removing toothed belt from camshaft sprocket	46
1.8 Checking semi-automatic tensioning roller for toothed belt	49
2 Removing and installing sealing flanges and pressure plate/drive plate	52
2.1 Sealing flanges and pressure plate/drive plate - exploded view of components	52
2.2 Renewing crankshaft oil seal (pulley end)	54
2.3 Removing and installing sealing flange (front)	56
2.4 Removing and installing sealing flange (rear)	58
2.5 Removing and installing pressure plate	60
2.6 Removing and installing drive plate	61
3 Removing and installing crankshaft	63
3.1 Crankshaft - exploded view of components	63
3.2 Crankshaft dimensions	65
3.3 Removing and installing chain sprocket	65
4 Dismantling and assembling pistons and conrods	67
4.1 Pistons and conrods - exploded view of components	67
4.2 Piston and cylinder dimensions	70
15 - Cylinder head, valve gear	71
1 Removing and installing cylinder head	71
1.1 Cylinder head - exploded view of components	71
1.2 Removing and installing cylinder head cover	73
1.3 Removing and installing cylinder head	73
2 Removing and installing intake manifold	83
2.1 Intake manifold - exploded view of components	83
2.2 Removing and installing intake manifold	84
2.3 Removing and installing intake manifold (bottom section)	88
2.4 Checking compression	91
3 Servicing valve gear	94
3.1 Valve gear - exploded view of components	94



3.2	Checking axial clearance of camshaft	95
3.3	Renewing camshaft oil seal	96
3.4	Removing and installing camshaft	98
3.5	Renewing valve stem oil seals	101
3.6	Checking supporting elements with hydraulic clearance compensation	104
3.7	Valve dimensions	106
3.8	Checking valve guides	106
3.9	Machining valve seats	107
3.10	Checking valves	109
17	- Lubrication	110
1	Removing and installing parts of lubrication system	110
1.1	Sump, oil pump - exploded view of components	110
1.2	Removing and installing sump	112
1.3	Removing and installing oil pump	115
1.4	Oil filter, oil filter bracket - exploded view of components	115
1.5	Checking oil pressure and oil pressure switch	117
1.6	Engine oil	119
1.7	Checking oil level	119
19	- Cooling	121
1	Removing and installing parts of cooling system	121
1.1	Diagram of coolant hose connections	121
1.2	Draining and filling cooling system	123
1.3	Removing and installing coolant pump	128
1.4	Map-controlled engine cooling system	131
1.5	Performing diagnosis of map-controlled engine cooling system	131
1.6	Electrical test of map-controlled engine cooling system	134
1.7	Coolant distributor housing - exploded view of components	136
1.8	Checking thermostat for map-controlled engine cooling system	137
1.9	Checking coolant temperature sender - radiator outlet G83	139
1.10	Removing and installing map-controlled engine cooling thermostat	141
1.11	Removing and installing coolant pipe	142
1.12	Radiator and radiator fan - exploded view of components	144
1.13	Removing and installing radiator	145
1.14	Checking cooling system for leaks	148
26	- Exhaust system	151
1	Removing and installing parts of exhaust system	151
1.1	Exhaust system - exploded view of components	151
1.2	Separating centre and rear silencers	154
1.3	Removing and installing front exhaust pipe with catalytic converter	154
1.4	Removing and installing exhaust manifold	156
1.5	Stress-free alignment of exhaust system	157
1.6	Checking exhaust system for leaks	159
2	Exhaust gas recirculation system	160
2.1	Exhaust gas recirculation system - exploded view of components	160
2.2	Checking adaption of zero position for exhaust gas recirculation valve N18	162
2.3	Electrical test of exhaust gas recirculation valve N18 and exhaust gas recirculation potentiometer G212	163
2.4	Removing and installing exhaust gas recirculation valve N18 with exhaust gas recirculation potentiometer G212	169
3	Secondary air system	171
3.1	Principle and function	171
3.2	Carrying out diagnosis of secondary air system	172
3.3	Checking secondary air pump relay J299 and activation	173

3.4	Checking combination valve for secondary air system for proper operation and leakage . .	179
3.5	Removing and installing combination valve for secondary air system	180
3.6	Removing and installing secondary air pump	181