

## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Technical data</b>	<b>1</b>
1.1 Engine number	1
1.2 Engine data	1
<b>2 General repair instructions</b>	<b>2</b>
2.1 Safety precautions	2
2.2 Rules for cleanliness when working on fuel supply system, injection system and turbocharger	3
2.3 Contact corrosion!	3
2.4 Foreign particles in engine	4
2.5 Routing and attachment of pipes, hoses and wiring	4
2.6 Checking vacuum system	4
2.7 Installing radiators, condensers and charge air coolers	5
<b>10 - Removing and installing engine</b>	<b>6</b>
<b>1 Removing and installing engine</b>	<b>6</b>
1.1 Removing engine	6
1.2 Separating engine and gearbox	23
1.3 Securing engine to assembly stand	24
1.4 Installing engine	26
<b>2 Adjusting assembly mountings</b>	<b>32</b>
2.1 Checking adjustment	32
2.2 Adjusting assembly mountings	33
<b>13 - Crankshaft group</b>	<b>36</b>
<b>1 Servicing work on pulley end</b>	<b>36</b>
1.1 Poly V-belt drive - exploded view	36
1.2 Removing and installing poly V-belt	37
1.3 Removing and installing vibration damper	40
1.4 Removing and installing bracket for ancillaries	41
1.5 Toothed belt - exploded view of components	47
1.6 Removing and installing toothed belt	50
1.7 Detaching toothed belt from camshaft sprocket	54
1.8 Positioning crankshaft at "TDC" with engine installed	55
1.9 Positioning crankshaft at "TDC" with engine removed	58
<b>2 Removing and installing sealing flanges and dual-mass flywheel</b>	<b>59</b>
2.1 Sealing flanges and dual-mass flywheel - exploded view	59
2.2 Renewing crankshaft oil seal (pulley end)	61
2.3 Removing and installing sealing flange (front)	63
2.4 Removing and installing dual-mass flywheel	65
<b>3 Removing and installing crankshaft</b>	<b>67</b>
3.1 Crankshaft - exploded view	67
3.2 Crankshaft dimensions	69
3.3 Removing and installing drive chain sprocket	69
<b>4 Dismantling and assembling pistons and conrods</b>	<b>72</b>
4.1 Pistons and conrods - exploded view	72
4.2 Piston and cylinder dimensions	74
4.3 Measuring radial clearance of conrods	74
<b>15 - Cylinder head, valve gear</b>	<b>76</b>
<b>1 Removing and installing cylinder head</b>	<b>76</b>
1.1 Cylinder head - exploded view	76



1.2	Removing and installing cylinder head cover	78
1.3	Removing and installing cylinder head	82
1.4	Removing and installing intake manifold	86
1.5	Checking compression	90
<b>2</b>	<b>Servicing valve gear</b>	<b>94</b>
2.1	Valve gear - exploded view	94
2.2	Checking axial clearance of camshafts	97
2.3	Renewing exhaust camshaft oil seal	98
2.4	Renewing inlet camshaft oil seal	100
2.5	Removing and installing camshafts and hydraulic chain tensioner/camshaft adjuster	103
2.6	Checking hydraulic bucket tappets	109
2.7	Renewing valve stem oil seals	110
2.8	Valve dimensions	114
2.9	Checking valve guides	114
2.10	Machining valve seats	115
<b>3</b>	<b>Checking variable valve timing - vehicles with engine code AMK, BAM</b>	<b>118</b>
3.1	Checking function of variable valve timing	118
3.2	Checking inlet camshaft control valve 1 N205	119
<b>17</b>	<b>Lubrication</b>	<b>124</b>
<b>1</b>	<b>Removing and installing parts of lubrication system</b>	<b>124</b>
1.1	Lubrication system - exploded view of components	124
1.2	Removing and installing sump	125
1.3	Removing and installing oil pump	129
1.4	Oil filter and oil cooler - exploded view of components	129
1.5	Checking oil pressure and oil pressure switch F1	131
1.6	Engine oil	133
1.7	Checking oil level	134
<b>19</b>	<b>Cooling</b>	<b>135</b>
<b>1</b>	<b>Removing and installing parts of cooling system</b>	<b>135</b>
1.1	Diagram of coolant hose connections	135
1.2	Draining and filling cooling system	137
1.3	Removing and installing coolant pump	142
1.4	Removing and installing thermostat	142
1.5	Checking thermostat	145
1.6	Removing and installing coolant pipe	145
1.7	Checking continued coolant circulation pump V51	147
1.8	Radiator and radiator fan - exploded view of components	149
1.9	Removing and installing radiator	149
1.10	Checking cooling system for leaks	155
<b>21</b>	<b>Turbocharging/supercharging</b>	<b>158</b>
<b>1</b>	<b>Servicing charge air system with turbocharger</b>	<b>158</b>
1.1	Safety precautions	158
1.2	Test requirements for checking turbocharging system	158
1.3	Diagram of connections for charge pressure control system and vacuum system	158
1.4	Effects of leaks in charge air system	161
1.5	Checking turbocharger and charge pressure control	162
1.6	Checking mechanical air recirculation valve	165
1.7	Checking air recirculation valve for turbocharger N249	166
1.8	Checking charge pressure control solenoid valve N75	171
1.9	Checking charge pressure sender G31	175
<b>2</b>	<b>Charge air system with turbocharger</b>	<b>179</b>
2.1	Rules for cleanliness	179

2.2	Turbocharger - exploded view	179
2.3	Removing and installing turbocharger	180
2.4	Charge air cooling - exploded view	186
2.5	Removing and installing charge air cooler	189
<b>26</b>	<b>- Exhaust system</b>	<b>192</b>
<b>1</b>	<b>Removing and installing parts of exhaust system</b>	<b>192</b>
1.1	Exhaust system - exploded view	192
1.2	Separating centre and rear silencers	195
1.3	Removing and installing catalytic converter with front exhaust pipe	196
1.4	Removing and installing exhaust manifold	201
1.5	Stress-free alignment of exhaust system	201
1.6	Checking exhaust system for leaks	203
<b>2</b>	<b>Exhaust gas temperature monitoring - vehicles with engine code AMK, BAM</b>	<b>204</b>
2.1	Checking exhaust gas temperature sender 1 G235	204
<b>3</b>	<b>Secondary air system - vehicles with engine codes APY, AUL</b>	<b>208</b>
3.1	Principle and function	208
3.2	Checking secondary air inlet valve N112	210
3.3	Checking secondary air pump relay J299 and secondary air pump motor V101	214
3.4	Checking combination valve for secondary air system for proper operation and leakage	220
3.5	Removing and installing combination valve for secondary air system	221
3.6	Removing and installing secondary air pump	222