

Contents

00 - Technical data	1
1 Technical data	1
1.1 Engine number	1
1.2 Engine data	1
10 - Removing and installing engine	2
1 Removing and installing engine	2
1.1 Removing engine	3
1.2 Securing engine to engine stand	18
1.3 Installing engine	19
13 - Crankshaft group	23
1 Dismantling and assembling engine	23
1.1 Lock carrier - exploded view of components	23
1.2 Moving lock carrier into service position	23
1.3 Poly V-belt for alternator, power steering pump and air conditioner compressor	26
1.4 Removing and installing poly V-belt	28
1.5 Removing and installing pulley	29
1.6 Removing and installing bracket for ancillaries	30
1.7 Toothed belt drive - exploded view of components	33
1.8 Removing and installing toothed belt	35
1.9 Removing toothed belt from camshaft sprocket	40
1.10 Checking semi-automatic tensioning roller for toothed belt	44
2 Removing and installing sealing flanges and dual-mass flywheel	47
2.1 Renewing crankshaft oil seal (pulley end)	48
2.2 Removing and installing front sealing flange	50
2.3 Removing and installing dual-mass flywheel	54
2.4 Removing and installing rear sealing flange	55
3 Removing and installing crankshaft	58
3.1 Crankshaft - exploded view of components	58
3.2 Crankshaft dimensions	60
3.3 Extracting and driving in needle bearing for crankshaft	60
3.4 Removing and installing chain sprocket	62
4 Dismantling and assembling pistons and conrods	64
4.1 Pistons and conrods - exploded view of components	64
4.2 Piston and cylinder dimensions	67
15 - Cylinder head, valve gear	68
1 Removing and installing cylinder head	68
1.1 Cylinder head - exploded view of components	68
1.2 Removing and installing cylinder head cover	71
1.3 Removing and installing cylinder head	71
2 Removing and installing intake manifold	81
2.1 Intake manifold - exploded view of components	81
2.2 Removing and installing intake manifold (top section)	82
2.3 Removing and installing intake manifold (bottom section)	85
2.4 Checking compression	86
3 Servicing valve gear	89
3.1 Valve gear - exploded view of components	89
3.2 Checking axial clearance of camshaft	90
3.3 Renewing camshaft oil seal	91
3.4 Removing and installing camshaft	93



3.5	Renewing valve stem oil seals	97
3.6	Checking supporting elements with hydraulic clearance compensation	100
3.7	Valve dimensions	102
3.8	Machining valve seats	102
3.9	Checking valve guides	104
3.10	Checking valves	105
17	- Lubrication	106
1	Removing and installing parts of lubrication system	106
1.1	Sump, oil pump - exploded view of components	106
1.2	Removing and installing sump	108
1.3	Removing and installing oil pump	118
1.4	Oil filter and oil cooler	118
1.5	Removing and installing oil filter bracket	120
1.6	Checking oil pressure and oil pressure switch	121
1.7	Engine oil	124
1.8	Checking oil level	125
19	- Cooling	126
1	Removing and installing parts of cooling system	126
1.1	Coolant hose connection diagram	126
1.2	Draining and filling cooling system	128
1.3	Removing and installing coolant pump	135
1.4	Removing and installing coolant pipe (top)	136
1.5	Removing and installing coolant pipe (bottom)	137
1.6	Thermostat housing - exploded view of components	138
1.7	Removing and installing thermostat housing with map-controlled engine cooling thermostat F265	139
1.8	Checking map-controlled engine cooling thermostat F265	140
1.9	Removing and installing radiator	142
1.10	Removing and installing radiator cowl	145
1.11	Removing and installing radiator fan	146
1.12	Renewing radiator fan motor	146
1.13	Checking cooling system for leaks	147
26	- Exhaust system	149
1	Removing and installing parts of exhaust system	149
1.1	Exhaust system - exploded view of components	149
1.2	Separating centre and rear silencers	152
1.3	Removing and installing front exhaust pipe	153
1.4	Removing and installing front exhaust pipe with catalytic converter	154
1.5	Removing and installing exhaust manifold	158
1.6	Stress-free alignment of exhaust system	161
1.7	Tailpipe alignment	163
1.8	Checking exhaust system for leaks	163
2	Exhaust gas recirculation system	164
2.1	Exhaust gas recirculation system - exploded view of components	164
2.2	Checking adaption of zero position for exhaust gas recirculation valve N18	166
2.3	Removing and installing exhaust gas recirculation valve N18 with exhaust gas recirculation potentiometer G212	167
3	Secondary air system	169
3.1	Principle and function	169
3.2	Checking combination valve for secondary air system for proper operation and leakage	169
3.3	Removing and installing combination valve for secondary air system	170
3.4	Removing and installing secondary air pump motor V101	171