

## Contents

<b>00 - Technical data</b>	<b>1</b>
1 <b>Technical data</b>	<b>1</b>
1.1    Engine number	1
1.2    Engine data	1
2 <b>Safety precautions</b>	<b>3</b>
2.1    Working on the fuel system	3
2.2    Procedure before opening high-pressure section of injection system	3
2.3    Working on the cooling system	4
2.4    Using testers and measuring instruments during a road test	4
2.5    Working on the exhaust system	4
3 <b>Repair instructions</b>	<b>5</b>
3.1    Rules for cleanliness when working on fuel supply system, injection system and turbocharger	5
3.2    Checking fuel system for leaks	5
3.3    Foreign particles in engine	6
3.4    Contact corrosion	6
3.5    Routing and attachment of pipes, hoses and wiring	6
3.6    Nuts, bolts	6
3.7    Identification plates	7
3.8    Use of impact wrenches	7
3.9    Checking vacuum system	7
3.10   Installing radiators, condensers and charge air coolers	8
<b>10 - Removing and installing engine</b>	<b>9</b>
1 <b>Removing and installing engine</b>	<b>9</b>
1.1    Removing engine	9
1.2    Securing engine to assembly stand	29
1.3    Installing engine	30
1.4    Vacuum connections	33
<b>13 - Crankshaft group</b>	<b>35</b>
1 <b>Dismantling and assembling engine</b>	<b>35</b>
1.1    Lock carrier - exploded view	35
1.2    Moving lock carrier into service position	35
1.3    Poly V-belt drive for power steering pump, alternator and air conditioner compressor - exploded view	38
1.4    Removing and installing poly V-belt	39
1.5    Removing and installing crankshaft pulley	41
1.6    Toothed belt drive - exploded view	41
1.7    Removing and installing toothed belt	44
2 <b>Removing and installing sealing flange and flywheel/drive plate</b>	<b>49</b>
2.1    Sealing flange and flywheel/drive plate - exploded view	49
2.2    Renewing crankshaft oil seal (pulley end)	50
2.3    Removing and installing sealing flange (front)	52
2.4    Removing dual-mass flywheel or flywheel for automatic gearbox 01J	57
2.5    Extracting and driving in needle bearing for dual-mass flywheel	58
3 <b>Removing and installing crankshaft</b>	<b>60</b>
3.1    Crankshaft - exploded view	60
3.2    Crankshaft dimensions	62
3.3    Measuring axial clearance of crankshaft	62
3.4    Measuring radial clearance of crankshaft	63
3.5    Removing and installing chain sprocket	64
4 <b>Dismantling and assembling pistons and conrods</b>	<b>65</b>

4.1	Pistons and conrods - exploded view .....	65
4.2	Piston and cylinder dimensions .....	68
4.3	Checking radial clearance of conrod bearings .....	68
<b>15 - Cylinder head, valve gear</b>	.....	<b>70</b>
1	<b>Removing and installing cylinder head</b> .....	70
1.1	Cylinder head - exploded view .....	70
1.2	Removing and installing cylinder head cover (left-side) .....	73
1.3	Removing and installing cylinder head cover (right-side) .....	76
1.4	Removing cylinder head (left-side) .....	79
1.5	Removing cylinder head (right-side) .....	81
1.6	Installing cylinder head .....	83
1.7	Removing and installing intake manifold .....	86
1.8	Checking compression .....	89
2	<b>Servicing valve gear</b> .....	94
2.1	Valve gear - exploded view .....	94
2.2	Checking axial clearance of camshafts .....	97
2.3	Renewing camshaft oil seals .....	98
2.4	Renewing oil seal for Hall sender and sealing cap - cylinder head (left-side) .....	100
2.5	Renewing oil seal for Hall sender - cylinder head (right-side) .....	101
2.6	Removing and installing camshafts and camshaft adjuster .....	104
2.7	Checking hydraulic bucket tappets .....	108
2.8	Renewing valve stem oil seals .....	109
2.9	Checking valve guides .....	113
2.10	Checking valves .....	114
2.11	Machining valve seats .....	114
3	<b>Checking variable valve timing</b> .....	116
3.1	Testing the system .....	116
3.2	Checking camshaft control valves (solenoid valves) .....	119
<b>17 - Lubrication</b>	.....	<b>123</b>
1	<b>Removing and installing parts of lubrication system</b> .....	123
1.1	Lubrication system - exploded view .....	123
1.2	Removing and installing sump (bottom section) .....	124
1.3	Removing and installing oil pump .....	127
1.4	Checking chain tensioner .....	128
1.5	Removing and installing drive chain and chain tensioner for oil pump .....	129
1.6	Removing and installing sump (top section) .....	130
1.7	Renewing oil retention valves .....	141
1.8	Checking oil pressure and oil pressure switch .....	142
1.9	Engine oil .....	145
1.10	Checking oil level .....	145
<b>19 - Cooling</b>	.....	<b>146</b>
1	<b>Removing and installing parts of cooling system</b> .....	146
1.1	Parts of cooling system .....	146
1.2	Draining and filling cooling system .....	148
1.3	Coolant pump and thermostat - exploded view .....	153
1.4	Removing and installing coolant pump .....	154
1.5	Removing, installing and checking thermostat .....	155
1.6	Coolant pipes - exploded view .....	158
1.7	Removing and installing coolant pipe (front) .....	159
1.8	Removing and installing coolant pipe (small) .....	161
1.9	Removing and installing coolant pipe (rear) .....	162
1.10	Removing and installing radiator .....	164
1.11	Renewing radiator fan motor .....	168

1.12	Checking cooling system for leaks . . . . .	169
<b>26 - Exhaust system</b>	.....	<b>171</b>
1	<b>Removing and installing parts of exhaust system</b> .....	171
1.1	Exhaust system - exploded view .....	171
1.2	Separating centre and rear silencers .....	175
1.3	Removing and installing front exhaust pipe (left-side) with starter catalytic converter and main catalytic converter .....	176
1.4	Removing and installing front exhaust pipe (right-side) with starter catalytic converter and main catalytic converter .....	180
1.5	Removing and installing exhaust manifold (left-side) .....	184
1.6	Removing and installing exhaust manifold (right-side) .....	186
1.7	Stress-free alignment of exhaust system .....	188
1.8	Checking exhaust system for leaks .....	190
<b>2</b>	<b>Secondary air system</b> .....	<b>191</b>
2.1	Principle and function .....	191
2.2	Checking secondary air inlet valve N112 .....	193
2.3	Checking secondary air pump relay J299 and activation .....	197
2.4	Removing and installing secondary air pump motor V101 .....	204
2.5	Checking combination valve for secondary air system for proper operation and leakage ..	206
2.6	Removing and installing combination valve for secondary air system (left-side) .....	208
2.7	Removing and installing combination valve for secondary air system (right-side) .....	210