

Contents

00 - Technical data	1
1 Identification	1
1.1 Engine number/engine data	1
2 Safety information	2
2.1 Safety precautions when working on the fuel supply system	2
2.2 Safety precautions when working on vehicles with start/stop system	2
2.3 Safety precautions when using testers and measuring instruments during a road test	3
2.4 Safety precautions when working on the cooling system	3
2.5 Safety precautions when working on the exhaust system	3
2.6 Safety precautions when working on the SCR system	4
2.7 Safety precautions when working on the glow plug system	5
2.8 Safety precautions when working on the subframe	5
3 Repair instructions	7
3.1 Rules for cleanliness	7
3.2 General notes	7
3.3 General repair instructions	8
3.4 Performing adaptations after renewing a component	9
3.5 Cleaning engine	10
3.6 Nuts, bolts	10
3.7 Identification plates	10
3.8 Use of impact wrenches	11
3.9 Foreign material in engine	11
3.10 Contact corrosion	11
3.11 Routing and attachment of pipes, hoses and wiring	12
3.12 Installing radiators and condensers	12
10 - Removing and installing engine	13
1 Removing and installing engine	13
1.1 Removing engine	13
1.2 Securing engine to engine and gearbox support	13
1.3 Installing engine	14
2 Assembly mountings	15
3 Engine cover panel	16
3.1 Removing and installing engine cover panel	16
13 - Crankshaft group	17
1 Cylinder block (pulley end)	17
1.1 Assembly overview - cylinder block (pulley end)	17
1.2 Assembly overview - sealing flange (pulley end)	20
1.3 Removing and installing poly V-belt	22
1.4 Removing and installing poly V-belt tensioner	23
1.5 Removing and installing vibration damper	23
1.6 Removing and installing bracket for ancillaries	26
1.7 Removing and installing engine support	27
1.8 Removing and installing sealing flange (pulley end)	27
2 Cylinder block (gearbox end)	31
2.1 Assembly overview - cylinder block (gearbox end)	31
2.2 Removing and installing drive plate	32
2.3 Renewing cylinder block sealing cap (gearbox end)	34
2.4 Removing and installing sealing flange (gearbox end)	36
3 Crankshaft	46
3.1 Assembly overview - crankshaft	46

3.2	Crankshaft dimensions	46
3.3	Measuring axial clearance of crankshaft	47
4	Pistons and conrods	48
4.1	Assembly overview - pistons and conrods	48
4.2	Removing and installing pistons	52
4.3	Measuring piston projection at TDC	53
4.4	Checking pistons and cylinder bores	56
4.5	Separating parts of new conrod	58
4.6	Checking radial clearance of conrod bearings	58
15	Cylinder head, valve gear	60
1	Toothed belt drive	60
1.1	Assembly overview - toothed belt guard	60
1.2	Assembly overview - toothed belt	60
1.3	Removing and installing toothed belt guard	62
1.4	Detaching toothed belt from camshaft	65
1.5	Removing and installing toothed belt	72
2	Cylinder head	85
2.1	Assembly overview - cylinder head	85
2.2	Assembly overview - cylinder head cover	88
2.3	Removing and installing cylinder head	90
2.4	Removing and installing cylinder head cover	98
2.5	Removing and installing seals for injectors	100
2.6	Removing and installing camshaft housing	101
2.7	Checking compression	106
3	Valve gear	109
3.1	Assembly overview - valve gear	109
3.2	Removing and installing camshaft oil seal	111
3.3	Removing and installing valve stem oil seals	114
4	Inlet and exhaust valves	125
4.1	Checking valve guides	125
4.2	Checking valves	126
4.3	Valve dimensions	126
17	Lubrication	127
1	Sump/oil pump	127
1.1	Assembly overview - sump/oil pump	127
1.2	Engine oil	130
1.3	Removing and installing sump	130
1.4	Removing and installing oil pump	135
1.5	Removing and installing oil level and oil temperature sender G266	135
2	Engine oil cooler	137
3	Oil filter/oil pressure switches	138
3.1	Assembly overview - oil filter housing/oil pressure switch	138
3.2	Removing and installing oil pressure switch F22	140
3.3	Removing and installing oil pressure switch for reduced oil pressure F378	142
3.4	Removing and installing oil filter housing	144
3.5	Removing and installing valve for oil pressure control N428	147
3.6	Checking oil pressure	147
19	Cooling	149
1	Cooling system/coolant	149
1.1	Connection diagram - coolant hoses	149
1.2	Checking cooling system for leaks	149
1.3	Draining and filling cooling system	153

1.4	Checking filling quality	153
2	Coolant pump/thermostat assembly	156
2.1	Assembly overview - coolant pump/thermostat	156
2.2	Assembly overview - electric coolant pump	158
2.3	Assembly overview - coolant temperature senders	158
2.4	Removing and installing electric coolant pump	159
2.5	Removing and installing coolant pump	159
2.6	Removing and installing thermostat	160
2.7	Checking thermostat	160
2.8	Removing and installing coolant valve for cylinder head N489	160
2.9	Removing and installing coolant temperature sender G62	161
3	Coolant pipes	164
4	Radiator/radiator fan	165
21	Turbocharging/supercharging	166
1	Turbocharger	166
1.1	Assembly overview - turbocharger	166
1.2	Removing and installing turbocharger	171
1.3	Renewing vacuum unit for turbocharger	176
2	Charge air system	183
2.1	Assembly overview - charge air system	183
2.2	Assembly overview - hose connections for charge air system	186
2.3	Removing and installing charge pressure sender G31	186
2.4	Removing and installing charge air temperature sender	187
2.5	Checking charge air system for leaks	188
23	Mixture preparation - injection	194
1	Injection system	194
1.1	Overview - fuel system	194
1.2	Overview of fitting locations - injection system	194
1.3	Filling and bleeding fuel system	194
1.4	Checking fuel system for leaks	195
2	Vacuum system	196
2.1	Connection diagram - vacuum system	196
2.2	Checking vacuum system	196
3	Air filter	197
4	Intake manifold	198
4.1	Assembly overview - intake manifold	198
4.2	Removing and installing throttle valve module J338	202
4.3	Removing and installing intake manifold	204
5	Injectors/high-pressure reservoir (rail)	210
5.1	Assembly overview - injectors	210
5.2	Assembly overview - high-pressure reservoir (rail)	212
5.3	Checking injectors	214
5.4	Performing adaption of correction values for injectors	214
5.5	Checking return flow rate of injectors with engine running	216
5.6	Checking return flow rate of injectors at starter cranking speed	219
5.7	Checking for injectors sticking open	221
5.8	Removing and installing injectors	224
5.9	Removing and installing high-pressure pipes	228
5.10	Removing and installing high-pressure reservoir (rail)	231
6	High-pressure pump	233
6.1	Assembly overview - high-pressure pump	233
6.2	Removing and installing high-pressure pump	234



6.3	Checking fuel pressure regulating valve N276 for dirt/swarf if high-pressure pump is defective	239
7	Senders and sensors	242
7.1	Removing and installing air mass meter G70	242
7.2	Removing and installing fuel temperature sender G81	242
7.3	Removing and installing fuel pressure sender G247	243
7.4	Checking fuel pressure regulating valve N276	245
7.5	Removing and installing fuel pressure regulating valve N276	247
7.6	Removing and installing pressure differential sender G505	249
7.7	Removing and installing exhaust gas pressure sensor 1 G450	250
8	Lambda probe	252
8.1	Assembly overview - Lambda probe	252
8.2	Removing and installing Lambda probe	254
8.3	Removing and installing NOx sender	256
9	Engine control unit	260
26	- Exhaust system	261
1	Exhaust pipes/silencers	261
1.1	Assembly overview - silencers	261
1.2	Removing and installing front exhaust pipe	261
1.3	Separating exhaust pipes/silencers	261
1.4	Removing and installing silencers	261
1.5	Stress-free alignment of exhaust system	261
1.6	Checking exhaust system for leaks	261
2	Emission control system	262
2.1	Assembly overview - emission control system	262
2.2	Removing and installing catalytic converter	264
2.3	Removing and installing emission control module	265
2.4	Removing and installing exhaust flap control unit J883	276
3	SCR (selective catalytic reduction) system	278
3.1	Assembly overview - reducing agent tank	278
3.2	Assembly overview - control unit for SCR system	278
3.3	Assembly overview - delivery unit	278
3.4	Assembly overview - injector for reducing agent	278
3.5	Releasing pressure in SCR system	279
3.6	Disconnecting reducing agent supply line	280
3.7	Draining reducing agent tank	283
3.8	Removing and installing reducing agent tank	283
3.9	Removing and installing injector for reducing agent N474	283
3.10	Removing and installing control unit for reducing agent metering system J880	285
3.11	Removing and installing pump for reducing agent V437	285
3.12	Removing and installing pressure sender for reducing agent metering system G686	285
3.13	Removing and installing connection for SCR supply line	285
4	Exhaust gas temperature regulation	286
4.1	Assembly overview - exhaust gas temperature regulation	286
4.2	Removing and installing exhaust gas temperature senders	288
5	Exhaust gas recirculation	295
5.1	Assembly overview - exhaust gas recirculation system	295
5.2	Removing and installing exhaust gas recirculation control motor V338	297
5.3	Removing and installing exhaust gas recirculation control motor 2 V339	298
5.4	Removing and installing exhaust gas recirculation cooler	300
5.5	Checking exhaust gas recirculation cooler for leaks	302
5.6	Removing and installing exhaust gas recirculation temperature sensor G98	306
28	- Glow plug system	309

1	Glow plug system	309
1.1	Assembly overview - glow plug system	309
1.2	Removing and installing glow plug	311
1.3	Removing and installing automatic glow period control unit J179	315
1.4	Removing and installing Hall sender G40	316
1.5	Removing and installing engine speed sender G28	316