

Contents

00 - Technical data	1
1 Identification	1
2 Safety information	2
2.1 Safety precautions	2
2.2 Safety precautions when working on the high-voltage system	2
2.3 Safety precautions when working in the vicinity of high-voltage components	3
3 Repair instructions	4
3.1 Rules for cleanliness when working on the high-voltage battery	4
3.2 Painting work on vehicles with high-voltage system	4
3.3 Repair instructions for all vehicles	4
4 Assessing high-voltage system risk level	5
4.1 Necessary qualifications	5
4.2 Work that requires high-voltage system to be de-energised	5
10 - Removing and installing engine	8
1 Safety information	8
2 Removing and installing engine	9
2.1 Removing engine	9
2.2 Separating engine and gearbox	62
2.3 Removing engine from scissor-type assembly platform	75
2.4 Securing engine to engine and gearbox support	78
2.5 Installing engine	81
3 Assembly mountings	87
3.1 Assembly overview - assembly mountings	87
3.2 Supporting engine in installation position	91
3.3 Removing and installing engine mountings	93
3.4 Removing and installing power unit mounting senders	97
3.5 Calibrating electrohydraulic engine mounting	98
3.6 Removing and installing gearbox mountings	99
4 Engine cover panel	103
13 - Crankshaft group	104
1 Safety information	104
2 Cylinder block (pulley end)	105
2.1 Assembly overview - cylinder block (pulley end)	105
2.2 Assembly overview - sealing flange (pulley end)	105
2.3 Removing and installing poly V-belts	105
2.4 Removing and installing poly V-belt tensioner	105
2.5 Removing and installing vibration damper	105
2.6 Removing and installing bracket for ancillaries	106
2.7 Removing and installing engine support	107
2.8 Renewing crankshaft oil seal (pulley end)	109
2.9 Removing and installing sealing flange (pulley end)	109
3 Cylinder block (gearbox end)	110
4 Crankshaft	111
5 Balance shaft	112
6 Pistons and conrods	113
15 - Cylinder head, valve gear	114
1 Safety information	114
2 Timing chain cover	115



3	Chain drive	116
3.1	Assembly overview - camshaft timing chains	116
3.2	Assembly overview - drive chain for oil pump	116
3.3	Removing camshaft timing chain from camshafts	116
3.4	Removing and installing camshaft timing chain	117
4	Cylinder head	118
4.1	Assembly overview - cylinder head	118
4.2	Assembly overview - camshaft housing	118
4.3	Removing and installing cylinder head	118
4.4	Removing and installing camshaft housing	118
4.5	Checking compression	120
5	Valve gear	121
5.1	Assembly overview - valve gear	121
5.2	Measuring axial clearance of camshaft	121
5.3	Measuring radial clearance of camshaft	121
5.4	Removing and installing camshaft	121
5.5	Removing and installing cam actuators	121
5.6	Removing and installing camshaft control valve 1 N205	122
5.7	Removing and installing valve stem oil seals	122
17 - Lubrication		123
1	Safety information	123
2	Sump/oil pump	124
2.1	Assembly overview - sump/oil pump	124
2.2	Engine oil	124
2.3	Removing and installing lower part of sump	124
2.4	Removing and installing upper part of sump	124
2.5	Removing and installing oil baffle plate	124
2.6	Removing and installing oil pump	124
2.7	Removing and installing oil level and oil temperature sender G266	124
3	Engine oil cooler	125
3.1	Assembly overview - engine oil cooler	125
3.2	Removing and installing engine oil cooler	125
3.3	Removing and installing spray nozzle valve	125
4	Crankcase breather	126
5	Oil filter/oil pressure switches	127
5.1	Assembly overview - oil filter	127
5.2	Assembly overview - oil pressure switches/oil pressure control	127
5.3	Removing and installing oil filter housing	127
5.4	Removing and installing oil pressure switch F22	128
5.5	Removing and installing oil temperature sender G8	128
5.6	Removing and installing oil pressure sender G10	128
5.7	Checking oil pressure	128
5.8	Removing and installing valve for oil pressure control N428	128
19 - Cooling		130
1	Safety information	130
2	Cooling system/coolant	131
2.1	Connection diagram - coolant hoses	131
2.2	Assembly overview - coolant expansion tank	139
2.3	Checking cooling system for leaks	141
2.4	Draining and filling cooling system	147
3	Coolant pump/thermostat assembly	172
3.1	Assembly overview - coolant pump/thermostat	172

3.2	Assembly overview - electric coolant pump	172
3.3	Assembly overview - coolant temperature senders	175
3.4	Assembly overview - coolant valves	178
3.5	Removing and installing electric coolant pump	181
3.6	Removing and installing coolant pump	192
3.7	Removing and installing map-controlled engine cooling system thermostat F265	192
3.8	Removing and installing coolant temperature sender G62	192
3.9	Removing and installing engine outlet coolant temperature sender G82	192
3.10	Removing and installing radiator outlet coolant temperature sender G83	192
3.11	Removing and installing temperature sender for engine temperature regulation G694	194
3.12	Removing and installing coolant temperature sender for high-voltage system	194
3.13	Removing and installing coolant valves	205
4	Coolant pipes	214
4.1	Assembly overview - coolant pipes	214
4.2	Removing and installing coolant pipes	221
5	Radiator/radiator fans	247
5.1	Assembly overview - radiator/radiator fans	247
5.2	Assembly overview - radiator cowl and radiator fans	251
5.3	Removing and installing radiator	252
5.4	Removing and installing radiator cowl	257
5.5	Removing and installing radiator fan V7	260
5.6	Removing and installing radiator for high-voltage coolant circuit	260
21	Turbocharging/supercharging	264
1	Safety information	264
2	Turbochargers	265
2.1	Assembly overview - turbocharger	265
2.2	Removing and installing turbocharger	265
2.3	Renewing vacuum unit for turbocharger	266
2.4	Removing and installing temperature sender for engine cover panel G765	266
3	Charge air system	267
3.1	Assembly overview - charge air system	267
3.2	Assembly overview - hose connections for charge air system	268
3.3	Removing and installing air pipe	268
3.4	Removing and installing charge air cooler	270
3.5	Removing and installing charge pressure sender G31	273
3.6	Removing and installing overrun air recirculation valve	273
3.7	Checking charge air system for leaks	274
24	Mixture preparation - injection	276
1	Safety information	276
2	Injection system	277
2.1	Overview of fitting locations - injection system	277
2.2	Checking fuel system for leaks	291
3	Vacuum system	292
4	Air filter	293
4.1	Assembly overview - air filter housing	293
4.2	Removing and installing air filter housing	294
5	Intake manifold	295
5.1	Assembly overview - intake manifold	295
5.2	Removing and installing intake manifold	295
5.3	Removing and installing throttle valve module GX3	296
6	Injectors	298
7	Senders and sensors	299



7.1	Assembly overview - pressure differential sender, vehicles with particulate filter	299
7.2	Removing and installing intake air temperature sender G42/intake manifold pressure sender G71	299
7.3	Removing and installing fuel pressure sender G247	300
7.4	Removing and installing fuel pressure sender for low pressure G410	300
7.5	Removing and installing pressure differential sender for particulate filter G1037 - vehicles with particulate filter	300
8	High-pressure pump	301
8.1	Assembly overview - high-pressure pump	301
8.2	Removing and installing high-pressure pump	301
8.3	Removing and installing high-pressure pipe	301
9	Lambda probe	303
9.1	Assembly overview - Lambda probe	303
9.2	Removing and installing Lambda probe	303
10	Engine control unit	304
10.1	Assembly overview - engine control unit	304
10.2	Removing and installing engine control unit J623	304
26	- Exhaust system	306
1	Safety information	306
2	Exhaust pipes/silencers	307
2.1	Assembly overview - silencers	307
2.2	Removing and installing front silencers	311
2.3	Separating exhaust pipes/silencers	312
2.4	Removing and installing silencers	313
2.5	Stress-free alignment of exhaust system	318
2.6	Checking exhaust system for leaks	318
3	Emission control system	319
3.1	Assembly overview - emission control system	319
3.2	Removing and installing catalytic converter	323
3.3	Removing and installing particulate filter	325
3.4	Removing and installing exhaust flap control unit J883	328
4	Exhaust gas temperature regulation	329
4.1	Removing and installing exhaust gas temperature sender 3 G495 - vehicles with particulate filter	329
28	- Ignition system	330
1	Safety information	330
2	Ignition system	331
2.1	Assembly overview - ignition system	331
2.2	Removing and installing ignition coil	331
2.3	Removing and installing knock sensor 1 G61	334
2.4	Removing and installing Hall senders	334
2.5	Removing and installing engine speed sender G28	334
93	- Electric drive systems	335
1	Safety information	335
2	High-voltage components	336
2.1	Overview of fitting locations - high-voltage components	336
3	Warning stickers	339
3.1	Checking warning stickers	339
4	High-voltage battery unit	343
4.1	Assembly overview - high-voltage battery (installed)	343
4.2	Determining mean cell voltage	346
4.3	Charging and discharging battery modules	348

4.4	Leak test for hybrid battery unit AX1	349
4.5	Checking high-voltage battery for leaks	356
4.6	Inspecting and classifying hybrid battery unit AX1	356
4.7	Removing and installing hybrid battery unit AX1	357
4.8	Removing and installing battery regulation control unit J840	368
4.9	Removing and installing switching unit for high-voltage battery SX6	369
5	High-voltage battery components	373
5.1	Assembly overview - components of hybrid battery unit AX1	373
5.2	Overview of fitting locations - battery modules	379
5.3	Removing battery module	381
5.4	Installing battery module	394
6	Power and control electronics for electric drive	405
6.1	Overview of fitting locations - power and control electronics for electric drive	405
6.2	Removing and installing power and control electronics for electric drive	408
6.3	Removing and installing bracket for power and control electronics for electric drive JX1 ..	412
7	Electric drive motor	416
7.1	Assembly overview - electric drive motor	416
7.2	Removing and installing three-phase current drive VX54	419
7.3	Removing and installing centring sleeve	419
7.4	Removing and installing drive motor temperature sender G712	421
7.5	Removing and installing drive motor rotor position sender 1 G713	422
7.6	Removing and installing torsion damper	423
7.7	Removing and installing actuator for disengagement clutch V606	425
7.8	Removing and installing coolant connection	427
7.9	Transporting three-phase current drive	429
7.10	Checking free movement of disengagement clutch	430
8	High-voltage wiring	432
8.1	Overview of fitting locations - high-voltage wiring	432
8.2	Removing and installing high-voltage wiring harness for high-voltage battery	439
8.3	Removing and installing high-voltage wiring harness for drive motor and electrical air conditioner compressor	441
8.4	Removing and installing high-voltage wire for high-voltage heater (PTC)	446
9	De-energising high-voltage system	450
10	Re-energising high-voltage system	453
11	Potential equalisation lines	455
11.1	General notes - potential equalisation lines	455
11.2	Overview of fitting locations - potential equalisation lines	455
11.3	Potential equalisation measurement	456
11.4	Removing and installing potential equalisation lines	457
12	Charging socket	464
12.1	Assembly overview - charging socket	464
12.2	e-tron charging system	465
12.3	Diagnosis of e-tron charging system	466
12.4	Removing and installing high-voltage battery charging socket 1 UX4	469
12.5	Removing and installing module for battery charge selector buttons EX32	472
13	Charging unit for high-voltage battery	474
13.1	Assembly overview - charging unit for high-voltage battery	474
13.2	Removing and installing charging unit 1 for high-voltage battery AX4	474
13.3	Removing and installing bracket for charging unit 1 for high-voltage battery AX4	480
14	Vehicle noise/engine sound	482
14.1	Overview of fitting locations - vehicle noise/engine sound	482
14.2	Removing and installing engine sound generator control unit J943	482
14.3	Removing and installing actuator 1 for engine sound generator R257	483
14.4	Removing and installing fan for engine sound generator control unit V719	485