

Contents

00 - Technical data	1
1 Identification	1
1.1 Engine number/engine data	1
2 Safety information	2
2.1 Safety precautions when working on the fuel supply system	2
2.2 Safety precautions when using testers and measuring instruments during a road test	3
2.3 Safety precautions when working on vehicles with start/stop system	3
2.4 Safety precautions when working on the cooling system	3
2.5 Safety precautions when working on the exhaust system	4
2.6 Safety precautions when working on the SCR system	5
3 Repair instructions	7
3.1 Rules for cleanliness	7
3.2 General notes	7
3.3 General repair instructions	8
3.4 Performing adaptions after renewing a component	9
3.5 Cleaning engine	9
3.6 Bolts/nuts	9
3.7 Identification plates	9
3.8 Use of impact wrenches	10
3.9 Foreign material in engine	10
3.10 Contact corrosion	11
3.11 Routing and attachment of pipes, hoses and wiring	11
3.12 Installing radiators and condensers	11
10 - Removing and installing engine	12
1 Removing and installing engine	12
1.1 Removing engine	12
1.2 Separating engine and gearbox	12
1.3 Securing engine to engine and gearbox support	20
1.4 Installing engine	22
2 Assembly mountings	23
3 Engine cover panel	24
3.1 Removing and installing engine cover panel	24
13 - Crankshaft group	25
1 Cylinder block (pulley end)	25
1.1 Assembly overview - cylinder block (pulley end)	25
1.2 Assembly overview - sealing flange (pulley end)	28
1.3 Removing and installing poly V-belt	30
1.4 Removing and installing poly V-belt tensioner	31
1.5 Removing and installing vibration damper	32
1.6 Removing and installing bracket for ancillaries	32
1.7 Removing and installing engine support	34
1.8 Removing and installing sealing flange (pulley end)	34
2 Cylinder block (gearbox end)	38
2.1 Assembly overview - cylinder block (gearbox end)	38
2.2 Removing and installing flywheel	40
2.3 Renewing cylinder block cover (gearbox end)	42
2.4 Removing and installing sealing flange (gearbox end)	43
3 Crankshaft	64
3.1 Assembly overview - crankshaft	64
3.2 Crankshaft dimensions	65



3.3	Measuring axial clearance of crankshaft	66
3.4	Renewing needle bearing in crankshaft	67
4	Pistons and conrods	70
4.1	Assembly overview - pistons and conrods	70
4.2	Removing and installing pistons	74
4.3	Measuring piston projection at TDC	76
4.4	Checking pistons and cylinder bores	78
4.5	Checking radial clearance of conrod bearings	80
15 - Cylinder head, valve gear		81
1	Toothed belt drive	81
1.1	Assembly overview - toothed belt guard	81
1.2	Assembly overview - toothed belt	82
1.3	Removing and installing toothed belt guard	84
1.4	Detaching toothed belt from camshaft	90
1.5	Removing and installing toothed belt	98
2	Cylinder head	111
2.1	Assembly overview - cylinder head	111
2.2	Assembly overview - cylinder head cover	115
2.3	Removing and installing cylinder head cover	117
2.4	Removing and installing seals for injectors	119
2.5	Removing and installing camshaft housing	120
2.6	Removing and installing cylinder head	127
2.7	Checking compression	135
3	Valve gear	138
3.1	Assembly overview - valve gear	138
3.2	Removing and installing camshaft oil seal	140
3.3	Removing and installing valve stem oil seals	143
4	Inlet and exhaust valves	154
4.1	Checking valve guides	154
4.2	Checking valves	155
4.3	Valve dimensions	155
17 - Lubrication		156
1	Sump/oil pump	156
1.1	Assembly overview - sump/oil pump	156
1.2	Engine oil	158
1.3	Removing and installing sump	158
1.4	Removing and installing oil pump	163
1.5	Removing and installing oil level and oil temperature sender G266	164
2	Engine oil cooler	166
3	Oil filter/oil pressure switches	167
3.1	Assembly overview - oil filter housing/oil pressure switches	167
3.2	Removing and installing oil filter housing	169
3.3	Removing and installing oil pressure switch F22	172
3.4	Removing and installing oil pressure switch for reduced oil pressure F378	174
3.5	Removing and installing valve for oil pressure control N428	175
3.6	Checking oil pressure	176
19 - Cooling		178
1	Cooling system/coolant	178
1.1	Connection diagram - coolant hoses	178
1.2	Checking cooling system for leaks	178
1.3	Draining and filling cooling system	181
2	Coolant pump/thermostat assembly	182

2.1	Assembly overview - coolant pump/thermostat	182
2.2	Assembly overview - electric coolant pump	186
2.3	Assembly overview - coolant temperature senders	186
2.4	Removing and installing electric coolant pump	187
2.5	Removing and installing coolant pump	187
2.6	Removing and installing thermostat	189
2.7	Checking thermostat	193
2.8	Removing and installing coolant valve for cylinder head N489	193
2.9	Removing and installing coolant temperature sender G62	194
3	Coolant pipes	197
4	Radiators/radiator fans	198
21 - Turbocharging/supercharging	199	
1	Turbocharger	199
1.1	Assembly overview - turbocharger	199
1.2	Removing and installing turbocharger	207
1.3	Renewing vacuum unit for turbocharger	211
2	Charge air system	222
2.1	Assembly overview - charge air system	222
2.2	Assembly overview - hose connections for charge air system	224
2.3	Removing and installing charge pressure sender G31	225
2.4	Removing and installing charge air temperature sender	225
2.5	Checking charge air system for leaks	226
23 - Mixture preparation - injection	232	
1	Injection system	232
1.1	Overview - fuel system	232
1.2	Overview of fitting locations - injection system	233
1.3	Filling and bleeding fuel system	233
1.4	Checking fuel system for leaks	234
2	Vacuum system	235
2.1	Connection diagram - vacuum system	235
2.2	Checking vacuum system	236
3	Air filter	237
4	Intake manifold	238
4.1	Assembly overview - intake manifold	238
4.2	Removing and installing throttle valve module J338	241
4.3	Removing and installing intake manifold	244
5	Injectors/high-pressure reservoir (rail)	249
5.1	Assembly overview - injectors	249
5.2	Assembly overview - high-pressure reservoir (rail)	252
5.3	Checking injectors	254
5.4	Performing adaption of correction values for injectors	254
5.5	Checking for injectors sticking open	255
5.6	Checking return flow rate of injectors with engine running	258
5.7	Checking return flow rate of injectors at starter cranking speed	261
5.8	Removing and installing injectors	263
5.9	Removing and installing high-pressure pipes	267
5.10	Removing and installing high-pressure reservoir (rail)	271
6	High-pressure pump	273
6.1	Assembly overview - high-pressure pump	273
6.2	Removing and installing high-pressure pump	275
7	Senders and sensors	280
7.1	Removing and installing air mass meter G70	280



7.2	Removing and installing fuel temperature sender G81	282
7.3	Checking fuel pressure regulating valve N276	282
7.4	Removing and installing fuel pressure regulating valve N276	284
7.5	Removing and installing fuel pressure sender G247	286
7.6	Removing and installing pressure differential sender G505	287
7.7	Removing and installing exhaust gas pressure sensor 1 G450	288
8	Lambda probe	290
8.1	Assembly overview - Lambda probe	290
8.2	Removing and installing Lambda probe	295
8.3	Removing and installing NOx senders	298
9	Engine control unit	303
26	- Exhaust system	304
1	Exhaust pipes/silencer	304
1.1	Assembly overview - silencer	304
1.2	Removing and installing front exhaust pipe	304
1.3	Separating exhaust pipes/silencer	304
1.4	Removing and installing rear silencer	304
1.5	Stress-free alignment of exhaust system	304
1.6	Checking exhaust system for leaks	304
2	Emission control system	305
2.1	Assembly overview - emission control system	305
2.2	Removing and installing emission control module	309
2.3	Removing and installing particulate filter	321
2.4	Removing and installing catalytic converter	321
2.5	Removing and installing exhaust flap control unit J883	323
3	SCR (selective catalytic reduction) system	325
3.1	Assembly overview - reducing agent tank	325
3.2	Assembly overview - reducing agent supply line	325
3.3	Assembly overview - delivery unit for reducing agent	327
3.4	Disconnecting reducing agent supply line	328
3.5	Releasing pressure in SCR system	333
3.6	Draining reducing agent tank	333
3.7	Removing and installing reducing agent tank	333
3.8	Removing and installing delivery unit for reducing agent	334
3.9	Removing and installing injector for reducing agent N474	335
3.10	Removing and installing control unit for reducing agent heater J891	338
4	Exhaust gas temperature regulation	339
4.1	Assembly overview - exhaust gas temperature regulation	339
4.2	Removing and installing exhaust gas temperature senders	343
5	Exhaust gas recirculation	352
5.1	Assembly overview - exhaust gas recirculation system	352
5.2	Assembly overview - exhaust gas recirculation system	355
5.3	Removing and installing exhaust gas recirculation control motor V338	357
5.4	Removing and installing exhaust gas recirculation control motor 2 V339	358
5.5	Removing and installing exhaust gas recirculation temperature sensor G98	362
5.6	Removing and installing exhaust gas recirculation cooler	363
5.7	Checking exhaust gas recirculation cooler for leaks	369
28	- Glow plug system	375
1	Glow plug system	375
1.1	Assembly overview - glow plug system	375
1.2	Removing and installing glow plug	377
1.3	Removing and installing automatic glow period control unit J179	381
1.4	Removing and installing Hall sender G40	381

1.5	Removing and installing engine speed sender G28	382
-----	---	-----