

## Contents

<b>00 - Technical data</b> .....	<b>1</b>
<b>1 General notes</b> .....	<b>1</b>
1.1 Type plates .....	1
1.2 Notes on odours in vehicles with air conditioner .....	3
1.3 Seat heating .....	5
1.4 Heated rear window .....	9
1.5 Radiator fan .....	12
1.6 Ambient temperature indicator G106 .....	13
1.7 Checking pressure signal from high-pressure sender G65 .....	13
<b>2 Safety precautions</b> .....	<b>18</b>
2.1 Safety precautions when handling refrigerants .....	18
2.2 Safety precautions when working on vehicles with start/stop system .....	20
2.3 Safety precautions when using testers and measuring instruments during a road test .....	20
2.4 Safety precautions when working on the cooling system .....	21
<b>3 Repair instructions</b> .....	<b>22</b>
3.1 Rules for cleanliness .....	22
3.2 General notes .....	22
3.3 General repair instructions .....	23
3.4 Contact corrosion .....	24
3.5 Routing and attaching pipes and wiring .....	24
3.6 Installing radiators and condensers .....	24
3.7 Checking heating output .....	25
3.8 Checking cooling output .....	34
3.9 Discharging refrigerant circuit .....	49
3.10 Working on refrigerant circuit .....	50
3.11 Notes on general repairs .....	51
3.12 Paint repairs on vehicles with air conditioning system .....	53
3.13 Refrigerant circuit seals .....	53
3.14 Notes on control motors .....	54
3.15 Notes on dust and pollen filter .....	59
<b>4 Technical data</b> .....	<b>60</b>
4.1 Refrigerant capacities .....	60
4.2 Approved refrigerant oils and refrigerant oil capacities .....	62
4.3 Oil distribution .....	66
<b>80 - Heating</b> .....	<b>67</b>
<b>1 Overview of fitting locations - heater</b> .....	<b>67</b>
1.1 Overview of fitting locations - components not located in passenger compartment .....	67
1.2 Overview of fitting locations - components in passenger compartment (front) .....	67
<b>2 Heater</b> .....	<b>69</b>
2.1 Exploded view - heater unit .....	69
2.2 Removing and installing fresh air blower V2 .....	69
2.3 Removing and installing fresh air blower series resistor with overheating fuse N24 .....	70
2.4 Removing and installing auxiliary air heater element Z35 .....	70
2.5 Removing and installing temperature flap control motor V68 with potentiometer G92 .....	70
2.6 Removing and installing air recirculation flap control motor V113 .....	70
2.7 Removing and installing centre flap control motor V70 .....	71
2.8 Removing and installing dust and pollen filter .....	71
2.9 Removing and installing heat exchanger .....	71
2.10 Removing and installing heater unit .....	71
2.11 Dismantling and assembling heater unit .....	72
<b>3 Air duct system</b> .....	<b>73</b>



3.1	Exploded view - routing of air flow and air distribution in passenger compartment	73
3.2	Removing and installing vents (front)	73
3.3	Removing and installing fresh air intake	73
3.4	Checking forced ventilation vents in passenger compartment	73
3.5	Removing and installing forced ventilation vents in passenger compartment	73
3.6	Checking plenum chamber water drain	74
<b>4</b>	<b>Operating and display unit</b>	<b>75</b>
4.1	Overview of fitting locations - operating and display unit J65	75
4.2	Removing and installing operating and display unit J65	75
<b>5</b>	<b>Further control components</b>	<b>76</b>
5.1	Removing and installing ambient temperature sensor G17	76
5.2	Removing and installing evaporator output temperature sender G263	76
<b>87</b>	<b>Air conditioning system</b>	<b>77</b>
<b>1</b>	<b>Overview of fitting locations - air conditioner</b>	<b>77</b>
1.1	Overview of fitting locations - components not located in passenger compartment	77
1.2	Overview of fitting locations - components in passenger compartment (front)	83
<b>2</b>	<b>Refrigerant circuit</b>	<b>87</b>
2.1	System overview - refrigerant circuit	87
2.2	Exploded view - condenser	91
2.3	Removing and installing high-pressure sender G65	96
2.4	Checking cut-in signal for air conditioner compressor regulating valve N280	97
2.5	Detaching and attaching refrigerant lines at expansion valve	101
2.6	Removing and installing expansion valve	103
2.7	Detaching and attaching refrigerant lines at condenser	105
2.8	Removing and installing condenser	107
2.9	Removing and installing grommet for refrigerant lines	109
2.10	Removing and installing receiver	110
2.11	Removing and installing desiccant bag/desiccant cartridge	112
2.12	Differences in service connections depending on refrigerant (R134a or R1234yf)	120
2.13	Removing and installing service connections (low and high-pressure sides)	123
2.14	Starting up air conditioner after charging refrigerant circuit	125
<b>3</b>	<b>Air conditioner compressor</b>	<b>128</b>
3.1	Exploded view - drive unit for air conditioner compressor	128
3.2	Exploded view - pulley	133
3.3	Detaching and attaching air conditioner compressor at bracket	145
3.4	Detaching and attaching refrigerant lines at air conditioner compressor	149
3.5	Removing and installing air conditioner compressor	151
3.6	Preparations for renewing pulley	154
3.7	Removing and installing pulley	154
<b>4</b>	<b>Control motors</b>	<b>164</b>
4.1	Exploded view - control motors (front)	164
4.2	Removing and installing temperature flap control motor V68	168
4.3	Removing and installing centre flap control motor V70	171
4.4	Removing and installing defroster flap control motor V107	173
4.5	Removing and installing air recirculation flap control motor V113	176
4.6	Removing and installing left temperature flap control motor V158	181
4.7	Removing and installing right temperature flap control motor V159	184
<b>5</b>	<b>Heater and air conditioning unit (front)</b>	<b>187</b>
5.1	Exploded view - attachments for heater and air conditioning unit and air intake box	187
5.2	Exploded view - flaps and partitions in air distribution housing	192
5.3	Exploded view - evaporator housing	193
5.4	Removing and installing evaporator	194
5.5	Cleaning evaporator	195
5.6	Checking auxiliary air heater element Z35	204

5.7	Removing and installing auxiliary air heater element Z35	206
5.8	Removing and installing heater and air conditioning unit	208
5.9	Removing and installing air intake box of heater and air conditioning unit	214
5.10	Removing and installing air distribution housing	214
5.11	Removing and installing dust and pollen filter	215
5.12	Removing and installing fresh air blower V2	216
5.13	Removing and installing fresh air blower series resistor with overheating fuse N24	217
5.14	Removing and installing fresh air blower control unit J126	218
5.15	Removing and installing heat exchanger	219
5.16	Checking condensation drain	227
5.17	Removing and installing condensation drain	229
<b>6</b>	<b>Air duct system</b>	<b>230</b>
6.1	Exploded view - routing of air flow and air distribution in passenger compartment	230
6.2	Air intake and air outlet openings	233
6.3	Removing and installing footwell vent (driver side)	236
6.4	Removing and installing footwell vent (front passenger side)	236
6.5	Removing and installing rear footwell vent	237
6.6	Removing and installing air ducts	238
6.7	Checking forced ventilation vents in passenger compartment	242
6.8	Removing and installing forced ventilation vents in passenger compartment	244
6.9	Removing and installing cover for fresh air intake	245
6.10	Removing and installing fresh air intake	246
6.11	Checking plenum chamber water drain	246
6.12	Cleaning plenum chamber water drain	247
<b>7</b>	<b>Operating and display unit</b>	<b>248</b>
7.1	Overview - operating and display unit	248
7.2	Removing and installing operating and display unit	253
7.3	Removing and installing temperature sensor blower	256
<b>8</b>	<b>Further control components</b>	<b>258</b>
8.1	Removing and installing sunlight penetration photosensor G107	258
8.2	Operation of air quality sensor G238	259
8.3	Removing and installing air quality sensor G238	264
8.4	Removing and installing ambient temperature sensor G17	264
8.5	Removing and installing left vent temperature sender G150	265
8.6	Removing and installing right vent temperature sender G151	265
8.7	Removing and installing left footwell vent temperature sender G261	266
8.8	Removing and installing right footwell vent temperature sender G262	267
8.9	Removing and installing evaporator output temperature sender G263	267
8.10	Removing and installing humidity sender G355	268
8.11	Removing and installing continued coolant circulation pump V51 / auxiliary pump for heating V488	270