

Contents

00 - Technical data	1
1 Safety precautions	1
1.1 Safety precautions when working on air conditioners	1
1.2 Safety precautions when handling refrigerants	1
1.3 Safety precautions when working on vehicles with high-voltage system	2
1.4 Safety precautions when working in the vicinity of high-voltage components	2
1.5 Safety precautions when working on vehicles with start/stop system	3
1.6 Safety precautions when using testers and measuring instruments during a road test	3
1.7 Safety precautions when working on the cooling system	4
1.8 Safety precautions when working on vehicles with auxiliary/supplementary heater	4
2 Identification	5
2.1 Identification of heater and air conditioning unit	5
3 General notes	6
3.1 Type plates	6
3.2 Notes on odours in vehicles with air conditioner	7
4 Repair instructions	8
4.1 Rules for cleanliness	8
4.2 General notes	8
4.3 Contact corrosion	8
4.4 Routing and attachment of pipes, hoses and wiring	9
4.5 Installing radiators and condensers	9
4.6 Working on refrigerant circuit	9
4.7 Paintwork repairs on vehicles with air conditioning system	10
4.8 Refrigerant circuit seals	10
4.9 Notes on high-voltage components and potential equalisation lines	11
4.10 Use of impact wrenches	11
4.11 Identification plates	12
5 Technical data	13
5.1 Refrigerant capacities	13
5.2 Approved refrigerant oils and refrigerant oil capacities	13
5.3 Oil distribution	17
80 - Heating	18
1 Safety precautions	18
2 Overview of fitting locations - heater	19
87 - Air conditioning system	20
1 Safety precautions	20
2 Overview of fitting locations - air conditioner	21
2.1 Overview of fitting locations - components not located in passenger compartment	21
2.2 Overview of fitting locations - components in passenger compartment (front)	25
3 Refrigerant circuit	28
3.1 System overview - refrigerant circuit	28
3.2 Exploded view - refrigerant lines	32
3.3 Exploded view - condenser	40
3.4 Exploded view - heat exchanger for high-voltage battery	42
3.5 Removing and installing pressure sender for refrigerant circuit G805	43
3.6 Checking air conditioner compressor regulating valve N280 and air conditioner compressor	44
3.7 Removing and installing refrigerant shut-off valve for heater and air conditioning unit N541	45

3.8	Removing and installing refrigerant shut-off valve for high-voltage battery heat exchanger N542	50
3.9	Removing and installing heat exchanger for high-voltage battery	53
3.10	Removing and installing expansion valve	57
3.11	Detaching and attaching refrigerant lines at condenser	59
3.12	Removing and installing condenser	64
3.13	Removing and installing desiccant bag/desiccant cartridge	67
3.14	Removing and installing refrigerant lines	73
3.15	Removing and installing refrigerant lines with internal heat exchanger	83
3.16	Removing and installing service connections (low and high-pressure sides)	86
3.17	Starting up air conditioner after charging refrigerant circuit	88
4	Air conditioner compressor	89
4.1	Exploded view - air conditioner compressor	89
4.2	Exploded view - pulley	93
4.3	Detaching and attaching air conditioner compressor at bracket	95
4.4	Detaching and attaching refrigerant lines at air conditioner compressor	100
4.5	Removing and installing air conditioner compressor	108
4.6	Removing and installing pulley	112
5	Control motors	116
5.1	Overview of fitting locations - control motors (front)	116
5.2	Exploded view - control motors (front)	123
5.3	Notes on control motors	128
5.4	Removing and installing temperature flap control motor V68	129
5.5	Removing and installing defroster flap control motor V107	131
5.6	Removing and installing air recirculation flap control motor V113	133
5.7	Removing and installing left temperature flap control motor V158	137
5.8	Removing and installing right temperature flap control motor V159	139
5.9	Removing and installing rear temperature flap control motor V137	141
5.10	Removing and installing fresh air/air recirculation, air flow flap control motor V425	143
5.11	Removing and installing actuator for fresh air/air recirculation, air flow flap	149
5.12	Removing and installing air distribution flap control motor V428	150
5.13	Removing and installing front air distribution flap control motor V426	153
5.14	Removing and installing actuator for air distribution flap	157
5.15	Removing and installing actuator for rear temperature flap	161
6	Front heater and air conditioning unit	163
6.1	Exploded view - heater and air conditioning unit	163
6.2	Exploded view - attachments for heater and air conditioning unit and air intake box	165
6.3	Exploded view - evaporator housing	167
6.4	Exploded view - flaps and partitions in air distribution housing	168
6.5	Removing and installing evaporator	172
6.6	Removing and installing evaporator output temperature sender G263	173
6.7	Removing and installing heater and air conditioning unit	174
6.8	Removing and installing retainers for heater and air conditioning unit	178
6.9	Dismantling and assembling heater and air conditioning unit	179
6.10	Removing and installing air distribution housing	181
6.11	Removing and installing dust and pollen filter	182
6.12	Removing and installing fresh air blower V2	185
6.13	Removing and installing fresh air blower control unit J126	186
6.14	Removing and installing auxiliary air heater element Z35	187
6.15	Removing and installing heat exchanger	188
6.16	Removing and installing coolant pipes at heat exchanger	193
6.17	Checking condensation drain hose	195
6.18	Removing and installing condensation drain hose	198
7	Air duct	202
7.1	Exploded view - routing of air flow and air distribution in passenger compartment	202

7.2	Removing and installing footwell vent (driver side)	204
7.3	Removing and installing footwell vent (front passenger side)	204
7.4	Removing intermediate piece for air duct to footwell vent	205
7.5	Removing and installing air duct for vent (defrost function)	205
7.6	Removing and installing air duct for dash panel vent (centre)	206
7.7	Removing and installing rear footwell vent	207
7.8	Removing and installing air ducts	208
7.9	Removing and installing intake duct	209
7.10	Removing and installing cover for fresh air intake	210
7.11	Removing and installing fresh air intake	211
7.12	Checking forced ventilation vents in passenger compartment	213
7.13	Removing and installing forced ventilation vents in passenger compartment	215
7.14	Checking plenum chamber water drain	216
8	Coolant circuit	217
8.1	Exploded view - high-voltage heater (PTC) Z115 (with high-voltage heater (PTC) control unit J848)	217
8.2	Removing and installing high-voltage heater (PTC) Z115 (with high-voltage heater (PTC) control unit J848)	218
9	Operating and display unit	225
9.1	Overview of fitting locations - operating and display unit	225
9.2	Removing and installing operating and display unit	225
10	Further control components	228
10.1	Removing and installing footwell vent temperature sender G192	228
10.2	Removing and installing left vent temperature sender G150	229
10.3	Removing and installing right vent temperature sender G151	230
10.4	Removing and installing sunlight penetration photosensor G107	230
10.5	Removing and installing ambient temperature sensor G17	231
10.6	Removing and installing air quality sensor G238	231
10.7	Removing and installing humidity sender G355	232
10.8	Removing and installing air conditioner sensor for fine particle concentration G930	232