

Contents

00 - Technical data	1
1 Identification	1
1.1 Engine number/engine data	1
2 Safety information	2
2.1 Safety precautions when working on the fuel system	2
2.2 Safety precautions when using testers and measuring instruments during a road test	3
2.3 Safety precautions when working on the cooling system	3
2.4 Safety precautions when working on vehicles with start/stop system	3
2.5 Safety precautions when working on the SCR system	4
2.6 Safety precautions when working on the exhaust system	4
2.7 Safety precautions when working on the subframe	5
3 Repair instructions	6
3.1 Rules for cleanliness	6
3.2 General notes	6
3.3 General repair instructions	7
3.4 Resetting SCR learnt values	7
3.5 Nuts, bolts	8
3.6 Identification plates	8
3.7 Use of impact wrenches	8
3.8 Contact corrosion	9
3.9 Foreign material in engine	9
3.10 Routing and attachment of pipes, hoses and wiring	10
3.11 Installing radiators and condensers	10
10 - Removing and installing engine	11
1 Removing and installing engine	11
1.1 Removing engine	11
1.2 Securing engine to engine and gearbox support	41
1.3 Installing engine	42
2 Assembly mountings	53
2.1 Assembly overview - assembly mountings	53
2.2 Removing and installing engine mountings	54
2.3 Removing and installing torque reaction support and cross member	58
3 Engine cover panel	62
3.1 Removing and installing engine cover panel	62
13 - Crankshaft group	63
1 Cylinder block (pulley end)	63
1.1 Assembly overview - poly V-belt drive	63
1.2 Assembly overview - sealing flange (pulley end)	69
1.3 Removing and installing poly V-belt	70
1.4 Removing and installing poly V-belt tensioner	73
1.5 Removing and installing vibration damper	76
1.6 Removing and installing bracket for ancillaries	77
1.7 Renewing crankshaft oil seal (pulley end)	81
1.8 Removing and installing sealing flange (pulley end)	83
2 Cylinder block (gearbox end)	88
2.1 Assembly overview - cylinder block (gearbox end)	88
2.2 Removing and installing drive plate	89
2.3 Removing and installing sealing flange (gearbox end)	90
2.4 Renewing needle bearing in drive plate	101
3 Crankshaft	103



3.1	Assembly overview - crankshaft	103
3.2	Crankshaft dimensions	104
3.3	Measuring axial clearance of crankshaft	104
3.4	Measuring radial clearance of crankshaft	105
3.5	Pulling spur gear off crankshaft and shrink-fitting new spur gear	105
4	Pistons and conrods	109
4.1	Assembly overview - pistons and conrods	109
4.2	Removing and installing pistons	113
4.3	Measuring piston projection at TDC	114
4.4	Checking pistons and cylinder bores	116
4.5	Checking radial clearance of conrod bearings	118
15	Cylinder head, valve gear	119
1	Cylinder head	119
1.1	Assembly overview - cylinder head	119
1.2	Assembly overview - cylinder head cover	123
1.3	Removing and installing cylinder head	125
1.4	Removing and installing cylinder head cover	139
1.5	Checking compression	143
1.6	Removing and installing seals for injectors	145
2	Toothed belt drive	147
2.1	Assembly overview - toothed belt	147
2.2	Removing and installing toothed belt	149
3	Valve gear	162
3.1	Assembly overview - valve gear	162
3.2	Measuring axial clearance of camshaft	164
3.3	Measuring radial clearance of camshaft	165
3.4	Removing and installing camshaft oil seal	166
3.5	Removing and installing camshaft	169
3.6	Removing and installing valve stem oil seals	179
4	Inlet and exhaust valves	188
4.1	Reworking valve seats	188
4.2	Checking valve guides	188
4.3	Checking valves	189
4.4	Valve dimensions	189
17	Lubrication	190
1	Sump/oil pump	190
1.1	Assembly overview - sump/oil pump	190
1.2	Engine oil	195
1.3	Removing and installing sump	195
1.4	Removing and installing oil pump	200
1.5	Removing and installing oil level and oil temperature sender G266	202
2	Engine oil cooler	203
2.1	Removing and installing engine oil cooler	203
3	Oil filter/oil pressure switches	204
3.1	Exploded view - oil filter housing/oil pressure switch	204
3.2	Removing and installing oil pressure switch F1	205
3.3	Checking oil pressure and oil pressure switch	207
3.4	Removing and installing oil filter housing	209
3.5	Checking oil level	211
4	Balance shaft module	212
4.1	Removing and installing balance shaft module	212
19	Cooling	221

1	Cooling system/coolant	221
1.1	Connection diagram - coolant hoses	221
1.2	Checking cooling system for leaks	224
1.3	Draining and filling cooling system	227
2	Coolant pump/thermostat assembly	236
2.1	Assembly overview - coolant pump/thermostat	236
2.2	Assembly overview - coolant circulation pump V50	237
2.3	Assembly overview - pump for exhaust gas recirculation cooler V400	237
2.4	Removing and installing coolant circulation pump V50	238
2.5	Removing and installing coolant pump	240
2.6	Checking thermostat	240
2.7	Removing and installing 4/2-way valve with thermostat	240
2.8	Removing and installing coolant temperature sender G62	244
2.9	Removing and installing radiator outlet coolant temperature sender G83	245
2.10	Removing and installing pump for exhaust gas recirculation cooler V400	246
3	Coolant pipes	249
3.1	Assembly overview - coolant pipes	249
3.2	Removing and installing coolant pipe (top left)	251
3.3	Removing and installing coolant pipe (bottom left)	252
3.4	Removing and installing coolant pipe (rear right)	254
3.5	Removing and installing coolant pipe (rear)	258
4	Radiator/radiator fans	261
4.1	Exploded view - radiator/radiator fans	261
4.2	Removing and installing radiator cowl with radiator fans	264
4.3	Removing and installing radiator cowl	269
4.4	Removing and installing radiator fan control unit J293	276
4.5	Removing and installing radiator fans	278
21	Turbocharging/supercharging	280
1	Turbocharger	280
1.1	Exploded view - turbocharger	280
1.2	Removing and installing turbocharger	282
2	Charge air system	292
2.1	Overview - charge air system	292
2.2	Assembly overview - charge air system	293
2.3	Removing and installing charge air cooler	295
2.4	Removing and installing charge pressure sender G31 / intake air temperature sender G42	299
2.5	Checking charge air system for leaks	299
23	Mixture preparation - injection	303
1	Injection system	303
1.1	Overview - fuel system	303
1.2	Overview of fitting locations - injection system	304
1.3	Filling and bleeding fuel system	314
1.4	Checking fuel system for leaks	315
2	Vacuum system	316
2.1	Checking vacuum system	316
3	Injectors/high-pressure reservoir (rail)	317
3.1	Assembly overview - injectors	317
3.2	Checking injectors	320
3.3	Performing adaptation of correction values for injectors	321
3.4	Checking for injectors sticking open	322
3.5	Checking return flow rate of injectors with engine running	324
3.6	Checking return flow rate of injectors at starter cranking speed	327
3.7	Removing and installing injectors	328



3.8	Removing and installing high-pressure pipes	334
3.9	Removing and installing high-pressure reservoir (rail)	335
3.10	Checking fuel pressure (low pressure)	338
4	Air filter	342
4.1	Assembly overview - air filter housing	342
4.2	Removing and installing air filter housing	344
5	Intake manifold	349
5.1	Exploded view - intake manifold	349
5.2	Removing and installing intake manifold	351
5.3	Removing and installing throttle valve module J338	355
5.4	Cleaning throttle valve module J338	356
6	Senders and sensors	358
6.1	Removing and installing fuel pressure regulating valve N276	358
6.2	Checking fuel pressure regulating valve N276	360
6.3	Removing and installing fuel pressure sender G247	361
6.4	Removing and installing air mass meter G70	364
6.5	Removing and installing NOx sender 2 G687	364
7	Engine control unit	366
7.1	Wiring and component check with test box V.A.G 1598/42	366
7.2	Removing and installing engine/motor control unit J623	368
8	High-pressure pump	373
8.1	Assembly overview - high-pressure pump	373
8.2	Removing and installing high-pressure pump	375
8.3	Performing first fuel filling after installing high-pressure pump	378
9	Lambda probe	380
9.1	Assembly overview - Lambda probe	380
9.2	Removing and installing Lambda probe	382
26 - Exhaust system		384
1	Exhaust pipes/silencers	384
1.1	Exploded view - silencers	384
1.2	Removing and installing front exhaust pipe	390
1.3	Separating exhaust pipes/silencers	392
1.4	Renewing tailpipes	393
1.5	Stress-free alignment of exhaust system	395
1.6	Checking exhaust system for leaks	397
2	Emission control system	398
2.1	Removing and installing SCR catalytic converter	398
2.2	Removing and installing particulate filter	399
2.3	Removing and installing pressure differential sender G505	403
3	SCR (selective catalytic reduction) system	405
3.1	Assembly overview - reducing agent tank	405
3.2	Assembly overview - control unit for reducing agent metering system J880	407
3.3	Assembly overview - delivery unit for reducing agent	407
3.4	Assembly overview - injector for reducing agent N474	409
3.5	Assembly overview - pump for reducing agent V437	410
3.6	Removing and installing reducing agent tank	411
3.7	Draining reducing agent tank	415
3.8	Removing and installing delivery unit for reducing agent	417
3.9	Removing and installing reducing agent supply line	423
3.10	Removing and installing injector for reducing agent N474	425
3.11	Removing and installing pump for reducing agent V437	426
3.12	Removing and installing control unit for reducing agent metering system J880	428
4	Exhaust gas temperature regulation	430

4.1	Assembly overview - exhaust gas temperature regulation	430
4.2	Removing and installing exhaust gas temperature sender	432
5	Exhaust gas recirculation	439
5.1	Assembly overview - exhaust gas recirculation system	439
5.2	Removing and installing exhaust gas recirculation cooler	441
5.3	Checking exhaust gas recirculation cooler change-over	445
5.4	Cleaning exhaust gas recirculation system	446
6	Exhaust manifold	455
6.1	Exploded view - exhaust manifold	455
6.2	Removing and installing exhaust manifold	456
28	Glow plug system	459
1	Glow plug system	459
1.1	Assembly overview - glow plug system	459
1.2	Removing and installing glow plug	459
1.3	Checking glow plug	461
1.4	Removing and installing engine speed sender G28	462
1.5	Removing and installing Hall sender G40	463