

## Contents

<b>00 - Technical data</b> .....	<b>1</b>
<b>1 General notes</b> .....	<b>1</b>
1.1 Checking cut-in signal for air conditioner compressor regulating valve N280 .....	1
1.2 Checking pressure signal from high-pressure sender G65 .....	4
1.3 Notes on operation of auxiliary/supplementary heater on vehicles with diesel engine .....	9
1.4 Seat heating .....	11
1.5 Heated rear window .....	12
<b>2 Safety precautions</b> .....	<b>13</b>
2.1 Safety precautions when handling refrigerants .....	13
<b>3 Repair instructions</b> .....	<b>14</b>
3.1 General notes .....	14
3.2 General repair instructions .....	14
3.3 Contact corrosion .....	15
3.4 Notes on Guided Fault Finding .....	15
3.5 Checking electrical components .....	16
3.6 Checking heating output .....	17
3.7 Checking cooling output .....	23
3.8 Working on refrigerant circuit .....	33
3.9 Discharging refrigerant circuit .....	34
3.10 Notes on general repairs .....	36
3.11 Paint repairs on vehicles with air conditioning system .....	38
3.12 Refrigerant circuit seals .....	38
3.13 Notes on control motors .....	38
3.14 Notes on dust and pollen filter .....	43
<b>4 Technical data</b> .....	<b>44</b>
4.1 Capacities .....	44
<b>80 - Heating</b> .....	<b>46</b>
<b>1 Overview of fitting locations - heater</b> .....	<b>46</b>
1.1 Overview of fitting locations - components not located in passenger compartment .....	46
1.2 Overview of fitting locations - components in passenger compartment (front) .....	47
1.3 General notes on heater .....	51
<b>2 Heater</b> .....	<b>52</b>
2.1 Exploded view - heater unit .....	52
2.2 Exploded view - attachments for heater unit .....	56
2.3 Exploded view - air intake box of heater unit .....	59
2.4 Removing and installing heater unit .....	60
<b>87 - Air conditioning system</b> .....	<b>61</b>
<b>1 Overview of fitting locations - air conditioner</b> .....	<b>61</b>
1.1 Overview of fitting locations - components not located in passenger compartment .....	61
1.2 Overview of fitting locations - components in passenger compartment (front) .....	65
1.3 General notes on air conditioning systems .....	69
<b>2 Refrigerant circuit</b> .....	<b>70</b>
2.1 System overview - refrigerant circuit .....	70
2.2 Removing and installing high-pressure sender G65 .....	78
2.3 Detaching and attaching refrigerant lines at expansion valve .....	80
2.4 Removing and installing expansion valve .....	84
2.5 Removing and installing condenser .....	85
2.6 Detaching and attaching refrigerant lines at condenser .....	93
2.7 Removing and installing receiver .....	94
2.8 Removing and installing desiccant bag/desiccant cartridge .....	98

2.9	Starting up air conditioner after charging refrigerant circuit	106
2.10	General notes on refrigerant circuit	108
<b>3</b>	<b>Air conditioner compressor</b>	<b>110</b>
3.1	Exploded view - pulley	110
3.2	Detaching and attaching air conditioner compressor at bracket	117
3.3	Detaching and attaching refrigerant lines at air conditioner compressor	123
3.4	Removing and installing air conditioner compressor	126
3.5	Preparations for renewing pulley	128
3.6	Removing and installing pulley	129
<b>4</b>	<b>Control motors</b>	<b>134</b>
4.1	Removing and installing centre flap control motor V70	134
4.2	Removing and installing air flow flap control motor V71	136
4.3	Removing and installing defroster flap control motor V107	142
4.4	Removing and installing air recirculation flap control motor V113	145
4.5	Removing and installing left temperature flap control motor V158	147
4.6	Removing and installing right temperature flap control motor V159	151
<b>5</b>	<b>Heater and air conditioning unit (front)</b>	<b>154</b>
5.1	Exploded view - attachments for heater and air conditioning unit and air intake box	154
5.2	Exploded view - heater and air conditioning unit	158
5.3	Exploded view - evaporator housing	164
5.4	Removing and installing evaporator	165
5.5	Cleaning evaporator	167
5.6	Checking auxiliary air heater element Z35	170
5.7	Removing and installing auxiliary air heater element Z35	171
5.8	Removing and installing heater and air conditioning unit	173
5.9	Removing and installing dust and pollen filter	179
5.10	Removing and installing fresh air blower V2	180
5.11	Removing and installing fresh air blower control unit J126	183
5.12	Removing and installing heat exchanger	184
5.13	Checking condensation drain	192
5.14	Removing and installing condensation drain	193
<b>6</b>	<b>Air duct system</b>	<b>194</b>
6.1	Exploded view - routing of air flow and air distribution in passenger compartment	194
6.2	Air intake and air outlet openings, routing of air flow	197
6.3	Removing and installing cover for fresh air intake	201
6.4	Removing and installing fresh air intake	202
6.5	Removing and installing intake duct	202
6.6	Removing and installing forced ventilation vents in passenger compartment	205
6.7	Checking forced ventilation vents in passenger compartment	206
6.8	Removing and installing plenum chamber water drain	207
6.9	Checking plenum chamber water drain	208
6.10	Cleaning plenum chamber water drain	208
6.11	Removing and installing dash panel vent	209
6.12	Flap in outlet to defroster vents of air conditioner air distribution housing	210
<b>7</b>	<b>Operating and display unit</b>	<b>211</b>
7.1	Removing and installing operating and display unit	211
7.2	Removing and installing temperature sensor blower	213
<b>8</b>	<b>Further control components</b>	<b>215</b>
8.1	Removing and installing sunlight penetration photosensor G107	215
8.2	Removing and installing front chest vent temperature sensors G385 / G386	216
8.3	Removing and installing left footwell vent temperature sender G261	216
8.4	Removing and installing right footwell vent temperature sender G262	217
8.5	Removing and installing evaporator output temperature sender G263	218