



Contents

00 - Technical data	1
1 Safety instructions	1
1.1 General safety instructions	1
1.2 Safety precautions when working on vehicles with start-stop system	2
1.3 Notes on tow starting and towing	2
1.4 Safety precautions during test drives in which testing and measuring equipment is used ..	2
2 Identification	4
2.1 Gearbox identification	4
3 Repair instructions	6
3.1 Rules of cleanliness	6
3.2 General repair instructions	6
3.3 Contact corrosion	10
3.4 Seals and sealing rings	10
3.5 Screws, nuts	11
4 Technical data	12
4.1 Filling capacity	12
4.2 Allocation gearbox - engine	12
4.3 Calculation of gear ratios	12
5 Transmission System - Overview	13
6 Electrical components	15
6.1 Fitting location summary - electrical components	15
30 - Clutch	17
1 Clutch operation	17
1.1 Summary of components - clutch actuator	17
1.2 Assembly overview - clutch release mechanism	17
1.3 Check ball pin for wear and renew if necessary	19
1.4 Removing and installing clutch actuator VX64	20
1.5 Repairing the clutch release mechanism	25
2 Clutch	28
2.1 Assembly overview - clutch	28
2.2 Removing and installing clutch	28
34 - Controls, housing	35
1 Shift mechanism	35
1.1 Overview - shift mechanism	35
1.2 Summary of components - gearshift knob and cover	35
1.3 Assembly overview of shift mechanism	36
1.4 Summary of components - gear actuator	38
1.5 Removing and installing gearshift knob	39
1.6 Installing and removing the transmission cover	41
1.7 Remove and install guide for shift lever, adjust	42
1.8 Removing and installing selector mechanism	43
1.9 Removing and installing gear actuator VX65	46
2 Removing and installing the gearbox	56
2.1 Tightening torques for gearbox	56
2.2 Removing the gearbox	56
2.3 Installing the gearbox	67
3 Assembly bracket	72
3.1 Unit mounting - summary of components	72
4 Transporting the gearbox	73



5	Disassembling and assembling the gearbox	75
5.1	Schematic overview - Gearbox	75
5.2	Summary of components - Gearbox	75
5.3	Summary of components - input shaft, output shafts, differential gear and shift rods	76
5.4	Disassembling and assembling the gearbox	78
6	Gearbox housing, clutch housing	86
6.1	Summary of components - Clutch housing	86
6.2	Summary of components - Gearbox housing and clutch housing	86
6.3	Repairing gearbox housing	88
7	Attachment at engine and gearbox mount	90
8	Gear oil	92
8.1	Checking gear oil level	92
8.2	Draining and filling gearbox oil	92
35 - Gears, shafts		95
1	Drive shaft	95
1.1	Summary of components - Drive shaft	95
1.2	Disassembling and assembling the drive shaft	97
1.3	Setting drive shaft	106
1.4	Replacing input shaft sealing ring	111
2	Output shaft	113
2.1	Summary of components - Output shaft	113
2.2	Disassembling and assembling the output shaft	116
2.3	Setting output shaft	131
3	Reverse shaft	136
3.1	Removing and installing reverse gear shaft	136
39 - Final drive - differential		137
1	Sealing rings	137
1.1	Installation overview - sealing rings	137
1.2	Replacing left sealing ring	137
1.3	Replacing right sealing ring	140
2	Differential	141
2.1	Summary of components - Differential	141
2.2	Disassembling and assembling differential gear	143
2.3	Adjusting the differential	152
3	Setting overview	157
4	Gearbox control system	158
4.1	Installation overview - gearbox control system	158
4.2	Removing and installing the control unit for electronic transmission J514	158
4.3	Removing and installing the gearbox input r.p.m. sender G182	159