

Contents

01 - Self-diagnosis	1
1 Self-diagnosis of air conditioning - I	1
1.1 Initiate self-diagnosis	1
1.2 Query event memory and erase	4
1.3 Final control diagnosis	5
1.4 Initiating basic setting	6
1.5 Ending output	7
2 Self-diagnosis of air conditioning - II	8
2.1 Fault table	8
3 Self-diagnosis of air conditioning - III	17
3.1 Reading measured value block	17
80 - Heating	24
1 Repair the heating unit	24
1.1 Summary of components	24
1.2 Assembly overview – heater unit	26
1.3 Disassembling and assembling the heater unit	27
1.4 Summary of components: heat exchanger, Heating element for air auxiliary heating (PTC) Z35	29
2 Removing and installing parts of the heating unit system - Part 1	30
2.1 Removing and installing fresh air blower V2	30
2.2 Removing and installing series resistor for fresh air blower N24	30
2.3 Removing and installing heater control	31
2.4 Removing and installing dust pollen filter	31
2.5 Removing and installing flex shafts	32
2.6 Removing and installing heat exchanger and heater element for additional air heating Z35	33
3 Removing and installing parts of the heating unit system - Part 2	36
3.1 Removing and installing heater unit	36
3.2 Removing and installing control motor of fresh air flap and re-circulating air flap V154 ..	38
3.3 Removing and installing the control motor for air distribution flaps	39
3.4 Removing and installing the positioning unit for temperature flap	41
87 - Air conditioning system	43
1 Instructions and safety measures for repair work on vehicles with air conditioning and when using refrigerant R 134a	43
2 Functional description of the air conditioner	44
2.1 Operation of the air conditioning system	44
2.2 Structure of the refrigerant circuit	44
2.3 Parts of the refrigerant circuit	45
2.4 Connections for quick coupler adapters on refrigerant circuit	47
2.5 Parts for securing the refrigerant circuit	48
3 Properties of refrigerant R134a and refrigerant oil	50
4 Contents	51
4.1 Refrigerant R134a	51
4.2 Refrigerant machine oil	51
5 Repairing the air conditioning system - engine compartment	53
5.1 Repairing the air conditioning system - engine compartment - summary of installation ..	53
5.2 Removing and installing refrigerant line - condenser input	56
5.3 Removing and installing refrigerant line - condenser output	57
5.4 Removing and installing exhaust valve - low-pressure side	57
5.5 Removing and installing extractor and filling valve - lowhigh-pressure side	58



5.6	Assembly overview of the dryer cartridge	58
5.7	Removing and installing the AC compressor from holder	59
5.8	Removing and installing the refrigerant lines from the AC compressor	60
5.9	Belt protection for blocked AC compressor	60
5.10	Holder for refrigerant lines	61
5.11	Removing and installing the refrigerant lines on the expansion valve	61
5.12	Check valve for condensation water drain	61
6	Removing and installing parts of the air conditioning system - engine compartment	63
6.1	Removing and installing, inspecting high pressure sender G65	63
6.2	Removing and installing the expansion valve	63
6.3	Inspecting the pressure relief valve on the AC compressor	64
6.4	Removing and installing AC compressor	64
6.5	Running-in instructions of the AC compressor	65
6.6	Removing and installing the condenser	66
6.7	Replace desiccator cartridge	66
7	Quick couplings for refrigerant lines	68
7.1	Separating quick couplings for refrigerant lines	68
8	Repairing the air conditioning system - passenger compartment	72
8.1	Assembly overview, passenger compartment	72
8.2	Summary of components of heating and air conditioning unit	75
8.3	Summary of components: heat exchanger and heating element for air auxiliary heating (PTC) Z35	77
8.4	Summary of components for heating and air conditioning system control	78
9	Dismantling and assembling heater and air conditioning unit	80
9.1	Summary of components of heating and air conditioning unit	80
9.2	Expansion valve - Summary of components	82
9.3	Removing and installing evaporator	83
10	Removing and installing parts of the heating and air conditioning unit	85
10.1	Removing and installing heater and air conditioning unit	85
10.2	Removing and fitting the heating and air conditioning system control	88
10.3	Removing and installing flex shaft for positioning unit of air distribution flaps	88
10.4	Removing and installing control motor of fresh air flap and re-circulating air flap V154 ..	89
10.5	Removing and installing the control motor of temperature flap V68	89