



Contents

00 - Technical data	1
1 Safety instructions	1
1.1 Safety precautions when working on vehicles with a start/stop system	1
1.2 Safety precautions during road tests in which testing and measuring equipment is used	1
1.3 General safety instructions	1
2 Identification	3
2.1 Gearbox identification	3
3 Repair instructions	4
3.1 Rules of cleanliness	4
3.2 General repair instructions	4
3.3 Contact corrosion	10
3.4 Seals and sealing rings	10
3.5 Screws, nuts	11
4 Technical data	12
4.1 Filling capacity	12
4.2 Allocation gearbox - engine	12
4.3 Calculation of gear ratios	12
5 Overview of Transmission System	13
5.1 Overview of power transmission - front-wheel drive	13
6 Electrical components	14
6.1 Fitting location summary - electrical components	14
30 - Clutch	16
1 Clutch operation	16
1.1 Summary of components - Foot controls	16
1.2 Assembly overview - clutch hydraulics	18
1.3 Assembly overview - clutch release mechanism	22
1.4 Removing and installing clutch pedal	24
1.5 Removing and installing the over-centre helper spring	27
1.6 Removing and installing the bearing bracket	29
1.7 Removing and installing bearing bush	33
1.8 Removing and installing the master cylinder	34
1.9 Removing and installing the slave cylinder	35
1.10 Removing and installing cables for clutch control	38
1.11 Bleeding the clutch control	43
1.12 Removing and installing clutch position sender G476	45
1.13 Checking the master and slave cylinder	47
1.14 Repairing the clutch release mechanism	49
2 Clutch	51
2.1 Assembly overview - clutch	51
2.2 Removing and installing clutch	55
34 - Controls, housing	70
1 Shift mechanism	70
1.1 Installation position - shift mechanism	70
1.2 Summary of components - gearshift knob and cover	71
1.3 Summary of components - Gearshift mechanism	71
1.4 Removing and installing gearshift knob	73
1.5 Removing and installing selector mechanism	75
1.6 Repairing shift mechanism	81
1.7 Setting the shift mechanism	87
1.8 Inspecting the gearshift mechanism	91



1.9	Replacing the sealing ring for the gearshift shaft	91
2	Removing and installing the gearbox	93
2.1	Tightening torques for gearbox	93
2.2	Removing the gearbox	93
2.3	Installing the gearbox	112
3	Assembly bracket	117
3.1	Assembly overview - assembly mountings	117
4	Transporting the gearbox	118
5	Disassembling and assembling the gearbox	120
5.1	Schematic overview - Gearbox	120
5.2	Summary of components - Gearbox	121
5.3	Summary of components- Gearbox housing cover and 5th gear	121
5.4	Summary of components - Gearshift unit	123
5.5	Summary of components - input shaft, output shafts, differential gear and shift rods	123
5.6	Assembly overview - shift forks	125
5.7	Removing and installing switching unit	126
5.8	Repairing gearshift unit	129
5.9	Disassembling and assembling the gearshift forks	130
5.10	Disassembling and assembling the gearbox	134
6	Gearbox housing, clutch housing	149
6.1	Summary of components - Clutch housing	149
6.2	Summary of components - Gearbox housing and clutch housing	149
6.3	Repairing gearbox housing	151
7	Attachment at engine and gearbox mount	153
8	Gear oil	155
8.1	Checking gear oil level	155
35 - Gears, shafts		157
1	Drive shaft	157
1.1	Summary of components - Drive shaft	157
1.2	Disassembling and assembling the drive shaft	160
1.3	Replacing input shaft sealing ring	175
2	Output shaft	177
2.1	Summary of components - Output shaft	177
2.2	Disassembling and assembling the output shaft	180
39 - Final drive - differential		189
1	Sealing rings	189
1.1	Installation overview - sealing rings	189
1.2	Replacing left sealing ring	189
1.3	Replacing right sealing ring	194
2	Differential	199
2.1	Summary of components - Differential	199
2.2	Disassembling and assembling differential gear	201
2.3	Adjusting the differential	210