



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety measures when working on vehicles with a start/stop system	1
1.3 Safety precautions when using testers and measuring instruments during a road test	2
1.4 Safety precautions when working on the cooling system	2
1.5 Safety precautions when handling refrigerants	2
1.6 Safety precautions when working on vehicles with auxiliary/supplementary heater	3
1.7 Safety precautions when working on the SCR system	4
2 General information	6
2.1 Type plates	6
2.2 Notes concerning odours in air conditioned vehicles	6
3 Repair instructions	8
3.1 Rules for cleanliness	8
3.2 General information	8
3.3 General repair instructions	8
3.4 Contact corrosion	9
3.5 Nuts and bolts	9
3.6 Routing and attachment of lines	9
3.7 Fitting radiators and condensers	9
3.8 Checking cooling output	9
3.9 Working on refrigerant circuit	12
3.10 Refrigerant circuit seals	12
4 Technical data	14
4.1 Refrigerant capacity	14
4.2 Refrigerant oil capacities	14
4.3 Oil distribution	14
80 - Heating	15
1 Heater	15
1.1 Assembly overview – heater unit	15
1.2 Removing and installing fresh air blower V2	16
1.3 Removing and installing fresh air blower series resistor with overheating fuse N24	16
1.4 Removing and installing dust and pollen filter	16
1.5 Removing and installing heat exchanger	16
1.6 Removing and installing heater unit	16
1.7 Dismantling and assembling heater unit	20
2 Control motors	21
2.1 Overview of fitting locations – front control motors, heating system	21
2.2 Removing and installing fresh air and air recirculation flap control motor V154	21
3 Air duct	23
3.1 Removing and installing driver side footwell vents	23
3.2 Checking forced ventilation for passenger compartment	23
3.3 Removing and installing fresh air intake	23
4 Operating and display unit	24
4.1 Removing and installing operating and display unit	24
87 - Air conditioning system	26
1 Overview of fitting locations - air conditioning system	26
1.1 Overview of fitting locations - components not located in passenger compartment	26
1.2 Overview of fitting locations - components located in front section of passenger compartment	27



2	Refrigerant circuit	31
2.1	System overview - refrigerant circuit	31
2.2	Removing and installing high-pressure sender G65	35
2.3	Removing and installing expansion valve	37
2.4	Removing and installing condenser	39
2.5	Removing and installing desiccant bag or cartridge	41
2.6	Removing and installing evacuating and charging valves on low and high-pressure side	43
2.7	Commissioning of air conditioning system after filling refrigerant circuit	45
2.8	When is it necessary to purge the refrigerant circuit with refrigerant	46
3	Air conditioner compressor	48
3.1	Assembly overview - drive unit of air conditioner compressor	48
3.2	Removing and installing air conditioner compressor	49
3.3	Checking high-pressure safety valve on air conditioner compressor	55
4	Control motors	57
4.1	Overview of fitting locations – front control motors	57
4.2	Removing and installing temperature flap control motor V68	60
4.3	Removing and installing defroster flap control motor V107	61
4.4	Removing and installing air recirculation flap control motor V113	62
4.5	Removing and installing left temperature flap control motor V158	63
4.6	Removing and installing right temperature flap control motor V159	64
4.7	Footwell flap control motor V261	66
4.8	Removing and installing fresh air/air recirculation, air flow flap control motor V425	67
4.9	Removing and installing air distribution flap control motor V428	68
5	Front heater and air conditioning unit	70
5.1	Assembly overview - heater and air conditioning unit	70
5.2	Removing and installing evaporator	73
5.3	Removing and installing heater and air conditioning unit	74
5.4	Dismantling and assembling heater and air conditioning unit	78
5.5	Removing and installing dust and pollen filter	79
5.6	Removing and installing fresh air blower V2	79
5.7	Removing and installing fresh air blower control unit J126	80
5.8	Removing and installing heat exchanger	81
5.9	Removing and installing evaporator temperature sensor G308	86
5.10	Removing and installing condensation drain	86
5.11	Checking condensation drain	86
5.12	Removing and installing fresh air blower series resistor with overheating fuse N24	87
6	Air duct	88
6.1	Assembly overview - air duct and air distribution in passenger compartment	88
6.2	Removing and installing driver side footwell vents	89
6.3	Removing and installing rear footwell vent	89
6.4	Removing and installing air ducts	90
6.5	Checking forced ventilation for passenger compartment	90
6.6	Removing and installing fresh air intake	91
7	Operating and display unit	92
7.1	Overview of operating and display unit	92
7.2	Removing and installing operating and display unit	95
8	Other controlling and regulating components	97
8.1	Removing and installing sunlight penetration photosensor G107	97
8.2	Principle of operation of air quality sensor G238	98
8.3	Removing and installing air quality sensor G238	99
8.4	Removing and installing ambient temperature sensor G17	100
8.5	Removing and installing humidity sender for air conditioning system G260	100
8.6	Removing and installing left vent temperature sender G150	101
8.7	Removing and installing right vent temperature sender G151	101



8.8	Removing and installing footwell vent temperature sender G192	101
8.9	Removing and installing left footwell vent temperature sender G261	102
8.10	Removing and installing right footwell vent temperature sender G262	102