



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions during work on fuel system	1
1.2 Safety regulations for working on fuel supply	2
1.3 Safety precautions when working on the cooling system	2
1.4 Safety precautions when using testers and measuring instruments during a road test	3
2 Identification	5
2.1 Engine number/engine data	5
3 Repair instructions	7
3.1 General information	7
3.2 Rules for cleanliness	8
3.3 Instructions for working on fuel system	8
3.4 To avoid any risk of injuries to persons and/or the destruction of the injection and glow plug system, the following must be noted	10
3.5 Notes on hose connections with screw-type clips	10
10 - Removing and installing engine	12
1 Removing and installing engine	12
1.1 Removing engine	12
1.2 Securing engine on engine and gearbox support	25
1.3 Installing engine	27
2 Assembly mountings	30
2.1 Assembly overview - assembly mountings	30
13 - Crankshaft group	32
1 Cylinder block (pulley end)	32
1.1 Assembly overview - cylinder block (pulley end)	32
1.2 Assembly overview - sealing flange, belt pulley end	34
1.3 Assembly overview - poly V-belt drive	35
1.4 Assembly overview - poly V-belt drive, vehicles without A/C system	37
1.5 Assembly overview - cover for poly V-belt	39
1.6 Removing and installing poly-V belt	39
1.7 Removing and installing tensioner for poly V-belt	41
1.8 Removing and installing bracket for ancillaries	42
1.9 Removing and installing vibration damper	43
1.10 Renewing crankshaft oil seal - belt pulley end	44
1.11 Removing and installing sealing flange on pulley end	46
1.12 Removing and installing cover for poly V-belt	50
2 Cylinder block, gearbox end	51
2.1 Assembly overview - cylinder block, gearbox end	51
2.2 Removing and installing flywheel	52
2.3 Removing and installing sealing flange on gearbox side	53
2.4 Removing and installing drive plate	68
3 Crankshaft	70
3.1 Assembly overview - crankshaft	70
3.2 Crankshaft dimensions	71
3.3 Measuring axial clearance of crankshaft	71
3.4 Measuring radial clearance of crankshaft	72
3.5 Renewing needle bearing in crankshaft	72
4 Auxiliary drive	75
4.1 Assembly overview - ancillary drive	75
4.2 Retrofitting preparation for ancillary drive	75



5	Pistons and conrods	78
5.1	Assembly overview - pistons and conrods	78
5.2	Checking pistons and cylinder bores	79
5.3	Piston and cylinder dimensions	81
5.4	Measuring piston projection at TDC	81
5.5	Checking radial clearance of conrods	83
5.6	Bearing shells - installation position	83
5.7	Separating new conrod	84
15	Cylinder head, valve gear	85
1	Cylinder head	85
1.1	Assembly overview - cylinder head	85
1.2	Assembly overview - cylinder head cover	88
1.3	Removing and installing cylinder head	91
1.4	Removing and installing cylinder head cover	99
1.5	Removing and installing injector seals	105
1.6	Removing and installing vacuum pump	106
1.7	Checking compression	107
2	Toothed belt drive	109
2.1	Assembly overview - toothed belt	109
2.2	Removing and installing toothed belt	110
3	Fully enclosing toothed belt guard	120
3.1	Assembly overview - fully enclosing toothed belt guard	120
3.2	Removing and installing front toothed belt guard (fully enclosing)	122
3.3	Removing and installing lower toothed belt guard (fully enclosed)	125
3.4	Removing and installing rear toothed belt guard (fully enclosing)	126
4	Air supply for toothed belt drive	130
4.1	Assembly overview - air supply for toothed belt drive	130
4.2	Removing and installing blower of air supply for toothed belt drive	131
4.3	Removing and installing air filter housing of air supply for toothed belt drive	131
4.4	Removing and installing console of air supply for toothed belt drive	132
5	Valve gear	133
5.1	Assembly overview - valve gear	133
5.2	Measuring axial play of camshaft	135
5.3	Measuring radial play of camshaft	136
5.4	Removing and installing camshaft	137
5.5	Removing and installing camshaft oil seal	144
5.6	Checking hydraulic compensation elements	148
5.7	Removing and installing valve stem seals	149
6	Inlet and exhaust valves	154
6.1	Reworking valve seats	154
6.2	Checking valve guides	154
6.3	Valve dimensions	155
17	Lubrication	156
1	Sump, oil pump	156
1.1	Assembly overview - sump/oil pump	156
1.2	Removing and installing sump	158
1.3	Removing and installing oil pump	164
1.4	Removing and installing oil level and oil temperature sender G266	165
1.5	Removing and installing dipstick tube	166
2	Engine oil cooler	168
2.1	Checking engine oil cooler for leaks	168
3	Oil filter, oil pressure switch	170



3.1	Assembly overview - oil filter	170
3.2	Removing and installing oil filter housing	172
3.3	Removing and installing oil pressure switch F1	174
3.4	Checking oil pressure and oil pressure switch	174
3.5	Measuring oil consumption	176
4	Oil circuit	178
4.1	Removing and installing oil supply line, bi-turbo	178
4.2	Removing and installing oil pressure line for turbocharger, mono-turbo	180
5	Balancer shaft module	183
5.1	Assembly overview - balancer shaft module	183
5.2	Removing balancer shaft module	185
5.3	Installing a new balancer shaft module	187
5.4	Installing a previously used balancer shaft module again	191
19	Cooling	193
1	Cooling system/coolant	193
1.1	Connection diagram - coolant hoses	193
1.2	Assembly overview - coolant hoses	199
1.3	Checking cooling system for leaks	200
1.4	Draining and adding coolant	202
2	Coolant pump, regulation of cooling system	210
2.1	Assembly overview - coolant pump, thermostat	210
2.2	Assembly overview - electric coolant pump	211
2.3	Removing and installing coolant pump	214
2.4	Removing and installing 4/2-way valve with thermostat	216
2.5	Removing and installing coolant temperature sender G62	221
2.6	Removing and installing radiator outlet coolant temperature sender G83	222
2.7	Removing and installing continued coolant circulation pump V51	224
2.8	Removing and installing recirculation pump V55	227
2.9	Removing and installing Y-thermostat	228
3	Radiator, radiator fan	230
3.1	Assembly overview - radiator/radiator fan	230
3.2	Assembly overview - radiator cowl and radiator fan	232
3.3	Removing and installing radiator	232
3.4	Removing and installing radiator cowl with radiator fan	235
21	Turbocharging/supercharging	237
1	Turbocharger	237
1.1	Assembly overview - turbocharger, bi-turbo	237
1.2	Assembly overview - turbocharger, single turbo	241
1.3	Removing and installing turbocharger, bi-turbo	243
1.4	Removing and installing turbocharger, single turbo	249
1.5	Assembly overview - dismantling turbocharger, bi-turbo	253
1.6	Renewing seal between bi-turbo turbine housings	255
1.7	Checking vacuum unit for turbocharger, bi-turbo	259
1.8	Checking regulating flap potentiometer G584	263
1.9	Removing and installing charge pressure sender 2 G447	265
1.10	Removing and installing regulating flap potentiometer G584 and vacuum unit for turbocharger	266
1.11	Removing and installing regulating flap potentiometer G584 and vacuum unit for turbocharger	278
1.12	Removing and installing charge pressure control solenoid valve N75	290
2	Charge air system	292
2.1	Assembly overview - charge air system	292
2.2	Removing and installing charge air cooler	293



2.3	Removing and installing charge air pressure sender G31 / intake air temperature sender G42	294
2.4	Removing and installing exhaust gas flap valve N220	294
2.5	Checking charge air system for leaks	295
23	- Mixture preparation - injection	299
1	Injection system	299
1.1	Schematic overview - fuel system	299
1.2	Overview of fitting locations - injection system	301
1.3	Assembly overview - fuel system	308
1.4	Checking fuel system for leaks	313
1.5	Filling/bleeding fuel system	313
2	Vacuum system	315
2.1	Connection diagram - vacuum system	315
2.2	Checking vacuum system	320
3	Injectors/high-pressure accumulator (rail)	328
3.1	Overview of injectors	328
3.2	Adapting correction values for injectors	328
3.3	Removing and installing injectors	329
3.4	Removing and installing high-pressure lines	338
3.5	Removing and installing fuel rail	340
3.6	Checking return flow rate of injectors with engine running	343
4	Air filter	347
4.1	Assembly overview - air filter housing	347
4.2	Removing and installing air filter housing	349
5	Intake manifold	351
5.1	Assembly overview - intake manifold	351
5.2	Removing and installing intake manifold	352
5.3	Removing and installing throttle valve module GX3	354
6	Senders and sensors	356
6.1	Removing and installing air mass meter G70	356
6.2	Removing and installing exhaust pressure sensor 1 G450	357
6.3	Removing and installing fuel pressure regulating valve N276	359
6.4	Checking fuel pressure regulating valve N276	361
6.5	Removing and installing fuel pressure sender G247	362
7	Engine control unit	365
7.1	Removing and installing engine (motor) control unit J623	365
8	High-pressure pump	366
8.1	Assembly overview - high-pressure pump	366
8.2	Removing and installing high-pressure pump	367
8.3	Checking high-pressure pump	370
26	- Exhaust system	373
1	Exhaust pipes and silencers	373
1.1	Assembly overview - silencers	373
1.2	Checking exhaust system for leaks	374
1.3	Aligning exhaust system free of stress	374
2	Emission control	376
2.1	Assembly overview - emission control, diesel particulate filter	376
2.2	Assembly overview - emission control, catalytic converter	378
2.3	Removing and installing particulate filter	380
2.4	Removing and installing catalytic converter	385
3	Exhaust gas recirculation	388
3.1	Assembly overview - exhaust gas recirculation, version A	388



3.2	Assembly overview - exhaust gas recirculation, version B	389
3.3	Removing and installing exhaust gas recirculation cooler, version A	390
3.4	Removing and installing exhaust gas recirculation cooler, version B	394
3.5	Removing and installing exhaust gas recirculation valve 1 GX5	397
3.6	Removing and installing changeover valve for exhaust gas recirculation cooler N345	397
3.7	Pressure loss test for exhaust gas recirculation cooler	398
28	Glow plug system	401
1	Glow plug system	401
1.1	Assembly overview - glow plug system	401
1.2	Checking glow plug system	402
1.3	Removing and installing glow plug	403
1.4	Removing and installing engine speed sender G28	406
1.5	Removing and installing Hall sender G40	407