



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety precautions when working on high-voltage system	1
1.3 Safety measures when working on vehicles with a start/stop system	2
1.4 Safety precautions when using testers and measuring instruments during a road test	2
1.5 Safety precautions when working on the cooling system	3
1.6 Safety precautions when handling refrigerants	3
1.7 Safety precautions for working on vehicles with auxiliary/supplementary heater	3
1.8 Safety precautions when working on SCR system	4
2 Identification	6
2.1 Identification of heater and air conditioning unit	6
3 General information	8
3.1 Type plates	8
4 Repair notes	9
4.1 Rules for cleanliness	9
4.2 General information	9
4.3 General repair notes	9
4.4 Contact corrosion	10
4.5 Nuts and bolts	10
4.6 Routing and attachment of lines	10
4.7 Fitting radiators and condensers	11
4.8 Checking cooling output	11
4.9 Working on refrigerant circuit	12
4.10 Refrigerant circuit seals	13
5 Technical data	15
5.1 Refrigerant capacity	15
5.2 Refrigerant oil capacities	15
5.3 Oil distribution	16
87 - Air conditioning system	17
1 Overview of fitting locations – air conditioning system	17
1.1 Overview of fitting locations – components not located in passenger compartment	17
1.2 Overview of fitting locations – components located in front section of passenger compartment	21
1.3 Overview of fitting locations – components located in rear section of passenger compartment	23
2 Refrigerant circuit	26
2.1 System overview - refrigerant circuit	26
2.2 Removing and installing refrigerant circuit pressure sender G805	31
2.3 Removing and installing expansion valve	33
2.4 Removing and installing condenser	38
2.5 Removing and installing desiccant bag or cartridge	41
2.6 Removing and installing evacuating and charging valves on low and high-pressure side	42
2.7 Bringing air conditioning system into service after charging	44
2.8 Cleaning refrigerant circuit	45
2.9 Removing and installing refrigerant line from condenser to evaporator	46
2.10 Removing and installing refrigerant line from air conditioner compressor to condenser	52
2.11 Removing and installing refrigerant line from evaporator to air conditioner compressor	54
2.12 Removing and installing refrigerant line to rear heater and air conditioning unit	58
2.13 Removing and installing refrigerant shut-off valve for heater and air conditioner unit N541	66
3 Air conditioner compressor	70



3.1	Assembly overview – air conditioner compressor	70
3.2	Removing and installing air conditioner compressor	75
3.3	Removing air conditioning compressor from and installing on bracket	80
3.4	Checking high-pressure safety valve on air conditioner compressor	85
3.5	Removing and installing air conditioner compressor regulating valve N280	86
4	Control motors	89
4.1	Overview of fitting locations – control motors at front	89
4.2	Removing and installing defroster flap control motor V107	95
4.3	Removing and installing left temperature flap control motor V158	99
4.4	Removing and installing right temperature flap control motor V159	103
4.5	Removing and installing front left chest vent control motor V237	107
4.6	Removing and installing fresh air/air recirculation, air flow flap control motor V425	111
4.7	Removing and installing air distribution flap adjustment unit	115
5	Front heater and air conditioning unit	117
5.1	Assembly overview – heater and air conditioning unit	117
5.2	Assembly overview – evaporator housing	123
5.3	Removing and installing evaporator	124
5.4	Removing and installing heater and air conditioning unit	126
5.5	Removing and installing dust and pollen filter	129
5.6	Removing and installing fresh air blower V2	134
5.7	Checking auxiliary air heater element Z35 with auxiliary air heater control unit J604	137
5.8	Removing and installing auxiliary air heater element Z35 with auxiliary air heater control unit J604	139
5.9	Removing and installing fresh air blower control unit J126	141
5.10	Removing and installing heat exchanger	142
5.11	Removing and installing coolant pipes on heat exchanger	162
5.12	Removing and installing evaporator temperature sensor G308	166
5.13	Checking condensation drain	167
5.14	Removing and installing air distribution housing	167
6	Rear heater and air conditioning unit	169
6.1	Assembly overview – heater and air conditioning unit	169
6.2	Removing and installing evaporator	171
6.3	Removing and installing heater and air conditioning unit	173
6.4	Removing and installing rear fresh air blower V80	177
6.5	Removing and installing fresh air blower control unit J391	177
6.6	Removing and installing heat exchanger	178
6.7	Removing and installing control motors	180
7	Air duct system	182
7.1	Assembly overview – air duct and air distribution in passenger compartment	182
7.2	Removing and installing fresh air intake	184
7.3	Removing and installing air intake duct	184
7.4	Removing and installing driver side footwell vents	185
7.5	Removing and installing front passenger side footwell vents	187
7.6	Removing and installing rear footwell vent	188
7.7	Removing and installing air ducts	189
7.8	Removing and installing front air duct for dash panel	189
7.9	Checking forced ventilation for passenger compartment	191
7.10	Removing and installing forced ventilation for passenger compartment	191
7.11	Removing and installing air duct for defroster vent	193
8	Coolant circuit	194
8.1	Connection diagram – high-voltage heater	194
8.2	Assembly overview – high-voltage heater (PTC)	200
8.3	Removing and installing coolant valve for high-voltage battery N688	201
8.4	Removing and installing coolant valve for high-voltage battery V590	203
8.5	Removing and installing high-voltage heater (PTC) Z115/high-voltage heater (PTC) J848	204



9	Operating and display unit	208
9.1	Overview of fitting locations – operating and display unit	208
9.2	Overview of operating and display unit	208
9.3	Removing and installing operating and display unit, front	209
9.4	Removing and installing rear operating and display unit E265	209
10	Other controlling and regulating components	211
10.1	Working principles of air quality sensor G238	211
10.2	Removing and installing air quality sensor G238	212
10.3	Removing and installing ambient temperature sensor [G17]	213
10.4	Removing and installing humidity sender for air conditioning system G260	214
10.5	Removing and installing left vent temperature sender G150	214
10.6	Removing and installing right vent temperature sender G151	215
10.7	Removing and installing footwell vent temperature sender G192	216
10.8	Removing and installing vehicle interior temperature sensor G1090	217
10.9	Removing and installing heater and air conditioning system control unit J979	218