



Contents

00 - Technical data	1
1 General information	1
1.1 Notes concerning odours in air conditioned vehicles	1
1.2 Notes for vehicles with a start/stop system	1
1.3 Procedure when checking and adjusting components	2
1.4 Distribution of oil in refrigerant circuit	2
2 Safety information	3
2.1 Safety precautions when working on air conditioning systems	3
2.2 Safety measures when working on vehicles with a start/stop system	3
3 Repair instructions	4
3.1 Checking cooling output	4
4 Technical data	5
4.1 Refrigerant capacity	5
4.2 Refrigerant oil capacities	5
4.3 Oil distribution	5
80 - Heating	7
1 Heater	7
1.1 Overview of fitting locations - heater unit	7
1.2 Overview of fitting locations - heater unit for second heat exchanger	9
1.3 Coolant hose schematic diagram for vehicles equipped with second heat exchanger	10
1.4 Operating and display unit for heater and fresh air system for second heat exchanger	10
1.5 Removing and installing heater for second heat exchanger	11
1.6 Dismantling and assembling heater for second heat exchanger	12
1.7 Removing and installing second heat exchanger	12
1.8 Removing and installing rear fresh air blower control unit J391 for second heat exchanger	14
1.9 Removing and installing potentiometer for rear temperature flap motor G479 for second heat exchanger	14
1.10 Removing and installing fresh air blower V2	15
1.11 Removing and installing fresh air blower series resistor with overheating fuse N24	15
1.12 Removing and installing dust and pollen filter	16
1.13 Dust and pollen filter with activated charcoal filter insert	16
1.14 Removing and installing heater unit	17
1.15 Dismantling and assembling heater unit	19
1.16 Removing and installing heat exchanger	19
1.17 Removing and installing auxiliary air heater element Z35	20
2 Control motors/actuators	21
2.1 Removing and installing temperature flap actuator	21
2.2 Removing and installing fresh air/air recirculation flap control motor V154	21
3 Air duct	23
3.1 Overview of fitting locations of air ducting and vents	23
3.2 Removing and installing driver side footwell vents	24
3.3 Removing and installing front passenger side footwell vents	25
3.4 Removing and installing rear footwell vent	26
3.5 Checking forced ventilation	28
3.6 Removing and installing air duct for defroster vent	28
3.7 Removing and installing air duct for centre dash panel vent	29
3.8 Removing and installing air duct for dash panel vent on driver side/front passenger side	31
3.9 Removing and installing air duct for side window vents	31
3.10 Removing and installing vent for second heat exchanger	32
4 Operating and display unit	33



4.1	Removing and installing operating and display unit for heater and fresh air system	33
4.2	Pin assignment for multi-pin connectors on back of operating and display unit for heater and fresh air system	34
87 - Air conditioning system	35
1	Overview of fitting locations - air conditioning system	35
1.1	Overview of fitting locations - components not located in passenger compartment	35
1.2	Overview of fitting locations - components located in front section of passenger compartment	37
2	Refrigerant circuit	39
2.1	System overview - refrigerant circuit	39
2.2	Assembly overview - expansion valve	40
2.3	Removing and installing high-pressure sender G65	41
2.4	Removing and installing expansion valve	42
2.5	Removing and installing condenser	45
2.6	Removing and installing desiccant bag or cartridge	47
2.7	Removing and installing evacuating and charging valves on low and high-pressure side	48
2.8	Commissioning of air conditioning system after filling refrigerant circuit	49
2.9	When is it necessary to purge the refrigerant circuit with refrigerant	50
3	Air conditioner compressor	52
3.1	Assembly overview - drive unit of air conditioner compressor	52
3.2	Assembly overview - pulley	53
3.3	Removing and installing air conditioner compressor	53
3.4	Notes on installing air conditioner compressor	56
3.5	Checking high-pressure safety valve on air conditioner compressor	58
3.6	Removing and installing pulley	58
4	Control motors	59
4.1	Removing and installing temperature flap control motor V68	59
4.2	Removing and installing centre flap control motor V70	59
4.3	Removing and installing air recirculation flap control motor V113	60
5	Front heater and air conditioning unit	61
5.1	Assembly overview - heater and air conditioning unit	61
5.2	Removing and installing evaporator	62
5.3	Removing and installing heater and air conditioning unit	63
5.4	Dismantling and assembling heater and air conditioning unit	65
5.5	Checking condensation drain	66
6	Air duct	68
6.1	Removing and installing evaporator temperature sensor G308	68
7	Operating and display unit	69
7.1	Overview of operating and display unit with air conditioning system control unit J301	69
7.2	Removing and installing air conditioning system control unit J301	69
7.3	Pin assignment of multi-pin connectors on back of air conditioning system control unit J301	71
8	Other controlling and regulating components	73
8.1	Removing and installing radiator fan housing	73
8.2	Removing and installing radiator fan V7	74
8.3	Removing and installing radiator fan relay J26	74
8.4	Fresh air blower control unit J126	74
8.5	Removing and installing radiator fan control unit J293	75
9	Roof air conditioning system	76
9.1	Assembly overview - roof air conditioning system	76
9.2	Assembly overview - trim panels and roof air ducts	77
9.3	Roof air conditioning system - way in which air is exchanged	79
9.4	Removing and installing air conditioning system control unit J301	79



9.5	Operation and function of air conditioning system control unit J301 with second evaporator and second heat exchanger	80
9.6	Pin assignment on back of air conditioning system control unit J301	81
9.7	Removing and installing fleece filter element	82
9.8	Removing and installing front vent trim	82
9.9	Removing and installing trim panel for heat exchanger housing	84
9.10	Removing and installing centre vent trim	87
9.11	Removing and installing rear vent trim	89
9.12	Removing and installing front roof air duct	91
9.13	Removing and installing rear roof air duct	93
9.14	Removing and installing upper cover	94
9.15	Removing and installing insulation and upper air duct	96
9.16	Removing and installing rear evaporator blower V20	96
9.17	Removing and installing evaporator blower control unit J349	98
9.18	Removing and installing rear temperature flap control motor V137	99
9.19	Removing and installing rear evaporator temperature sender G153	100
9.20	Removing and installing rear vent temperature sender G174 with temperature sensor blower V42	101
10	Refrigerant circuit of roof air conditioning system	103
10.1	Assembly overview - roof air conditioning system fitting locations	103
10.2	Connection diagram of refrigerant circuit on vehicles with second evaporator	105
10.3	Assembly overview - condensation drainage	106
10.4	Removing and installing expansion valve with refrigerant circulation solenoid valve N43	106
10.5	Removing and installing heat exchanger housing (complete)	111