



## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Safety information</b>	<b>1</b>
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety measures when working on vehicles with a start/stop system	2
1.3 Safety precautions when using testers and measuring instruments during a road test	2
1.4 Safety precautions when working on the cooling system	2
1.5 Safety precautions when handling refrigerants	2
1.6 Safety precautions when working on vehicles with auxiliary/supplementary heater	3
1.7 Safety precautions when working on SCR system	4
<b>2 General information</b>	<b>6</b>
2.1 Type plates	6
2.2 Notes concerning odours in air conditioned vehicles	7
<b>3 Repair instructions</b>	<b>8</b>
3.1 Rules for cleanliness	8
3.2 General information	8
3.3 General repair instructions	8
3.4 Contact corrosion	9
3.5 Nuts and bolts	9
3.6 Routing and attachment of lines	9
3.7 Fitting radiator and condensers	9
3.8 Checking cooling output	9
3.9 Working on refrigerant circuit	11
3.10 Refrigerant circuit seals	12
<b>4 Technical data</b>	<b>13</b>
4.1 Refrigerant capacity	13
4.2 Refrigerant oil capacities	13
4.3 Oil distribution	15
<b>80 - Heating</b>	<b>16</b>
<b>1 Heater</b>	<b>16</b>
1.1 Assembly overview – heater unit	16
1.2 Assembly overview - second heater unit	18
1.3 Removing and installing rear warm air blower V47	19
1.4 Removing and installing warm air blower control unit J350	22
1.5 Removing and installing heat exchanger for second heater unit	23
1.6 Removing and installing second heater unit	24
1.7 Dismantling and assembling second heater unit	26
<b>2 Control motors</b>	<b>30</b>
2.1 Overview of fitting locations - front control motors	30
2.2 Removing and installing rear temperature flap control motor V137	31
<b>3 Air duct</b>	<b>33</b>
3.1 Removing and installing air ducts	33
<b>4 Operating and display unit</b>	<b>35</b>
4.1 Overview of operating and display unit	35
<b>5 Other controlling and regulating components</b>	<b>36</b>
5.1 Removing and installing rear vent temperature sender G174	36
<b>87 - Air conditioning system</b>	<b>37</b>
<b>1 Overview of fitting locations - air conditioning system</b>	<b>37</b>
1.1 Overview of fitting locations - components not located in passenger compartment	37
1.2 Overview of fitting locations - components located in front section of passenger compartment	42



1.3	Overview of fitting locations - components located in rear section of passenger compartment .....	44
<b>2</b>	<b>Refrigerant circuit</b> .....	<b>45</b>
2.1	System overview - refrigerant circuit .....	45
2.2	Assembly overview - refrigerant lines .....	50
2.3	Assembly overview - condenser .....	54
2.4	Removing and installing refrigerant circuit pressure sender G805 .....	54
2.5	Removing and installing expansion valve .....	57
2.6	Removing and installing condenser .....	62
2.7	Separating and connecting refrigerant lines on condenser .....	65
2.8	Removing and installing desiccant bag or cartridge .....	68
2.9	Removing and installing evacuating and charging valves on low and high-pressure side .....	73
2.10	Commissioning of air conditioning system after filling refrigerant circuit .....	75
2.11	Removing and installing refrigerant line from air conditioner compressor to condenser ..	75
2.12	Removing and installing refrigerant line from air conditioner compressor to evaporator ..	79
2.13	Removing and installing refrigerant line from evaporator to air conditioner compressor ..	83
2.14	Removing and installing refrigerant lines to heater and air conditioning unit .....	90
2.15	When is it necessary to purge the refrigerant circuit with refrigerant .....	98
<b>3</b>	<b>Air conditioner compressor</b> .....	<b>100</b>
3.1	Assembly overview - drive unit of air conditioner compressor .....	100
3.2	Removing air conditioning compressor from and installing on bracket .....	101
3.3	Removing and installing air conditioner compressor .....	104
3.4	Removing and installing 2nd air conditioner compressor .....	108
3.5	Checking high-pressure safety valve on air conditioner compressor .....	109
3.6	Removing and installing air conditioner compressor regulating valve N280 .....	110
<b>4</b>	<b>Control motors</b> .....	<b>113</b>
4.1	Overview of fitting locations - front control motors .....	113
4.2	Assembly overview - front control motors .....	117
4.3	Removing and installing temperature flap control motor V68 .....	119
4.4	Removing and installing defroster flap control motor V107 .....	121
4.5	Removing and installing air recirculation flap control motor V113 .....	122
4.6	Removing and installing left temperature flap control motor V158 .....	124
4.7	Removing and installing right temperature flap control motor V159 .....	125
4.8	Removing and installing fresh air/air recirculation, air flow flap control motor V425 .....	126
4.9	Removing and installing front air distribution flap control motor V426 .....	128
4.10	Removing and installing air distribution flap control motor V428 .....	129
<b>5</b>	<b>Front heater and air conditioning unit</b> .....	<b>131</b>
5.1	Assembly overview - heater and air conditioning unit .....	131
5.2	Assembly overview - evaporator housing .....	133
5.3	Removing and installing evaporator .....	134
5.4	Checking auxiliary air heater element Z35 .....	134
5.5	Removing and installing auxiliary air heater element Z35 .....	135
5.6	Removing and installing heater and air conditioning unit .....	136
5.7	Removing and installing holder for heater and air conditioning unit .....	141
5.8	Dismantling and assembling heater and air conditioning unit .....	142
5.9	Removing and installing air distribution housing .....	143
5.10	Removing and installing dust and pollen filter .....	144
5.11	Removing and installing fresh air blower V2 .....	146
5.12	Removing and installing fresh air blower control unit J126 .....	146
5.13	Removing and installing heat exchanger .....	147
5.14	Removing and installing coolant pipes on heat exchanger .....	148
5.15	Removing and installing evaporator temperature sensor G308 .....	151
5.16	Removing and installing condensation drain .....	153
5.17	Checking condensation drain .....	154



<b>6</b>	<b>Rear heater and air conditioning unit</b>	155
6.1	Assembly overview - heater and air conditioning unit	155
6.2	Removing and installing evaporator	157
6.3	Dismantling and assembling evaporator housing	158
6.4	Removing and installing heater and air conditioning unit	161
6.5	Removing and installing supplementary blower for air conditioning V625 / supplementary blower 2 for air conditioning V626	164
6.6	Removing and installing control unit for supplementary blower for air conditioning J1144 / control unit for supplementary blower 2 for air conditioning J1145	167
6.7	Removing and installing rear evaporator temperature sensor G464	168
6.8	Removing and installing condensation drain hose	169
6.9	Checking condensation drain hose	172
<b>7</b>	<b>Air duct</b>	173
7.1	Overview of fitting locations - air ducts and air distribution in passenger compartment	173
7.2	Removing and installing driver side footwell vents	176
7.3	Removing and installing front passenger side footwell vents	177
7.4	Removing and installing air ducts	178
7.5	Removing and installing forced ventilation for passenger compartment	182
7.6	Checking forced ventilation for passenger compartment	184
7.7	Removing and installing fresh air intake	184
7.8	Removing and installing cover for fresh air intake	188
7.9	Removing and installing air intake duct	189
7.10	Removing and installing air duct for defroster vent	189
7.11	Removing and installing intermediate piece	190
7.12	Removing and installing cold air hose of glove compartment	190
7.13	Removing and installing connection for cold air hose of glove compartment	190
7.14	Removing and installing valve for cold air hose of glove compartment	191
7.15	Removing and installing air intake duct	192
<b>8</b>	<b>Operating and display unit</b>	193
8.1	Overview of operating and display unit	193
8.2	Removing and installing operating and display unit	196
<b>9</b>	<b>Other controlling and regulating components</b>	199
9.1	Removing and installing sunlight penetration photosensor G107	199
9.2	Principle of operation of air quality sensor G238	200
9.3	Removing and installing air quality sensor G238	201
9.4	Removing and installing ambient temperature sensor G17	202
9.5	Removing and installing humidity sender for air conditioning system G260	202
9.6	Removing and installing footwell vent temperature sender G192	202
9.7	Removing and installing chest vent temperature sensors at front G385 / G386	203