



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety measures when working on vehicles with a start/stop system	1
1.3 Safety precautions when working on the cooling system	1
2 General information	3
2.1 Notes concerning odours in air conditioned vehicles	3
2.2 Notes for vehicles with start-stop system	3
3 Repair instructions	4
3.1 Working on refrigerant circuit	4
3.2 Refrigerant circuit seals	4
3.3 Notes on control motors	5
4 Technical data	11
4.1 Capacities for refrigerant R134a	11
4.2 Refrigerant oil	11
4.3 Oil distribution	11
80 - Heating	12
1 Heater	12
1.1 Removing and installing fresh air blower V2	12
1.2 Removing and installing fresh air blower series resistor with overheating fuse N24	13
1.3 Removing and installing heater unit	13
1.4 Dismantling and assembling heater unit	17
2 Control motors	20
3 Air duct	21
4 Operating and display unit	22
5 Other controlling and regulating components	23
87 - Air conditioning system	24
1 Overview of fitting locations - air conditioning system	24
1.1 Overview of fitting locations - components located in front section of passenger compartment	24
2 Refrigerant circuit	30
2.1 System overview - refrigerant circuit	30
2.2 Removing and installing high-pressure sender G65	31
2.3 Removing and installing expansion valve	32
2.4 Removing and installing condenser	35
2.5 Removing and installing receiver	38
2.6 Removing and installing desiccant bag or cartridge	39
2.7 Removing and installing evacuating and charging valves on low and high-pressure side	41
3 Air conditioner compressor	43
3.1 Assembly overview - drive unit of air conditioner compressor	43
3.2 Removing and installing air conditioner compressor	43
3.3 Checking high-pressure safety valve on air conditioner compressor	48
3.4 Ancillary bracket for air conditioner compressor	49
4 Front heater and air conditioning unit	61
4.1 Assembly overview - heater and air conditioning unit	61
4.2 Removing and installing heater and air conditioning unit	66
4.3 Removing and installing evaporator	71
4.4 Dismantling and assembling evaporator housing	72
4.5 Removing fresh air blower V2 with fresh air blower control unit J126	73



4.6	Removing and installing evaporator output temperature sender G263	74
4.7	Removing and installing evaporator temperature sensor G308	75
4.8	Removing and installing dust and pollen filter	75
4.9	Removing and installing heat exchanger	76
4.10	Removing and installing auxiliary air heater element Z35	80
4.11	Checking condensation drain	83
4.12	Removing and installing glove box cooling	83
5	Air duct	85
5.1	Removing and installing fresh air intake	85
5.2	Removing and installing air intake duct	86
5.3	Removing vents	87
5.4	Checking forced ventilation for passenger compartment	89
5.5	Removing and installing forced ventilation for passenger compartment	89
6	Operating and display unit	91
6.1	Overview of operating and display unit	91
6.2	Removing and installing operating and display unit	102
6.3	Multi-pin connector pin assignment on back of operating and display unit	103
7	Control motors	110
7.1	Removing and installing temperature flap control motor V68	110
7.2	Removing and installing centre flap control motor V70	112
7.3	Removing and installing air flow flap control motor V71	113
7.4	Removing and installing defroster flap control motor V107	117
7.5	Removing and installing air recirculation flap control motor V113	119
7.6	Removing and installing fresh air and air recirculation flap control motor V154	121
7.7	Removing and installing left temperature flap control motor V158	124
7.8	Removing and installing right temperature flap control motor V159	126
7.9	Removing and installing fresh air/air recirculation, air flow flap control motor V425	128
7.10	Removing and installing front air distribution flap control motor V426	130
7.11	Removing and installing air distribution flap control motor V428	131
7.12	Removing and installing air distribution flap actuator	132
7.13	Removing and installing flexible shaft, vehicles up to week 21/08	133
8	Other controlling and regulating components	135
8.1	Removing and installing ambient temperature sensor G17	135
8.2	Removing sunlight penetration photosensor G107 or sunlight penetration photosensor 2 G134	135
8.3	Principle of operation of air quality sensor G238	136
8.4	Removing and installing air quality sensor G238, vehicles from week 22/08	137
8.5	Removing and installing left vent temperature sender G150	138
8.6	Removing and installing right vent temperature sender G151	139
8.7	Removing and installing centre vent temperature sender G191	139
8.8	Removing and installing footwell vent temperature sender G192	139
8.9	Removing and installing left footwell vent temperature sender G261	140
8.10	Removing and installing right footwell vent temperature sender G262	140