



Contents

00 - Technical data	1
1 — Change history —	1
2 Safety instructions	2
2.1 Safety measures regarding work on the fuel supply	2
2.2 Safety measures in test drives using testing and measurement devices	3
2.3 Safety measures when working on the cooling system	4
2.4 Safety measures when working on the ignition system	4
3 Identification	6
3.1 Engine number/engine characteristics	6
4 Repair instructions	8
4.1 Cleaning rules	8
4.2 Foreign bodies on the engine	8
4.3 Contact corrosion	8
4.4 Connection installation and fastening	8
4.5 Radiator and capacitor installation	9
10 - Removing and installing engine	10
1 Engine - remove and install	10
1.1 Engine - removal	10
1.2 Engine - separate gearbox	19
1.3 Secure the engine to the engine and gearbox swivelling stand	21
1.4 Engine - installation	22
2 Power-drive unit supports	25
2.1 Power unit brackets - assembly overview	25
2.2 Power-drive unit supports (engine side) - remove and install	27
2.3 Power-drive unit supports (gearbox side) - remove and install	29
2.4 Pendulum support (torque limiter) - remove and install	32
2.5 Additional notes and installation works in vehicles with air conditioning	33
13 - Crankshaft group	34
1 Cylinder block (pulley side)	34
1.1 Poly-V belt - assembly overview	34
1.2 Poly-V belt - remove and install	36
1.3 Poly-V belt tensioner - remove and install	39
1.4 Crankshaft pulley (vibration damper) - remove and install	40
1.5 Engine console - remove and install	41
1.6 Crankshaft seal (pulley side) - replace	43
2 Cylinder block (gearbox side)	47
2.1 Cylinder block (gearbox side) - assembly overview	47
2.2 Flywheel - remove and install	48
2.3 Crankshaft flange (flywheel side) - replace	49
3 Crankshaft	62
3.1 Crankshaft dimensions	62
3.2 Crankshaft - check axial clearance	62
4 Pistons and conrods	64
4.1 Pistons and conrods - assembly overview	64
4.2 Pistons - remove and install	68
4.3 Pistons, rings, and cylinders - check (conrod with bushing)	69
4.4 Pistons, rings, and cylinders - check (conrod without bushing)	71
4.5 Connecting rod (radial clearance) - check	74
4.6 Oil injectors - remove and install	74



15 - Cylinder head, valve gear	76
1 Engine cylinder head	76
1.1 Engine cylinder head - assembly overview	76
1.2 Cylinder head cover with camshafts - assembly overview	78
1.3 Engine cylinder head - remove and install	81
1.4 Cylinder head cover with camshafts - remove and install	88
1.5 Compression - check	91
2 Toothed belt drive	95
2.1 Upper and lower cover of the mechanical distributor and console - assembly overview	95
2.2 Toothed belt - assembly overview	96
2.3 Mechanical distribution cover - removal and installation	98
2.4 Valve timing - check	99
2.5 Remove the toothed belt from the camshafts	106
2.6 Toothed belt - remove and install	116
3 Camshaft mechanism - repair	124
3.1 Camshaft mechanism - assembly overview	124
3.2 Crankshaft - check axial clearance	126
3.3 Inlet camshaft regulator - remove and install	127
3.4 Exhaust camshaft sprocket - remove and install	133
3.5 Camshaft seal - replace	138
3.6 Camshaft adjustment valve 1 N205 - remove and install	145
3.7 Valve stem sealant - replace	145
4 Inlet and exhaust valves	156
4.1 Valve guides - check	156
4.2 Valves - check	157
4.3 Valves - dimensions	157
17 - Lubrication	158
1 Crankcase/oil pump	158
1.1 Crankcase/oil pump - assembly overview	158
1.2 Lower sump - remove and install	161
1.3 Upper crankcase - remove and install	164
1.4 Oil pump - remove and install	168
1.5 Engine oil	171
2 Engine oil cooler	172
2.1 Engine oil cooler - assembly overview	172
2.2 Engine oil cooler - remove and install	172
3 Engine crankcase ventilation	174
3.1 Engine crankcase ventilation - assembly overview	174
3.2 Crankcase ventilation device - remove and install	175
4 Oil filter/Oil pressure switch F1	178
4.1 Oil filter/Oil pressure switch F1 - assembly overview	178
4.2 Oil pressure switch 0.3...0.6 bar F1 - remove and install	178
4.3 Oil filter - remove and install	180
4.4 Oil pressure and Oil pressure switch F1 - check	181
19 - Cooling	184
1 Cooling system components	184
1.1 Cooling system - assembly overview	184
1.2 Hose connection diagram for cooling system	186
1.3 Cooling system - drainage and replenishment	187
1.4 Cooling system - check air-tightness	196
1.5 Coolant tank flap - check safety valve	198
2 Coolant/cooling system water pump	200



2.1	Water pump - assembly overview	200
2.2	Water pump - remove and install	203
2.3	Water pump sprocket - remove and install	209
2.4	Thermostat valve - remove and install	210
2.5	Water pump toothed belt - remove and install	218
2.6	Coolant temperature sensor G62 - remove and install	221
3	Radiator	224
3.1	Radiator - remove and install	224
3.2	Cowling with Radiator fan V7 - remove and install	227
3.3	Radiator fan V7 - remove and install	227
20	Fuel supply system	228
1	Fuel supply system components	228
1.1	Fuel tank - assembly overview	228
1.2	Safety measures regarding work on the fuel supply	232
1.3	Cleaning rules	232
1.4	Cold start system components - remove and install	233
1.5	Fuel pump (pre-supply pump) G6 - remove and install	234
1.6	Fuel gauge sensor G - remove and install	238
1.7	Fuel tank - remove and install	238
1.8	Fuel shutoff in case of crash	240
1.9	Fuel pump (pre-supply pump) G6 - check	241
2	Engine power electronic adjustment (electronic accelerator)	254
2.1	Engine power electronic adjustment (electronic accelerator) - assembly overview	254
2.2	Electronic accelerator system operation	254
3	Activated charcoal filter system	256
3.1	Operation	256
3.2	Activated charcoal filter system components - repair	256
3.3	Fuel tank ventilation - check	258
24	Mixture preparation - injection	260
1	Injection system	260
1.1	Sensors, switches (intake side) - assembly overview	260
1.2	Sensor, ignition coils and lambda probe (exhaust side) - assembly overview	261
1.3	Injection system - assembly overview	262
2	Injection valves	267
2.1	Fuel rail with injection valves - assembly overview	267
2.2	Injection valves - remove and install	270
2.3	Injection valves - check	274
3	Air cleaner	279
3.1	Air filter - assembly overview	279
3.2	Air filter - remove and install	280
4	Intake manifold	281
4.1	Intake manifold - assembly overview	281
4.2	Intake manifold - remove and install	282
4.3	Throttle butterfly valve control unit J338 - remove and install	286
4.4	Throttle valve control unit J338 - clean	287
4.5	Supply system pressure, fuel pressure gauge and residual pressure - check	288
5	READINESS code	296
5.1	Function	296
5.2	Creating and Interpreting the READINESS code	296
6	Transmitters and sensors	297
6.1	Intake manifold pressure sensor G71 with Air intake temperature sensor G42 - remove and install	297



7	Engine control unit J623	299
7.1	Engine control unit J623 - remove and install	299
8	Lambda probe	303
8.1	Lambda probe - assembly overview	303
8.2	Lambda probe - remove and install	304
26 - Exhaust system		308
1	Exhaust pipes/silencers	308
1.1	Exhaust pipes/silencers - exploded view	308
1.2	Separate exhaust pipes/silencers	309
1.3	Silencers - remove and install	310
1.4	Exhaust system - free of stress alignment	311
1.5	Exhaust system - check air-tightness	311
1.6	Pipe clamp installation position	312
2	Exhaust gas purging	313
2.1	Front exhaust pipe with catalytic converters - assembly overview	313
2.2	Front exhaust pipe with catalytic converters - remove and install	315
28 - Ignition system		318
1	Ignition system	318
1.1	Ignition system - assembly overview	318
1.2	Ignition coils with final power stage - assembly overview	320
1.3	Test data, spark plugs	321
1.4	Ignition coil with final power stage - remove and install	321
1.5	Knock sensor 1 G61 - remove and install	324
1.6	Hall Sensor G40 - remove and install	326
1.7	Engine speed sensor G28 - remove and install	327
1.8	Glow plug relay J52 and Glow plug activation control unit J370 - remove and install	328