



## Contents

<b>80 - Heating</b> .....	<b>1</b>
<b>1 Repairing heating system</b> .....	<b>1</b>
1.1 Heating, passenger compartment (Jetta 2011►) .....	1
1.2 Removing fresh air blower V2 .....	2
1.3 Removing and installing fresh air blower series resistor with overheating fuse N24 .....	3
1.4 Removing and installing dust and pollen filter .....	4
1.5 Removing vent (Jetta 2011►) .....	5
1.6 Removing and installing controls for heated and fresh air .....	10
1.7 Connectors on controls for heated and fresh air .....	11
1.8 Removing and installing flexible shaft for air distribution .....	12
1.9 Removing and installing Bowden cable for temperature flap .....	13
1.10 Removing and installing fresh air and air recirculation flap control motor V154 .....	14
1.11 A .....	14
1.12 Removing and installing heat exchanger .....	14
1.13 Removing and installing auxiliary air heater element Z35 , vehicles ► 1K-7M 119 726 .....	18
1.14 Checking, removing and installing auxiliary air heater element Z35 , vehicles 1K-7M 119 727 ► .....	19
1.15 Checking ventilation .....	21
1.16 Removing and installing air intake grille .....	21
1.17 Removing and installing heater unit .....	22
<b>2 Dismantling and assembling heater unit</b> .....	<b>26</b>
2.1 Dismantling and assembling heater unit .....	26
2.2 Removing and installing air distribution housing .....	27
2.3 Dismantling and assembling heater unit .....	28
2.4 Removing and installing air distribution flap actuator .....	29
2.5 Removing and installing temperature flap actuator .....	29
2.6 Removing and installing air distribution housing lever .....	30
<b>87 - Air conditioning system</b> .....	<b>32</b>
<b>1 Notes on repair work to vehicles with air conditioning and on handling refrigerant</b> .....	<b>32</b>
<b>2 Notes for vehicles with a start/stop system</b> .....	<b>33</b>
<b>3 Overview of fitting locations - air conditioning system</b> .....	<b>34</b>
3.1 Overview of fitting locations - components not located in passenger compartment .....	34
<b>4 Air conditioning system with manual controls</b> .....	<b>36</b>
4.1 Air conditioning and heating - passenger compartment .....	36
4.2 Removing and installing heater and air conditioner unit (manually operated air conditioning system) .....	37
4.3 Dismantling and assembling heater and air conditioning unit (manually operated air conditioning system) .....	42
4.4 Removing and installing heating and air conditioning system controls (manually operated air conditioning system) .....	43
4.5 Connectors on controls for heating and air conditioning system (manually operated air conditioning system) .....	44
4.6 Removing and installing flexible shaft .....	45
4.7 Checking condensation drain hose on heater and air conditioner unit .....	46
4.8 Removing and installing air recirculation flap control motor V113 .....	46
4.9 Removing and installing temperature flap control motor V68 .....	46
4.10 Removing and installing footwell vent temperature sender G192 .....	48
4.11 Removing and installing centre vent temperature sender G191 .....	49
<b>5 Climatronic air conditioning with automatic regulation</b> .....	<b>50</b>
5.1 Procedure when checking and adjusting components .....	50
5.2 Function of operating and display unit for Climatronic air conditioning system E87 .....	51



5.3	Removing and installing operating and display unit for Climatronic air conditioning system E87 with Climatronic control unit J255	52
5.4	Connectors on Climatronic control unit J255	53
5.5	Climatronic - passenger compartment	54
5.6	Removing and installing fresh air blower control unit J126	57
5.7	Removing and installing heater and air conditioning unit (Climatronic)	57
5.8	Dismantling and assembling heater and air conditioning unit	62
5.9	Dismantling and assembling evaporator housing	63
5.10	Removing and installing left footwell vent temperature sender G261	64
5.11	Removing and installing right footwell vent temperature sender G262	65
5.12	Removing and installing evaporator temperature sensor G308	65
5.13	Removing left vent temperature sender G150 and right vent temperature sender G151	66
5.14	Removing sunlight penetration photosensor G107 or sunlight penetration photosensor 2 G134	66
5.15	Checking condensation drain hose on heater and air conditioner unit	67
5.16	Renewing control motors for air conditioning regulation	67
5.17	Removing and installing fresh air and air recirculation flap control motor V154	68
5.18	Removing and installing air flow flap control motor V71 or fresh air/air recirculation, air flow flap control motor V425	68
5.19	Removing and installing defroster flap control motor V107	69
5.20	Removing and installing left temperature flap control motor V158	70
5.21	Removing and installing right temperature flap control motor V159	71
5.22	Removing and installing centre flap control motor V70	72
<b>6</b>	<b>Ancillary bracket for air conditioner compressor</b>	<b>73</b>
6.1	Removing and installing ancillary bracket for air conditioner compressor (Jetta 2011►)	73
6.2	Removing and installing ancillary bracket for air conditioner compressor, engine codes BRM, BXE	73
6.3	Removing and installing ancillary bracket for air conditioner compressor, engine codes BGP and BGQ	75
6.4	Removing and installing ancillary bracket for air conditioner compressor, engine codes BPY, BWA, BSE, BSF, BLR, BLY	77
<b>7</b>	<b>Repair work on refrigerant circuit which may be performed only in appropriate workshops by specially trained mechanics</b>	<b>80</b>
7.1	Testing equipment and tools	80
7.2	Renewing refrigerant circuit components	82
7.3	Removing high-pressure sender G65	83
7.4	Removing and installing receiver with desiccant cartridge from Showa (FUJIKOKI)	84
7.5	Removing and installing receiver with dryer (Modine dryer and strainer)	85
7.6	Air conditioner compressor	87
7.7	Compressor run-in	91
7.8	Notes on installing air conditioner compressor	91
7.9	Checking high-pressure safety valve on air conditioner compressor	92
7.10	Expansion valve, function and removing	93
7.11	Removing and installing evaporator	95
7.12	A	96
7.13	Removing and installing condenser (Jetta 2011►)	96
7.14	Notes on installing air conditioner compressor	98
<b>8</b>	<b>Capacities</b>	<b>100</b>
8.1	Refrigerant R134a	100
8.2	Refrigerant oil	100