



## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Safety information</b>	<b>1</b>
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety measures when working on vehicles with a start/stop system	1
1.3 Safety precautions when using testers and measuring instruments during a road test	2
1.4 Safety precautions when working on the cooling system	2
1.5 Safety precautions when handling refrigerants	2
1.6 Safety precautions for working on vehicles with auxiliary/supplementary heater	3
<b>2 General information</b>	<b>5</b>
2.1 Type plates	5
2.2 Notes concerning odours in air conditioned vehicles	6
2.3 Notes for vehicles with start-stop system	7
2.4 Notes on dust and pollen filter	8
<b>3 Repair instructions</b>	<b>9</b>
3.1 Rules for cleanliness	9
3.2 Nuts and bolts	9
3.3 Routing and attachment of lines	10
3.4 Fitting radiators and condensers	10
3.5 Checking heater output	10
3.6 Checking cooling output	13
3.7 Working on refrigerant circuit	15
3.8 Paint work on vehicles with air conditioning system	16
3.9 Refrigerant circuit seals	16
3.10 General repair instructions	16
<b>4 Technical data</b>	<b>18</b>
4.1 Refrigerant capacity	18
4.2 Refrigerant oil capacities	18
4.3 Oil distribution	18
<b>80 - Heating</b>	<b>20</b>
<b>1 Overview of fitting locations - heating</b>	<b>20</b>
1.1 Overview of fitting locations - components not located in passenger compartment	20
1.2 Overview of fitting locations - components located in front section of passenger compartment	21
<b>2 Heater</b>	<b>22</b>
2.1 Assembly overview – heater unit	22
<b>3 Control motors</b>	<b>28</b>
3.1 Overview of fitting locations – control motors at front	28
3.2 Removing and installing fresh air and air recirculation flap control motor V154	28
<b>4 Air duct</b>	<b>30</b>
<b>5 Operating and display unit</b>	<b>31</b>
5.1 Overview of operating and display unit	31
<b>6 Other controlling and regulating components</b>	<b>33</b>
<b>87 - Air conditioning system</b>	<b>34</b>
<b>1 Overview of fitting locations - air conditioning system</b>	<b>34</b>
1.1 Overview of fitting locations - components not located in passenger compartment	34
1.2 Overview of fitting locations - components located in front section of passenger compartment	36
<b>2 Refrigerant circuit</b>	<b>39</b>
2.1 System overview - refrigerant circuit	39
2.2 Assembly overview – condenser	41



2.3	Removing and installing refrigerant circuit pressure sender G805	43
2.4	Removing and installing refrigerant line with internal heat exchanger	44
2.5	Removing and installing expansion valve	48
2.6	Removing and installing condenser	53
2.7	Removing and installing desiccant bag or cartridge	57
2.8	Removing and installing damper weight for refrigerant line, low-pressure side	61
2.9	Removing and installing evacuating and charging valves on low and high-pressure side	62
2.10	Removing and installing refrigerant line from air conditioner compressor to evaporator	65
2.11	Removing and installing refrigerant line from condenser to air conditioner compressor	68
2.12	Removing and installing refrigerant line from air conditioner compressor to evaporator	71
<b>3</b>	<b>Air conditioner compressor</b>	<b>74</b>
3.1	Assembly overview – drive unit of air conditioner compressor	74
3.2	Assembly overview - pulley	76
3.3	Removing air conditioning compressor from and installing on bracket	78
3.4	Removing and installing air conditioner compressor	80
3.5	Checking high-pressure safety valve on air conditioner compressor	84
3.6	Removing and installing pulley	86
<b>4</b>	<b>Control motors</b>	<b>89</b>
4.1	Overview of fitting locations – control motors at front	89
4.2	Removing and installing temperature flap control motor V68	91
4.3	Removing and installing defroster flap control motor V107	93
4.4	Removing and installing air recirculation flap control motor V113	95
4.5	Removing and installing left temperature flap control motor V158	97
4.6	Removing and installing right temperature flap control motor V159	99
4.7	Removing and installing fresh air/air recirculation, air flow flap control motor V425	101
4.8	Removing and installing front air distribution flap control motor V426	103
4.9	Removing and installing air distribution flap control motor V428	105
4.10	Removing and installing air distribution flap actuator	107
<b>5</b>	<b>Front heater and air conditioning unit</b>	<b>111</b>
5.1	Assembly overview - add-on parts of heater and air conditioning unit and of air intake box	111
5.2	Assembly overview - flaps and partitions in air distribution housing	113
5.3	Assembly overview – heater and air conditioning unit	116
5.4	Assembly overview – evaporator housing	120
5.5	Removing and installing evaporator	121
5.6	Checking auxiliary air heater element Z35	123
5.7	Removing and installing auxiliary air heater element Z35	124
5.8	Removing and installing heater and air conditioning unit	125
5.9	Removing and installing holder for heater and air conditioning unit	132
5.10	Dismantling and assembling heater and air conditioning unit	134
5.11	Removing and installing air distribution housing	136
5.12	Removing and installing dust and pollen filter	136
5.13	Removing and installing fresh air blower V2	139
5.14	Removing and installing fresh air blower control unit J126	140
5.15	Removing and installing heat exchanger	140
5.16	Removing and installing coolant pipes on heat exchanger	146
5.17	Removing and installing evaporator temperature sensor G308	148
5.18	Removing and installing condensation drain	149
5.19	Checking condensation drain	152
<b>6</b>	<b>Air duct</b>	<b>154</b>
6.1	Assembly overview – air duct and air distribution in passenger compartment	154
6.2	Removing and installing driver side footwell vents	155
6.3	Removing and installing front passenger side footwell vents	156
6.4	Removing and installing rear footwell vent	158
6.5	Removing and installing air ducts	159
6.6	Removing and installing forced ventilation for passenger compartment	160



6.7	Checking forced ventilation for passenger compartment	161
6.8	Removing and installing fresh air intake	161
6.9	Removing and installing cover for fresh air intake	163
6.10	Removing and installing air intake duct	163
6.11	Removing and installing air duct for defroster vent	165
6.12	Removing and installing air duct for centre dash panel vent	165
<b>7</b>	<b>Operating and display unit</b>	<b>167</b>
7.1	Overview of fitting locations – operating and display unit	167
7.2	Removing and installing operating and display unit	171
<b>8</b>	<b>Other controlling and regulating components</b>	<b>174</b>
8.1	Removing and installing sunlight penetration photosensor G107	174
8.2	Working principles of air quality sensor G238	175
8.3	Removing and installing air quality sensor G238	176
8.4	Removing and installing ambient temperature sensor G17	177
8.5	Removing and installing humidity sender for air conditioning system G260	177
8.6	Removing and installing left vent temperature sender G150	178
8.7	Removing and installing right vent temperature sender G151	179
8.8	Removing and installing footwell vent temperature sender G192	180