



Contents

27 - Starter, current supply, CCS	1
1 Battery	1
1.1 Types of battery	1
1.2 Warning notices and safety regulations	1
1.3 Battery terminal connection	1
2 Checking battery	2
3 Charging battery	3
4 Disconnecting and connecting battery	4
4.1 Disconnecting and connecting battery, vehicles with battery in engine compartment	4
4.2 Disconnecting and connecting battery, vehicles with battery in luggage compartment	5
5 Removing and installing battery	8
5.1 Removing and installing battery, vehicles with battery in engine compartment	8
5.2 Removing and installing battery, models with battery in luggage compartment	11
6 Battery isolator	16
6.1 Overview of fitting locations	16
6.2 Safety precautions when working on battery isolator	16
6.3 Removing and installing battery isolator	17
7 Specified torques: battery	19
8 Starter motor	20
8.1 Checking starter B	20
8.2 Removing and installing starter, automatic gearbox	20
8.3 Removing and installing starter, manual gearbox	22
9 Specified torques: starter	27
9.1 Automatic gearbox except 3L and FSI models	27
9.2 Manual gearbox	27
10 Alternator	29
10.1 Checking alternator C	29
10.2 Checking poly V-belt	29
10.3 Alternator ► 04.99	29
10.4 Alternator 05.99 ►	30
10.5 4-cylinder injection engine (except vehicles with engine codes AHT and AVY)	31
10.6 4-cylinder fuel injected engine, engine code AHT	36
10.7 4-cylinder fuel injected engine, engine code AVY	41
10.8 3-cylinder diesel engine	43
10.9 4-cylinder diesel engine	45
10.10 Renewing poly V-belt pulley on alternator	46
10.11 Installing poly V-belt pulley with freewheel	48
11 Specified torques: alternator	50
11.1 General specified torques for all vehicles	50
11.2 Specified torques, 4-cyl. injection engine	50
11.3 Specified torques for 4-cyl. injection engine, engine code AHT	51
11.4 Specified torques for 4-cyl. injection engine, engine code AVY	51
11.5 Specified torques 3-cyl. diesel engine	52
11.6 Specified torques 4-cyl. diesel engine	52
90 - Gauges, instruments	53
1 Dash panel insert	53
1.1 Renewing dash panel insert	53
1.2 Removing and installing dash panel insert	54
1.3 Description of back of dash panel insert	55
1.4 Pin assignment of connectors on dash panel insert	57



1.5	Warning lamp symbols and instruments in dash panel insert	59
2	Service interval display	60
2.1	Resetting service interval display	60
92	Windscreen wash/wipe system	61
1	windscreen wiper system.	61
1.1	Removing and installing windscreen wiper system	61
1.2	Adjusting wiper blade park position	67
1.3	Checking and adjusting angle of incidence	67
1.4	Removing and installing wiper rubber	68
1.5	Removing and installing joint-free wipers	69
1.6	Removing and installing joint-free wiper rubber (manufacturer: Bosch)	70
2	Windscreen washer system	72
2.1	Assembly overview - windscreen washer system	72
2.2	Removing and installing windscreen washer system reservoir	73
2.3	Removing and installing windscreen and rear window washer pump V59	74
2.4	Removing and installing windscreen washer system spray jets	74
2.5	Adjusting windscreen washer system spray jets	74
3	Rear window wiper system	75
3.1	Assembly overview - rear window wiper system	75
3.2	Removing and installing rear window wiper	75
3.3	Adjusting rear window wiper park position	77
3.4	Renewing wiper rubber blade	78
3.5	Removing and installing aerodynamic wipers	78
4	Rear window washer system	80
4.1	Assembly overview - rear window washer system	80
4.2	Renewing spray jet	81
4.3	Adjusting spray jet	81
5	Headlight washer system	82
5.1	Assembly overview - headlight washer system	82
5.2	Removing and installing headlight washer system pump V11	83
5.3	Removing and installing spray jet pop-up cylinders	84
5.4	Removing and installing spray jet retainer	84
5.5	Removing and installing headlight washer system reservoir	85
5.6	Adjusting windscreen washer system spray jets	85
5.7	Bleeding headlight washer system	85
6	Washer fluid line hose couplings	86
7	Hose repair	87
8	Specified torques: Windscreen wash/wipe system	88
94	Lights, bulbs, switches - exterior	89
1	Headlights	89
1.1	Assembly overview - headlight	89
1.2	Removing and installing headlight	90
1.3	Renewing headlight bulbs	91
1.4	Renewing headlight bulbs, Lupo 16V	92
1.5	Renewing headlight bulbs, Lupo TDI	94
1.6	Removing and installing headlight range control motor	96
1.7	Repairing headlight retaining tabs	97
1.8	Headlight conversion for driving on left/right	99
1.9	Adjusting headlights	101
2	Headlight with gas discharge bulb	102
2.1	Assembly overview, headlights with gas discharge bulb	103
2.2	Removing and installing headlight	104



2.3	Renewing gas discharge headlight bulb	105
2.4	Removing and installing headlight range control motor for headlights with gas discharge bulb	112
2.5	Removing and installing gas discharge bulb control unit	114
2.6	Removing and installing rear left vehicle level sender G76 with integrated control unit for headlight range control J431	116
2.7	Coding headlight range control unit J431	116
2.8	Repairing headlight retaining tabs	117
2.9	Adjusting headlight with gas discharge bulb	117
3	Fog lights	118
3.1	Removing and installing fog light	118
3.2	Renewing fog light bulb	118
3.3	Adjusting fog lights	119
4	Front turn signals	120
4.1	Removing and installing front turn signal	120
4.2	Renewing turn signal bulb	121
5	Turn signal repeaters	123
5.1	Removing and installing turn signal repeaters	123
6	Tail lights	124
6.1	Assembly overview - tail light	124
6.2	Removing and installing tail light cluster	124
6.3	Removing and installing tail light bulb carrier	125
6.4	Specified torques: tail light cluster	125
7	Number plate light	126
7.1	Removing and installing number plate light	126
8	Additional brake lights	127
8.1	Lupo with steel rear lid	127
8.2	Lupo with alloy rear lid (Lupo 3L und Lupo FSI)	129
8.3	Lupo with steel rear lid and rear spoiler (Lupo GTI)	131
9	Steering column switch and ignition/starter switch	134
9.1	Assembly overview - steering column	134
9.2	Removing and installing steering column switch	135
9.3	Pin assignment on steering column switch	137
9.4	Removing and installing steering lock housing	137
9.5	Removing and installing lock cylinder	139
9.6	Removing and installing ignition/starter switch	140
9.7	Pin assignment for ignition switch	140
96	Lights, bulbs, switches - interior	141
1	Interior lights and switches	141
1.1	Removing and installing switch to deactivate interior monitor E267	141
2	Lights and switches in engine compartment	142
2.1	Removing and installing engine compartment light W27	142
2.2	Removing and installing anti-theft alarm and vermin repellent system contact switch F120	142
3	Lights and switches in dash panel, vehicles ► 04.00	143
3.1	Assembly overview - lights and switches in dash panel	143
3.2	Removing and installing light switch E1	143
3.3	Removing and installing headlight range control adjuster E102 and switch and instrument illumination regulator E20	144
3.4	Removing and installing switches in centre of dash panel	145
4	Lights and switches in dash panel, vehicles 05.00 ►	147
4.1	Assembly overview - switches in dash panel	147
4.2	Removing and installing light switch E1	147



4.3	Removing and installing headlight range control adjuster E102 and switch and instrument illumination regulator E20	148
4.4	Removing and installing switches in centre of dash panel	148
4.5	Removing and installing hazard warning light switch E3	149
4.6	Removing and installing front passenger side airbag deactivated warning lamp K145	150
4.7	Removing and installing key-operated switch to deactivate front passenger side airbag E224	151
5	Lights and switches in front doors	152
5.1	Removing and installing switch module for driver side window regulator	152
5.2	Removing and installing front right window regulator switch E41	153
5.3	Removing and installing Central locking SAFELOCK function warning lamp K133	154
5.4	Removing and installing door contact switch	155
6	Lights and switches in luggage compartment	156
6.1	Removing and installing luggage compartment light W3	156
6.2	Components - rear lid lock	156
7	Lights and switches in roof trim	157
7.1	Front interior light W	157
8	Horn	158
8.1	Removing and installing horn/dual tone horn H1	158
8.2	Removing and installing treble horn H2 and bass horn H7	159
9	Immobiliser	160
9.1	Immobiliser control unit J362	160
9.2	Removing and installing immobiliser reader coil D2	162
9.3	Ignition key	162
10	Anti-theft alarm (ATA)	164
10.1	Activating and deactivating anti-theft alarm	164
10.2	Removing and installing switch to deactivate interior monitor E267	165
10.3	Removing and installing ultrasonic sensor for ATAS G209	165
10.4	Central locking and anti-theft alarm system aerial R47	165
10.5	Alarm horn H12	165
97 - Wiring		167
1	Vehicle diagnosis, testing and information systems	167
1.1	Connecting vehicle diagnosis, testing and information system VAS 5051A	167
2	Removing and installing relay carrier, coupling station and fuse holder	170
2.1	Removing and installing relay carrier	170
2.2	Removing and installing coupling station below relay carrier	172
2.3	Removing and installing fuse holder in front left footwell	173
3	Select Control units	176
3.1	Data bus diagnostic interface J533	176
3.2	Central locking and anti-theft alarm system control unit J379	176
3.3	Voltage stabiliser J532	179
4	Wiring harness and connector repairs	181