



Contents

00 - Technical data	1
1 Technical data	1
1.1 Technical data	1
1.2 Engine number	1
1.3 Engine data	1
10 - Removing and installing engine	3
1 Removing and installing engine	3
1.1 Removing and installing engine	3
1.2 Notes on removing	4
1.3 Fastening the engine to the assembly stand	8
1.4 Notes on installation	9
1.5 Prescribed torque's	10
1.6 Aligning engine and gearbox mountings	11
1.7 Assembly mounting	12
1.8 Additional information and assembly work on models with an air conditioning system . . .	13
13 - Crankshaft group	14
1 Dismantling and assembling the engine	14
1.1 Dismantling and assembling the engine	14
1.2 Removing and installing poly V-belt	23
1.3 Checking semi-automatic toothed belt tensioning roller	25
2 Removing and installing sealing flange and pressure plate/drive plate	26
2.1 Removing and installing sealing flange and pressure plate/drive plate	26
2.2 Renewing crankshaft oil seal, belt pulley end	29
2.3 Removing and installing front sealing flange	33
2.4 Removing and installing drive plate	35
3 Removing and installing crankshaft	38
3.1 Removing and installing crankshaft	38
3.2 Colour markings	42
3.3 Crankshaft dimensions	42
4 Dismantling and assembling piston and conrod	43
4.1 Dismantling and assembling piston and conrod	43
4.2 Piston and cylinder dimensions	48
15 - Cylinder head, Valve gear	49
1 Removing and installing cylinder head	49
1.1 Removing and installing cylinder head	49
1.2 Removing, installing and tensioning toothed belts	53
1.3 Removing and installing cylinder head	60
1.4 Check compression pressures	64
2 Servicing valve gear	66
2.1 Servicing valve gear	66
2.2 Reworking valve seats	71
2.3 Renewing camshaft oil seal	73
2.4 Removing and installing camshaft	76
2.5 Checking valve guides	81
2.6 Renewing valve stem seals	82
17 - Lubrication	85
1 Removing and installing parts of the lubrication system	85
1.1 Removing and installing parts of the lubrication system	85
1.2 Removing and installing oil sump	93



1.3	Checking oil pressure and oil pressure switch	96
19	- Cooling system	98
1	Removing and installing parts of cooling system	98
1.1	Removing and installing parts of cooling system	98
1.2	Parts of cooling system body side	99
1.3	Parts of cooling system engine side	103
1.4	Coolant hose connection diagram	107
1.5	Draining and filling coolant system	108
1.6	Removing and installing the radiator	111
1.7	Removing and installing coolant pump	113
1.8	Removing and installing thermostat	115
20	- Fuel supply system	117
1	Removing and installing parts of fuel supply system	117
1.1	Removing and installing parts of fuel supply system	117
1.2	Removing and installing fuel tank with its attachments and fuel filter	118
1.3	Safety precautions when working on the fuel supply system	124
1.4	Rules for cleanliness	124
1.5	Removing and installing fuel delivery unit	125
1.6	Removing and installing fuel gauge sender	126
1.7	Removing and installing fuel tank	127
1.8	Checking fuel pump	129
1.9	Crash fuel shut-off	131
2	Checking electronic power control (EPC)	137
2.1	Checking electronic power control (EPC)	137
2.2	Function of EPC system	138
2.3	Checking accelerator pedal position sender	139
3	Activated charcoal canister system	142
3.1	Activated charcoal canister system	142
3.2	Function	142
3.3	Servicing parts of the activated charcoal canister system	143
3.4	Checking activated charcoal canister solenoid valve 1	145
3.5	Checking fuel tank breather	146
26	- Exhaust system	149
1	Removing and installing parts of exhaust system	149
1.1	Removing and installing parts of exhaust system	149
1.2	Exhaust manifold, front exhaust pipe and catalytic converter with attachments	150
1.3	Silencer with mountings	154
1.4	Checking catalytic converter	157
2	Secondary air system	159
2.1	Secondary air system	159
2.2	Function	159
2.3	Removing and installing parts of the secondary air system	160
2.4	Checking secondary air system	164
2.5	Checking secondary air pump motor	166
2.6	Checking combination valve	172
3	Exhaust gas recirculation system	172
3.1	Exhaust gas recirculation system	172
3.2	Servicing parts of exhaust gas recirculation system	173
3.3	Checking exhaust gas recirculation potentiometer (G212)	176