



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety measures when working on vehicles with a start/stop system	1
1.3 Safety precautions when working on the cooling system	1
2 General information	3
2.1 Notes concerning odours in air conditioned vehicles	3
2.2 Notes for vehicles with start-stop system	3
3 Repair notes	4
3.1 Checking cooling output	4
3.2 Working on refrigerant circuit	5
3.3 Refrigerant circuit seals	5
3.4 Notes on control motors	6
4 Technical data	12
4.1 Refrigerant capacity	12
4.2 Refrigerant oil capacities	12
4.3 Oil distribution	13
80 - Heating	14
1 Heating	14
87 - Air conditioning system	15
1 Overview of fitting locations - air conditioning system	15
1.1 Overview of fitting locations - components located in front section of passenger compartment	15
2 Refrigerant circuit	20
2.1 System overview - refrigerant circuit	20
2.2 Assembly overview - condenser	22
2.3 Removing and installing high-pressure sender G65	22
2.4 Removing and installing expansion valve	24
2.5 Removing and installing condenser	26
2.6 Removing and installing desiccant bag or cartridge	28
2.7 Removing and installing evacuating and charging valves on low and high-pressure side	34
3 Air conditioner compressor	37
3.1 Assembly overview - pulley	37
3.2 Removing air conditioning compressor from and installing on bracket	38
3.3 Removing and installing air conditioner compressor	40
3.4 Checking high-pressure safety valve on air conditioner compressor	43
3.5 Removing and installing pulley	44
4 Control motors	47
4.1 Overview of fitting locations - front control motors	47
4.2 Removing and installing temperature flap control motor V68	49
4.3 Removing and installing defroster flap control motor V107	51
4.4 Removing and installing air recirculation flap control motor V113	53
4.5 Removing and installing left temperature flap control motor V158	58
4.6 Removing and installing right temperature flap control motor V159	60
4.7 Removing and installing indirect ventilation flap control motor V213	62
4.8 Removing and installing fresh air/recirculated air, air flow flap control motor V425	63
4.9 Removing and installing front air distribution flap control motor V426	65
4.10 Removing and installing air distribution flap control motor V428	66
4.11 Removing and installing fresh air/air recirculation, air flow flap actuator	67



5	Front heater and air conditioning unit	68
5.1	Assembly overview - heater and air conditioning unit	68
5.2	Removing and installing evaporator	73
5.3	Dismantling and assembling evaporator housing	73
5.4	Removing and installing heater and air conditioning unit	74
5.5	Dismantling and assembling heater and air conditioning unit	78
5.6	Removing and installing air distribution housing	80
5.7	Dismantling and assembling air distribution housing	81
5.8	Checking auxiliary air heater element Z35	83
5.9	Removing and installing auxiliary air heater element Z35	84
5.10	Removing and installing evaporator temperature sensor G308	85
5.11	Removing and installing dust and pollen filter	85
5.12	Removing and installing fresh air blower series resistor with overheating fuse N24	86
5.13	Removing and installing fresh air blower V2	87
5.14	Removing and installing fresh air blower control unit J126	89
5.15	Removing and installing heat exchanger	89
5.16	Removing and installing condensation drain	93
5.17	Checking condensation drain	94
6	Air duct	95
6.1	Assembly overview - air duct and air distribution in passenger compartment	95
6.2	Removing and installing centre vent	96
6.3	Removing and installing driver or front passenger side air vents	97
6.4	Removing and installing rear vents	98
6.5	Removing and installing driver side footwell vents	99
6.6	Removing and installing front passenger side footwell vents	100
6.7	Removing and installing left or right side window vents	101
6.8	Removing and installing rear footwell vent	102
6.9	Removing and installing rear centre console vent duct	103
6.10	Removing and installing rear footwell vent	104
6.11	Removing and installing fresh air intake	104
6.12	Removing and installing glove box cooling	105
6.13	Checking forced ventilation for passenger compartment	105
6.14	Removing and installing forced ventilation for passenger compartment	106
7	Operating and display unit	108
7.1	Overview of operating and display unit	108
7.2	Removing and installing operating and display unit	118
8	Other controlling and regulating components	122
8.1	Removing and installing sunlight penetration photosensor G107	122
8.2	Principle of operation of air quality sensor G238	122
8.3	Removing and installing air quality sensor G238	124
8.4	Removing and installing ambient temperature sensor G17	124
8.5	Removing and installing left vent temperature sender G150	125
8.6	Removing and installing right vent temperature sender G151	125
8.7	Removing and installing left footwell vent temperature sender G261	126
8.8	Removing and installing right footwell vent temperature sender G262	126