



## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Safety information</b>	<b>1</b>
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety precautions when handling refrigerants	2
1.3 Safety measures when working on vehicles with a start/stop system	2
1.4 Safety precautions when working on high-voltage system	2
1.5 Safety precautions when working in the vicinity of high-voltage components	3
1.6 Safety precautions when working on the cooling system	3
1.7 Safety precautions when working on vehicles with auxiliary/supplementary heater	4
<b>2 Identification</b>	<b>5</b>
2.1 Identification of heater and air conditioning unit	5
<b>3 General information</b>	<b>6</b>
3.1 Notes concerning odours in air conditioned vehicles	6
3.2 Notes for vehicles with start-stop system	6
3.3 Type plates	7
<b>4 Repair notes</b>	<b>8</b>
4.1 Working on refrigerant circuit	8
4.2 General repair instructions	9
4.3 Refrigerant circuit seals	9
4.4 Checking heater output	10
4.5 Checking cooling output	30
<b>5 Technical data</b>	<b>60</b>
5.1 Refrigerant capacity	60
5.2 Refrigerant oil capacities	60
5.3 Oil distribution	61
<b>80 - Heating</b>	<b>62</b>
<b>1 Heating</b>	<b>62</b>
<b>87 - Air conditioning system</b>	<b>63</b>
<b>1 Overview of fitting locations - air conditioning system</b>	<b>63</b>
1.1 Overview of fitting locations - components not located in passenger compartment	63
1.2 Overview of fitting locations - components located in front section of passenger compartment	66
<b>2 Refrigerant circuit</b>	<b>69</b>
2.1 System overview - refrigerant circuit	69
2.2 Assembly overview - condenser	75
2.3 Removing and installing refrigerant circuit pressure sender G805	77
2.4 Removing and installing expansion valve	79
2.5 Removing and installing condenser	86
2.6 Removing and installing desiccant bag or cartridge	90
2.7 Removing and installing damper weight for refrigerant line, low-pressure side	98
2.8 Removing and installing refrigerant pressure and temperature sender G395	99
2.9 Removing and installing refrigerant shut-off valve for heater and air conditioner unit N541	100
2.10 Removing and installing refrigerant shut-off valve for high-voltage battery heat exchanger N542	104
2.11 Removing and installing heat exchanger for high-voltage battery	107
2.12 Removing and installing evacuating and charging valves on low and high-pressure side	110
2.13 Removing and installing refrigerant line with internal heat exchanger	112
2.14 Refrigerant line with restrictor	119



2.15	Removing and installing refrigerant line between condenser and heat exchanger for high-voltage battery, refrigerant line with internal heat exchanger, Passat GTE .....	119
2.16	Removing and installing refrigerant line between electrical air conditioner compressor V470 and heat exchanger for high-voltage battery, refrigerant line with internal heat exchanger, Passat GTE .....	121
2.17	Removing and installing refrigerant line between condenser and evaporator .....	124
2.18	Removing and installing refrigerant line between condenser and air conditioner compressor .....	127
2.19	Removing and installing refrigerant line between condenser and air conditioner compressor, Passat GTE .....	130
2.20	Removing and installing refrigerant line between air conditioner compressor and evaporator .....	132
2.21	Commissioning of air conditioning system after filling refrigerant circuit .....	135
<b>3</b>	<b>Air conditioner compressor .....</b>	<b>137</b>
3.1	Assembly overview - drive unit of air conditioner compressor .....	137
3.2	Assembly overview - pulley .....	141
3.3	Removing air conditioning compressor from and installing on bracket .....	145
3.4	Removing and installing air conditioner compressor .....	149
3.5	Removing and installing high-voltage system fuse 3 S353 .....	156
3.6	Checking high-pressure safety valve on air conditioner compressor .....	157
3.7	Removing and installing pulley .....	157
<b>4</b>	<b>Control motors .....</b>	<b>162</b>
4.1	Overview of fitting locations – front control motors .....	162
4.2	Removing and installing temperature flap control motor V68 with potentiometer G92 .....	167
4.3	Removing and installing defroster flap control motor V107 with potentiometer G135 .....	170
4.4	Removing and installing air recirculation flap control motor V113 .....	174
4.5	Removing and installing left temperature flap control motor V158 with potentiometer G220 .....	178
4.6	Removing and installing right temperature flap control motor V159 with potentiometer G221 .....	182
4.7	Removing and installing rear temperature flap control motor V137 .....	185
4.8	Removing and installing fresh air/air recirculation, air flow flap control motor V425 with potentiometer G644 .....	186
4.9	Removing and installing front air distribution flap control motor V426 with potentiometer for front air distribution flap control motor G642 .....	191
4.10	Removing and installing air distribution flap control motor V428 with potentiometer G645 .....	196
4.11	Removing and installing air distribution flap actuation unit .....	200
<b>5</b>	<b>Front heater and air conditioning unit .....</b>	<b>206</b>
5.1	Assembly overview - heater and air conditioning unit .....	206
5.2	Assembly overview - add-on parts of heater and air conditioning unit and of air intake box .....	210
5.3	Assembly overview - evaporator housing .....	212
5.4	Assembly overview - flaps and partitions in air distribution housing .....	213
5.5	Removing and installing heater and air conditioning unit .....	216
5.6	Dismantling and assembling heater and air conditioning unit .....	221
5.7	Removing and installing air distribution housing .....	222
5.8	Removing and installing holder for heater and air conditioning unit .....	222
5.9	Removing and installing evaporator .....	223
5.10	Removing and installing fresh air blower control unit J126 .....	225
5.11	Removing and installing dust and pollen filter .....	226
5.12	Removing and installing fresh air blower V2 .....	228
5.13	Checking auxiliary air heater element Z35 with auxiliary air heater control unit J604 .....	229
5.14	Removing and installing auxiliary air heater element Z35 with auxiliary air heater control unit J604 .....	231
5.15	Removing and installing heat exchanger .....	233
5.16	Removing and installing coolant pipes on heat exchanger .....	254
5.17	Removing and installing evaporator temperature sensor G308 .....	256



5.18	Checking condensation drain .....	258
5.19	Removing and installing condensation drain .....	259
5.20	Removing and installing baffle plate .....	263
<b>6</b>	<b>Air duct .....</b>	<b>264</b>
6.1	Assembly overview - air duct and air distribution in passenger compartment .....	264
6.2	Removing and installing fresh air intake .....	265
6.3	Removing and installing cover for fresh air intake .....	267
6.4	Removing and installing air intake duct .....	268
6.5	Removing and installing driver side footwell vents .....	269
6.6	Removing and installing front passenger side footwell vents .....	270
6.7	Removing and installing rear footwell vent .....	271
6.8	Removing and installing air duct for rear vent .....	272
6.9	Removing and installing dash panel air duct .....	273
6.10	Removing and installing rear centre console vent duct .....	273
6.11	Checking forced ventilation for passenger compartment .....	274
6.12	Removing and installing forced ventilation for passenger compartment .....	274
6.13	Removing and installing air duct for defroster vent .....	275
6.14	Removing and installing air duct for centre vent .....	276
<b>7</b>	<b>Coolant circuit .....</b>	<b>277</b>
7.1	Incorporation of high-voltage heater (PTC) Z115 into coolant circuit .....	277
7.2	Incorporation of heat exchanger for high-voltage battery into coolant circuit of high-voltage system .....	281
7.3	Removing and installing coolant valve for high-voltage battery N688 .....	283
7.4	Removing and installing coolant valve for high-voltage battery V590 .....	285
7.5	Removing and installing high-voltage heater (PTC) Z115 / high-voltage heater (PTC) J848 .....	286
<b>8</b>	<b>Operating and display unit .....</b>	<b>291</b>
8.1	Overview of operating and display unit .....	291
8.2	Removing and installing operating and display unit .....	296
<b>9</b>	<b>Other controlling and regulating components .....</b>	<b>299</b>
9.1	Removing and installing sunlight penetration photosensor G107 .....	299
9.2	Removing and installing external air quality and humidity sensor G935 .....	300
9.3	Removing and installing ambient temperature sensor G17 .....	302
9.4	Removing and installing humidity sender for air conditioning system G260 .....	302
9.5	Removing and installing left vent temperature sender G150 .....	302
9.6	Removing and installing right vent temperature sender G151 .....	303
9.7	Removing and installing rear vent temperature sender G174 .....	304
9.8	Removing and installing footwell vent temperature sender G192 .....	305