



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety measures when working on vehicles with start/stop system	1
2 Identification	2
2.1 Gearbox identification	2
3 Repair instructions	3
3.1 General repair instructions	3
4 Technical data	5
4.1 Allocation gearbox - engine	5
4.2 Capacities	5
5 Overview - power transmission	6
6 Electrical components	7
6.1 Overview of fitting locations - electrical components	7
30 - Clutch	8
1 Clutch mechanism	8
1.1 Assembly overview - pedal cluster	8
1.2 Assembly overview - clutch hydraulics	10
1.3 Checking clutch master cylinder and clutch slave cylinder	12
1.4 Removing and installing bearing bush	13
1.5 Removing and installing clutch position sender G476	14
1.6 Removing and installing return spring	15
1.7 Removing and installing over-centre spring	19
1.8 Removing and installing clutch pedal	22
1.9 Removing and installing mounting bracket	24
1.10 Removing and installing clutch master cylinder	29
1.11 Removing and installing lines for clutch mechanism	30
1.12 Bleeding clutch mechanism	33
2 Clutch	36
34 - Controls, housing	37
1 Selector mechanism	37
1.1 Assembly overview – gear knob and cover	37
1.2 Assembly overview - selector mechanism	38
1.3 Removing and installing gear knob	41
1.4 Removing and installing selector mechanism	43
1.5 Adjusting selector mechanism	53
1.6 Checking selector mechanism	56
2 Removing and installing gearbox	57
2.1 Specified torques for gearbox	57
2.2 Removing gearbox	58
2.3 Installing gearbox	66
3 Transporting gearbox	69
4 Gear oil	70
4.1 Checking gear oil level	70
4.2 Draining and filling gear oil	70
35 - Gears, shafts	72
1 Input shaft	72
2 Output shaft	73



39 - Final drive - differential	74
1 Oil seals	74
1.1 Overview of fitting locations - oil seals	74
1.2 Renewing left seal	75
1.3 Renewing right seal	79



Contents

00 - Technical data	1
1 Safety information	1
2 Identification	2
3 Repair instructions	3
3.1 General repair instructions	3
4 Technical data	4
4.1 Allocation gearbox - engine	4
4.2 Capacities	4
5 Overview - power transmission	5
6 Electrical components	6
6.1 Overview of fitting locations - electrical components	6
30 - Clutch	7
1 Clutch mechanism	7
1.1 Assembly overview - clutch release mechanism	7
1.2 Removing and installing clutch slave cylinder together with release bearing	7
1.3 Repairing clutch release mechanism	9
2 Clutch	10
2.1 Assembly overview - clutch	10
2.2 Removing and installing clutch	11
34 - Controls, housing	22
1 Selector mechanism	22
1.1 Renewing selector shaft seal	22
2 Removing and installing gearbox	24
3 Transporting gearbox	25
4 Dismantling and assembling gearbox	27
4.1 Assembly overview - gearbox	27
4.2 Assembly overview - selector unit	29
4.3 Removing and installing selector unit	30
4.4 Dismantling and assembling gearbox	32
5 Gearbox housing, clutch housing	55
5.1 Assembly overview - gearbox housing	55
5.2 Assembly overview - clutch housing	58
5.3 Repairing gearbox housing	60
5.4 Repairing clutch housing	68
6 Securing to engine and gearbox support	75
7 Gear oil	76
35 - Gears, shafts	77
1 Input shaft	77
1.1 Assembly overview - input shaft	77
1.2 Dismantling and assembling input shaft	80
1.3 Renewing input shaft seal	96
2 Output shaft	98
2.1 Assembly overview - output shaft	98
2.2 Dismantling and assembling output shaft	99
3 Reverse shaft	110
3.1 Assembly overview - reverse shaft	110
3.2 Dismantling and assembling reverse shaft	110



3.3	Adjusting reverse shaft	112
39	- Final drive - differential	117
1	Oil seals	117
1.1	Overview of fitting locations - oil seals	117
1.2	Renewing left seal	117
1.3	Renewing right seal	120
2	Differential	124
2.1	Adjusting differential	124
3	Adjustment overview	130