



## Contents

<b>80 - Heating</b>	<b>1</b>
<b>1 Repairing heating system, passenger compartment</b>	<b>1</b>
1.1 Removing and installing fresh air blower V2 on vehicles with manual controls	1
1.2 Removing and installing fresh air blower series resistor with overheating fuse N24	2
1.3 Removing and installing dust and pollen filter	3
1.4 Removing vents	3
1.5 Removing and installing heat exchanger	5
1.6 Removing and installing coolant pipes to heat exchanger	9
1.7 Checking, removing and installing auxiliary air heater element Z35	11
1.8 Checking ventilation	13
1.9 Removing and installing inlet grilles	14
<b>87 - Air conditioning system</b>	<b>16</b>
<b>1 Notes on repair work to vehicles with air conditioning and on handling refrigerant</b>	<b>16</b>
1.1 Notes concerning odours in air conditioned vehicles	16
<b>2 Notes for vehicles with a start-stop system</b>	<b>17</b>
<b>3 Air conditioning system with manual regulation „Climatic“ up to week 21/2011</b>	<b>18</b>
3.1 Air conditioning and heating - passenger compartment	18
3.2 Air conditioning system with manual controls „Climatic“ to WEEK 21/2011	21
3.3 Removing and installing heating and air conditioning controls, „Climatic“ with air conditioning system control unit J301	22
3.4 Connectors on controls for heating and air conditioning „Climatic“	23
3.5 Removing and installing flexible shaft for air distribution	24
3.6 Removing and installing air distribution flap actuator	25
3.7 Removing and installing air recirculation flap control motor V113	26
3.8 Removing and installing temperature flap control motor V68	26
3.9 Removing and installing footwell vent temperature sender G192	28
3.10 Removing and installing centre vent temperature sender G191	28
3.11 Ambient temperature sensor G17	29
<b>4 Air conditioning system with manual regulation from week 22/2011</b>	<b>30</b>
4.1 Function of manual air conditioning system controls	30
4.2 Multi-pin connector pin assignment on rear of front air conditioning system operating and display unit E87	31
4.3 Removing and installing evaporator temperature sensor G308	33
4.4 Removing and installing air distribution flap control motor V428	34
<b>5 Air conditioning system with automatic regulation „Climatronic“</b>	<b>35</b>
5.1 Procedure for checking and adjusting components	35
5.2 Function of operating and display unit for Climatronic air conditioning system E87	36
5.3 Removing and installing operating and display unit for Climatronic air conditioning system E87 with Climatronic control unit J255	37
5.4 Connectors on Climatronic control unit J255	38
5.5 Climatronic - passenger compartment	39
5.6 Removing and installing fresh air blower V2 on vehicles with automatic controls „Climatronic“	42
5.7 Removing and installing fresh air blower control unit J126	43
5.8 Removing and installing left footwell vent temperature sender G261	43
5.9 Removing and installing right footwell vent temperature sender G262	44
5.10 Removing and installing evaporator temperature sensor G308 or evaporator output temperature sender G263	44
5.11 Ambient temperature sensor G17	45
5.12 Function of air quality sensor G238	45
5.13 Removing and installing air quality sensor G238	47
5.14 Removing left vent temperature sender G150	48



5.15	Removing right vent temperature sender G151 .....	48
5.16	Removing sunlight penetration photosensor G107 or sunlight penetration photosensor 2 G134 .....	48
5.17	Checking condensation water drainage hose on heater and air conditioner unit .....	49
5.18	Removing and installing glove box cooling .....	49
5.19	Renewing control motors for air conditioning regulation .....	50
5.20	Removing and installing fresh air/recirculated air, air flow flap control motor V425 .....	50
5.21	Removing and installing setting unit for fresh air and air recirculation flap and air flow flap .....	51
5.22	Removing and installing defroster flap control motor V107 .....	52
5.23	Removing and installing left temperature flap control motor V158 .....	53
5.24	Removing and installing right temperature flap control motor V159 .....	55
5.25	Removing and installing front air distribution flap control motor V426 with potentiometer for front air distribution flap control motor G642 .....	55
<b>6</b>	<b>Removing and installing ancillary bracket for air conditioner compressor .....</b>	<b>57</b>
<b>7</b>	<b>Repair work on refrigerant circuit which may be performed only in appropriate workshops by specially trained mechanics .....</b>	<b>58</b>
7.1	Testing equipment and tools .....	59
7.2	Removing and installing heater and air conditioning unit .....	60
7.3	Dismantling and assembling heater and air conditioner unit „Climatic“ .....	65
7.4	Dismantling and assembling heater and air conditioner unit „Climatronic“ .....	67
7.5	Assembly overview - evaporator housing .....	69
7.6	Removing and installing air distribution housing .....	70
7.7	Dismantling and assembling evaporator housing .....	71
7.8	Removing and installing evaporator .....	71
7.9	Renewing refrigerant circuit components .....	72
7.10	Removing and installing high-pressure sender G65 .....	76
7.11	Removing and installing receiver with dryer .....	76
7.12	Renewing dryer cartridge on Modine condenser .....	78
7.13	Removing and installing air conditioner compressor .....	80
7.14	Removing and installing poly V-belt pulley (air conditioner compressor from „Denso“) .....	83
7.15	Checking high-pressure safety valve on air conditioner compressor .....	86
7.16	Expansion valve, function and removing .....	86
7.17	Removing and installing condenser .....	89
7.18	Notes on installing air conditioner compressor .....	91
<b>8</b>	<b>Capacities .....</b>	<b>95</b>
8.1	Refrigerant R134a .....	95
8.2	Refrigerant oil .....	95