



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety precautions when handling refrigerants	1
1.3 Safety measures when working on vehicles with a start/stop system	2
1.4 Safety precautions when working on high-voltage system	2
1.5 Safety precautions when working in the vicinity of high-voltage components	3
1.6 Safety precautions when working on the cooling system	3
1.7 Safety precautions for working on vehicles with auxiliary/supplementary heater	4
1.8 Safety precautions when using testers and measuring instruments during a road test	5
2 Identification	6
2.1 Identification of heater and air conditioning unit	6
3 General information	8
3.1 Type plates	8
4 Repair notes	11
4.1 Working on refrigerant circuit	11
4.2 General repair instructions	11
4.3 Refrigerant circuit seals	12
4.4 Checking cooling output	12
5 Technical data	15
5.1 Refrigerant capacity	15
5.2 Refrigerant oil capacities	15
5.3 Oil distribution	16
80 - Heating	17
1 Heating system	17
87 - Air conditioning system	18
1 Overview of fitting locations - air conditioning system	18
1.1 Overview of fitting locations – components not located in passenger compartment	18
1.2 Overview of fitting locations - components located in front section of passenger compartment	21
2 Refrigerant circuit	24
2.1 System overview - refrigerant circuit	24
2.2 Assembly overview – refrigerant lines	26
2.3 Assembly overview – condenser	30
2.4 Assembly overview - heat exchanger for high-voltage battery	32
2.5 Removing and installing refrigerant circuit pressure sender G805	33
2.6 Removing and installing expansion valve	34
2.7 Removing and installing condenser	42
2.8 Removing and installing desiccant bag or cartridge	45
2.9 Removing and installing damper weight for refrigerant line, low-pressure side	56
2.10 Removing and installing evacuating and charging valves on low and high-pressure side	56
2.11 Removing and installing refrigerant shut-off valve for heater and air conditioner unit N541	59
2.12 Removing and installing refrigerant shut-off valve for high-voltage battery heat exchanger N542	62
2.13 Removing and installing heat exchanger for high-voltage battery	65
2.14 Removing and installing refrigerant line with internal heat exchanger	70
2.15 Removing and installing refrigerant line from condenser to evaporator	77
2.16 Removing and installing refrigerant line from air conditioner compressor to condenser	83
2.17 Removing and installing refrigerant line from evaporator to air conditioner compressor	87
2.18 Commissioning air conditioning system after filling refrigerant circuit	92



3	Air conditioner compressor	94
3.1	Assembly overview – air conditioner compressor	94
3.2	Assembly overview - pulley	100
3.3	Removing air conditioning compressor from and installing on bracket	106
3.4	Removing and installing air conditioner compressor	110
3.5	Removing and installing high-voltage system fuse 3 S353	117
3.6	Checking high-pressure safety valve on air conditioner compressor	117
3.7	Removing and installing pulley	118
4	Control motors	127
4.1	Overview of fitting locations – control motors at front	127
4.2	Removing and installing temperature flap control motor V68 with potentiometer G92	133
4.3	Removing and installing defroster flap control motor V107 with potentiometer G135	136
4.4	Removing and installing air recirculation flap control motor V113	140
4.5	Removing and installing left temperature flap control motor V158 with potentiometer G220	144
4.6	Removing and installing right temperature flap control motor V159 with potentiometer G221	148
4.7	Removing and installing rear temperature flap control motor V137	152
4.8	Removing and installing fresh air/air recirculation, air flow flap control motor V425 with potentiometer G644	154
4.9	Removing and installing front air distribution flap control motor V426 with potentiometer for front air distribution flap control motor G642	158
4.10	Removing and installing air distribution flap control motor V428 with potentiometer G645	162
4.11	Removing and installing air distribution flap adjustment unit	167
5	Front heater and air conditioning unit	174
5.1	Assembly overview – heater and air conditioning unit	174
5.2	Assembly overview - add-on parts of heater and air conditioning unit and of air intake box	180
5.3	Assembly overview – evaporator housing	182
5.4	Assembly overview - flaps and partitions in air distribution housing	183
5.5	Removing and installing heater and air conditioning unit	186
5.6	Dismantling and assembling heater and air conditioning unit	191
5.7	Removing and installing air distribution housing	192
5.8	Removing and installing bracket for heater and air conditioning unit	193
5.9	Removing and installing evaporator	195
5.10	Removing and installing fresh air blower control unit J126	197
5.11	Removing and installing dust and pollen filter	198
5.12	Removing and installing fresh air blower V2	202
5.13	Checking auxiliary air heater element Z35 with auxiliary air heater control unit J604	205
5.14	Removing and installing auxiliary air heater element Z35 with auxiliary air heater control unit J604	207
5.15	Removing and installing heat exchanger	210
5.16	Removing and installing coolant pipes on heat exchanger	230
5.17	Removing and installing evaporator temperature sensor G308	234
5.18	Checking condensation drain	236
5.19	Removing and installing condensation drain	238
5.20	Removing and installing baffle plate	242
6	Air duct	243
6.1	Assembly overview – air duct and air distribution in passenger compartment	243
6.2	Removing and installing fresh air intake	244
6.3	Removing and installing cover for fresh air intake	246
6.4	Removing and installing air intake duct	247
6.5	Removing and installing driver side footwell vents	248
6.6	Removing and installing front passenger side footwell vents	250
6.7	Removing and installing rear footwell vent	251
6.8	Removing and installing air duct for rear vent	252
6.9	Removing and installing air duct for rear centre console vent	253
6.10	Checking forced ventilation for passenger compartment	254



6.11	Removing and installing forced ventilation for passenger compartment	254
6.12	Removing and installing air duct for defroster vent	255
6.13	Removing and installing air duct for centre vent	256
7	Coolant circuit	257
7.1	Connection diagram – high-voltage heater	257
7.2	Assembly overview - high-voltage heater (PTC) ZX17	262
7.3	Removing and installing high voltage heater (PTC) ZX17	263
7.4	Removing and installing coolant changeover valve 1 N632	270
7.5	Removing and installing coolant valve for high-voltage battery N688	270
7.6	Removing and installing coolant pump for high-voltage battery V590	270
8	Operating and display unit	271
8.1	Overview of operating and display unit	271
8.2	Removing and installing operating and display unit	278
9	Other controlling and regulating components	281
9.1	Removing and installing sunlight penetration photosensor G107	281
9.2	Removing and installing air quality sensor G238 / G935	282
9.3	Removing and installing ambient temperature sensor G17	284
9.4	Removing and installing humidity sender for air conditioning system G260	285
9.5	Removing and installing left vent temperature sender G150	285
9.6	Removing and installing right vent temperature sender G151	286
9.7	Removing and installing rear vent temperature sender G174	288
9.8	Removing and installing footwell vent temperature sender G192	288
9.9	Removing and installing heater and air conditioning system control unit J979	289