



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety precautions when handling refrigerants	1
1.3 Safety measures when working on vehicles with a start/stop system	2
1.4 Safety precautions when working on high-voltage system	2
1.5 Safety precautions when working in the vicinity of high-voltage components	3
1.6 Safety precautions when working on the cooling system	3
1.7 Safety precautions for working on vehicles with auxiliary/supplementary heater	4
2 General information	5
2.1 Notes concerning odours in air conditioned vehicles	5
2.2 Notes for vehicles with start-stop system	5
3 Repair notes	6
3.1 Working on refrigerant circuit	6
3.2 General repair instructions	6
3.3 Refrigerant circuit seals	6
4 Technical data	8
4.1 Refrigerant capacity	8
4.2 Refrigerant oil	8
4.3 Oil distribution	9
80 - Heating	10
1 Heating system	10
87 - Air conditioning system	11
1 Overview of fitting locations - air conditioning system	11
1.1 Overview of fitting locations - components not located in passenger compartment	11
2 Refrigerant circuit	13
2.1 System overview - refrigerant circuit	13
2.2 Removing and installing evacuating and charging valves on low and high-pressure side	17
2.3 Removing and installing desiccant bag or cartridge	20
2.4 Notes on installing air conditioner compressor	24
2.5 Removing and installing high-pressure sender G65	25
2.6 Removing and installing expansion valve	27
2.7 Removing and installing condenser	33
2.8 Removing and installing refrigerant line from air conditioner compressor to evaporator	36
2.9 Removing and installing refrigerant line from air conditioner compressor to condenser	41
3 Air conditioner compressor	48
3.1 Removing and installing air conditioner compressor	48
3.2 Checking high-pressure safety valve on air conditioner compressor	72
3.3 Removing and installing drive plate with overload protection	72
3.4 Checking and adjusting true running of drive plate with overload protection	73
3.5 Removing and installing air conditioner compressor drive plate	74
3.6 Conversion from Hardy disc to Gates coupling	75
3.7 Removing and installing mounting with freewheel on air conditioner compressor	77
4 Control motors	80
4.1 Renewing control motors on heater and air conditioner unit	80
4.2 Overview of control motors on heater and air conditioner unit	81
4.3 Removing and installing defroster flap control motor V107	82
4.4 Removing and installing left side vent control motor V299	83
4.5 Removing and installing left centre vent control motor V110	83
4.6 Removing and installing left footwell flap control motor V108	84



4.7	Removing and installing left temperature flap control motor V158	85
4.8	Removing and installing right temperature flap control motor V159	85
4.9	Removing and installing fresh air/air recirculation, air flow flap control motor V425	86
4.10	Removing and installing indirect ventilation flap control motor V213	86
4.11	Removing and installing control motor for right indirect ventilation flap V453	88
4.12	Removing and installing rear left temperature flap control motor V313	89
4.13	Removing and installing rear right temperature flap control motor V314	90
5	Front heater and air conditioning unit	91
5.1	Assembly overview – heater and air conditioning unit	91
5.2	Removing and installing auxiliary air heater element Z35	93
5.3	Removing and installing heater and air conditioning unit	97
5.4	Dismantling and assembling heater and air conditioning unit	100
5.5	Removing and installing dust and pollen filter	102
5.6	Removing and installing fresh air blower V2	104
5.7	Removing and installing evaporator temperature sensor G308	105
5.8	Removing and installing heat exchanger	105
5.9	Checking condensation drain	109
5.10	Dismantling and assembling evaporator housing	110
5.11	Removing and installing evaporator	113
5.12	Removing and installing evaporator with heater and air conditioner unit installed	115
6	Rear heater and air conditioning unit	117
6.1	Assembly overview – heater and air conditioning unit	117
6.2	Rear heater and air conditioning unit, service position	120
6.3	Removing and installing heater and air conditioning unit	121
6.4	Dismantling and assembling 2nd heater and air conditioning unit	125
6.5	Removing and installing rear left vent temperature sender G405	127
6.6	Removing and installing rear right vent temperature sender G406	127
6.7	Removing and installing rear fresh air blower V80	128
6.8	Removing and installing heat exchanger	128
6.9	Checking condensation drain hose	132
7	Air duct	133
7.1	Removing and installing driver-side vent in dash panel	133
7.2	Removing and installing front-passenger side vent in dash panel	134
7.3	Removing side vent in B-pillar	135
7.4	Removing and installing driver side footwell vents	135
7.5	Removing and installing front passenger side footwell vents	136
7.6	Removing and installing rear vents	137
7.7	Removing and installing fresh air intake	138
7.8	Checking forced ventilation for passenger compartment	139
8	Coolant circuit	140
8.1	Removing and installing coolant shut-off valve N82	140
8.2	Removing and installing circulation pump V55	143
9	Operating and display unit	146
9.1	Overview of operating and display unit	146
9.2	Removing and installing operating and display unit	151
9.3	Climatronic function via the infotainment system	154
10	Other controlling and regulating components	157
10.1	Removing and installing sunlight penetration photosensor G107	157
10.2	Removing and installing air quality sensor G238	158
10.3	Principle of operation of air quality sensor G238	158
10.4	Removing and installing ambient temperature sensor G17	160
10.5	Removing and installing humidity sender for air conditioning system G260	160
10.6	Removing and installing left footwell vent temperature sender G261	160
10.7	Removing and installing right footwell vent temperature sender G262	161



10.8	Removing and installing front right chest vent temperature sensor G386 and front left chest vent temperature sensor G385	161
------	--	-----