



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety precautions when handling refrigerants	1
1.3 Safety measures when working on vehicles with a start/stop system	2
1.4 Safety precautions when working on the cooling system	2
1.5 Safety precautions for working on vehicles with auxiliary/supplementary heater	2
2 Identification	4
2.1 Identification of heater and air conditioning unit	4
3 General information	6
3.1 Type plates	6
4 Repair notes	9
4.1 Working on refrigerant circuit	9
4.2 General repair instructions	9
4.3 Refrigerant circuit seals	9
5 Technical data	11
5.1 Refrigerant capacity	11
5.2 Refrigerant oil capacities	11
5.3 Oil distribution	12
80 - Heating	13
1 Overview of fitting locations - heating	13
1.1 Overview of fitting locations – components not located in passenger compartment	13
1.2 Overview of fitting locations - components located in front section of passenger compartment	14
2 Control motors	15
2.1 Overview of fitting locations – control motors at front	15
2.2 Removing and installing temperature flap control motor V68 with potentiometer G92	16
2.3 Removing and installing air recirculation flap control motor V113	17
2.4 Removing and installing air distribution flap control motor V428 with potentiometer G645	17
3 Heater	18
3.1 Assembly overview – heater unit	18
3.2 Removing and installing fresh air blower V2	23
3.3 Removing and installing fresh air blower control unit J126	23
3.4 Removing and installing dust and pollen filter	23
3.5 Removing and installing heater unit	23
3.6 Dismantling and assembling heater unit	23
3.7 Checking auxiliary air heater element Z35 with auxiliary air heater control unit J604	23
3.8 Removing and installing auxiliary air heater element Z35 with auxiliary air heater control unit J604	23
3.9 Removing and installing heat exchanger	23
4 Air duct	24
4.1 Assembly overview – air duct and air distribution in passenger compartment	24
4.2 Removing and installing driver side footwell vents	24
4.3 Removing and installing front passenger side footwell vents	24
4.4 Removing and installing rear footwell vent	24
4.5 Removing and installing fresh air intake	24
4.6 Removing and installing cover for fresh air intake	24
4.7 Removing and installing intake duct	24
4.8 Checking forced ventilation for passenger compartment	25
4.9 Removing and installing forced ventilation for passenger compartment	25
4.10 Removing and installing air duct for defroster vent	25



4.11	Removing and installing air duct for centre vent	25
5	Operating and display unit	26
5.1	Overview of operating and display unit	26
5.2	Removing and installing operating and display unit	28
6	Other controlling and regulating components	29
6.1	Removing and installing ambient temperature sensor G17	29
87	Air conditioning system	30
1	Overview of fitting locations - air conditioning system	30
1.1	Overview of fitting locations – components not located in passenger compartment	30
1.2	Overview of fitting locations - components located in front section of passenger compartment	32
2	Refrigerant circuit	35
2.1	System overview - refrigerant circuit	35
2.2	Assembly overview – condenser	37
2.3	Removing and installing refrigerant circuit pressure sender G805	39
2.4	Removing and installing expansion valve	41
2.5	Removing and installing condenser	44
2.6	Removing and installing desiccant bag or cartridge	47
2.7	Removing and installing refrigerant line with internal heat exchanger	57
2.8	Removing and installing evacuating and charging valves on low and high-pressure side	60
2.9	Removing and installing refrigerant line from condenser to evaporator	62
2.10	Removing and installing refrigerant line from air conditioner compressor to condenser	65
2.11	Removing and installing refrigerant line from evaporator to air conditioner compressor	67
2.12	Commissioning air conditioning system after filling refrigerant circuit	70
3	Air conditioner compressor	71
3.1	Assembly overview – drive unit of air conditioner compressor	71
3.2	Assembly overview - pulley	75
3.3	Removing air conditioner compressor from and installing on bracket	82
3.4	Removing and installing air conditioner compressor	84
3.5	Checking high-pressure safety valve on air conditioner compressor	89
3.6	Removing and installing pulley	90
4	Control motors	99
4.1	Overview of fitting locations – control motors at front	99
4.2	Removing and installing temperature flap control motor V68 with potentiometer G92	105
4.3	Removing and installing defroster flap control motor V107 with potentiometer G135	108
4.4	Removing and installing air recirculation flap control motor V113	112
4.5	Removing and installing left temperature flap control motor V158 with potentiometer G220	116
4.6	Removing and installing right temperature flap control motor V159 with potentiometer G221	120
4.7	Removing and installing rear temperature flap control motor V137	124
4.8	Removing and installing fresh air/air recirculation, air flow flap control motor V425 with potentiometer G644	126
4.9	Removing and installing front air distribution flap control motor V426 with potentiometer for front air distribution flap control motor G642	130
4.10	Removing and installing air distribution flap control motor V428	134
4.11	Removing and installing air distribution flap actuator	139
5	Front heater and air conditioning unit	146
5.1	Assembly overview – heater and air conditioning unit	146
5.2	Assembly overview - add-on parts of heater and air conditioning unit and of air intake box	152
5.3	Assembly overview – evaporator housing	154
5.4	Assembly overview - flaps and partitions in air distribution housing	155
5.5	Removing and installing heater and air conditioning unit	158
5.6	Dismantling and assembling heater and air conditioning unit	163
5.7	Removing and installing air distribution housing	164
5.8	Removing and installing bracket for heater and air conditioning unit	165



5.9	Removing and installing evaporator	167
5.10	Removing and installing fresh air blower control unit J126	168
5.11	Removing and installing dust and pollen filter	170
5.12	Removing and installing fresh air blower V2	174
5.13	Checking auxiliary air heater element Z35	177
5.14	Removing and installing auxiliary air heater element Z35	179
5.15	Removing and installing heat exchanger	181
5.16	Removing and installing coolant pipes on heat exchanger	201
5.17	Removing and installing evaporator temperature sensor G308	205
5.18	Checking condensation drain	207
5.19	Removing and installing condensation drain	209
6	Air duct	214
6.1	Assembly overview – air duct and air distribution in passenger compartment	214
6.2	Removing and installing fresh air intake	215
6.3	Removing and installing cover for fresh air intake	217
6.4	Removing and installing intake duct	218
6.5	Removing and installing driver side footwell vents	219
6.6	Removing and installing front passenger side footwell vents	221
6.7	Removing and installing rear footwell vent	222
6.8	Removing and installing air duct for rear centre console vent	223
6.9	Removing and installing air duct for rear centre console vent	224
6.10	Checking forced ventilation for passenger compartment	225
6.11	Removing and installing forced ventilation for passenger compartment	225
6.12	Removing and installing air duct for defroster vent	226
6.13	Removing and installing air duct for centre vent	227
7	Operating and display unit	229
7.1	Overview of operating and display unit	229
7.2	Removing and installing operating and display unit	234
8	Other controlling and regulating components	238
8.1	Removing and installing sunlight penetration photosensor G107	238
8.2	Removing and installing air quality sensor G238	239
8.3	Removing and installing ambient temperature sensor G17	241
8.4	Removing and installing humidity sender for air conditioning system G260	241
8.5	Removing and installing left vent temperature sender G150	242
8.6	Removing and installing right vent temperature sender G151	244
8.7	Removing and installing rear vent temperature sender G174	247
8.8	Removing and installing footwell vent temperature sender G192	247