Contents

00 - Technical data 1
1 **Brakes** 1
1.1 Brake variants and their assignment 1
1.2 Brake fluid 13

45 - Anti-lock brake system 15
1 **Antilock braking system (ABS)** 15
1.1 Instructions for repair work on Antilock braking system 15
1.2 Distinguishing features of the ABS systems 16
1.3 Basic information on fault finding and on repairs 17
1.4 Distinguishing features of the control units for ABS and ESP BOSCH 8.0 18
2 **Perform self-diagnosis - ABS BOSCH 8.0** 20
2.1 Test conditions 20
2.2 Connecting vehicle diagnosis, measurement and information system VAS and selecting function (ABS system BOSCH 8.0) 20
3 **Basic setting of the ABS system** 22
3.1 Basic setting - ABS BOSCH 8.0 22
3.2 Basic setting - ABS BOSCH 8.2 22
3.3 Basic setting - ABS/TCS/ESP BOSCH 8.2i 22
3.4 Null balance of the steering angle sender G85 (vehicles with ABS/TCS/ESP BOSCH 8.0 and ABS/TCS/ESP BOSCH 8.2i) 22
3.5 Performing ESP road and system test (vehicles with ABS/TCS/ESP BOSCH 8.0) 23
4 **Electric/electronic components and fitting locations ABS/ESP** 24
4.1 Overview - electric/electronic components and fitting locations ABS/ESP BOSCH 8.0 . . 24
4.2 Electric/electronic components and fitting locations ABS/ESP BOSCH 8.0 27
4.3 Electric/electronic components and fitting locations ABS/EDL/TCS/ESP BOSCH 8.2i 28
5 **Indication of faults by means of warning lights** 30
5.1 ABS/TCS/ESP BOSCH 8.0 30
5.2 ABS BOSCH 8.2/8.2i 34
6 **Hydraulic control unit (ABS systems BOSCH 8.0), brake servo unit/master brake cylinder** 37
6.1 Summary of components of control unit, brake servo unit and master brake cylinder 37
6.2 Removing and installing hydraulic control unit ABS BOSCH 8.0 - left-hand drive 40
6.3 Removing and installing hydraulic control unit ABS BOSCH 8.0 - vehicles - right-hand drive 44
6.4 Removing and installing the ABS control unit bracket BOSCH 8.0 48
6.5 Connect the brake lines 52
7 **Removing and installing parts of the ABS System on the front and rear axle** 54
7.1 Removing and installing the ABS speed sensor on the front axle 54
7.2 Removing and installing front wheel speed sensor cables - Vehicles with ABS BOSCH 8.0 56
7.3 Removing and installing the ABS speed sensor on the rear axle - vehicles up to 11/2012. 60
7.4 Removing and installing the ABS speed sensor on the rear axle - vehicles as of 11/2012. 62
7.5 Repairing rear ABS wheel speed sensor cables - Vehicles with ABS BOSCH 8.0 64
8 **Removing and installing parts of the ESP System** 66
8.1 Removing and installing sensor unit for ESP G419 66
8.2 Removing and installing steering angle sender G85 69
9 **ABS BOSCH 8.2** 70
9.1 Summary of Components of Hydraulic Control Unit, Brake Servo Unit/Master Brake Cylinder ABS BOSCH 8.2 - left-hand drive 70

9.2 Connection of the brake lines from the master brake cylinder to the hydraulic unit ABS BOSCH 8.2 - left-hand drive . . . 72
9.3 Removing and installing control unit and hydraulic unit ABS BOSCH 8.2 - left-hand drive . . . 72
9.4 Summary of Components of Hydraulic Control Unit, Brake Servo Unit/Master Brake Cylinder ABS BOSCH 8.2 - right-hand drive . . . 74
9.5 Connection of the brake lines from the master brake cylinder to the hydraulic unit ABS BOSCH 8.2 - right-hand drive . . . 76
9.6 Removing and installing control unit and hydraulic unit ABS BOSCH 8.2 - right-hand drive . . . 76
10 ABS/EDL/TCS/ESP BOSCH 8.2i . . . 80
10.1 Summary of Components of Hydraulic Control Unit, Brake Servo Unit/Master Brake Cylinder ABS/EDL/TCS/ESP BOSCH 8.2i - left-hand drive . . . 80
10.2 Connection of the brake lines from the master brake cylinder to the hydraulic unit ABS/EDL/TCS/ESP BOSCH 8.2i - left-hand drive . . . 82
10.3 Remove and install control unit and hydraulic unit ABS/EDL/TCS/ESP BOSCH 8.2i - left-hand drive . . . 82
10.4 Summary of Components of Hydraulic Control Unit, Brake Servo Unit/Master Brake Cylinder ABS/EDL/TCS/ESP BOSCH 8.2i - right-hand drive . . . 85
10.5 Connection of the brake lines from the master brake cylinder to the hydraulic unit ABS/EDL/TCS/ESP BOSCH 8.2i - right-hand drive . . . 87
10.6 Remove and install control unit and hydraulic unit ABS/EDL/TCS/ESP BOSCH 8.2i - right-hand drive . . . 88

46 - Brakes - mechanism . . . 92
1 Repairing front wheel brake . . . 92
1.1 Changing the brake pads of the front brake - Mounting instructions . . . 92
1.2 Repairing front wheel brake - Floating caliper disc brake FS-III . . . 92
1.3 Removing and installing brake pads and floating caliper disc brake FS-III . . . 94
1.4 Repairing front wheel brake - Floating caliper disc brake C54 . . . 99
1.5 Removing and installing brake pads and floating caliper disc brake C54 . . . 102
1.6 Repairing front wheel brake, brake caliper FN3 . . . 105
1.7 Removing and installing brake pads for brake caliper FN3 . . . 106
1.8 Removing and installing brake caliper FN3 . . . 109
2 Repairing rear brake . . . 112
2.1 Replacing the brake shoes of the rear brake - Mounting instructions . . . 112
2.2 Removing and installing rear brake - Drum brake up to 44.2012 . . . 112
2.3 Repairing rear brake - Drum brake up to 44.2012 . . . 114
2.4 Removing and installing brake shoes - Drum brake up to 44.2012 . . . 116
2.5 Removing and installing rear brake - Drum brake from 45.2012 . . . 120
2.6 Repairing rear brake - Drum brake from 45.2012 . . . 123
2.7 Removing and installing brake shoes - Drum brake from 45.2012 . . . 126
2.8 Testing wheel-brake cylinder for tightness . . . 131
2.9 Changing the brake pads of the rear wheel disc brake - Mounting instructions . . . 131
2.10 Removing and installing rear brake - Disc brake . . . 131
2.11 Removing and installing brake pads - Rear disc brake . . . 133
3 Handbrake . . . 138
3.1 Assembly overview of the handbrake . . . 138
3.2 Removing and installing the hand-brake cable . . . 139
3.3 Setting the hand-brake . . . 142
4 Foot Controls, Brake Pedal . . . 144
4.1 Summary of components of foot controls, brake pedal up to MY 2010 . . . 144
4.2 Setting, removing and installing the brake light switch F and brake pedal switch F47 up to MY 2010 . . . 146
4.3 Separating the brake pedal from the brake servo unit and clipping up to MY 2010 . . . 146
4.4 Removing and installing the foot controls up to MY 2010 - left-hand drive . . . 147
4.5 Removing and installing the pedals up to MY 2010 - left-hand drive . . . 151
4.6 Removing and installing the pedals up to MY 2010 - right-hand drive . . . 154

4.7 Summary of components: Brake pedal from MY 2011 - left-hand drive . . . 157
4.8 Separating the brake pedal from the brake servo unit and clipping as of MY 2011 . . . 157
4.9 Removing and installing the foot controls from MY 2011 - left-hand drive . . . 158
4.10 Removing and installing the brake pedal from MY 2011 - left-hand drive . . . 159
4.11 Summary of components: Brake pedal from MY 2011 - right-hand drive . . . 159
4.12 Removing and installing the foot controls from MY 2011 - right-hand drive . . . 161
4.13 Removing and installing the brake pedals from MY 2011 - right-hand drive . . . 161

47 - Brakes - hydraulics . . . 163

1 Repairing brake caliper . . . 163
1.1 Summary of components of the brake caliper of the FS-III brake at the front . . . 163
1.2 Removing and installing brake caliper piston of front FS-III brake . . . 164
1.3 Summary of components of the brake caliper of the C54 brake at the front . . . 166
1.4 Removing and installing brake caliper piston of front C54 brake . . . 167
1.5 Repairing brake caliper FN3 . . . 167
1.6 Removing and installing brake caliper piston FN3 . . . 167
1.7 Summary of components of the brake caliper of the brake at the rear . . . 170
1.8 Removing and installing brake caliper piston of rear brake . . . 171

2 Brake Servo Unit, Master Brake Cylinder . . . 173
2.1 Summary of components of brake servo unit, master brake cylinder up to MY 2010 . . . 173
2.2 Summary of components of brake servo unit, master brake cylinder as of MY 2011 - left-hand drive . . . 176
2.3 Summary of components of brake servo unit, master brake cylinder as of MY 2011 - right-hand drive . . . 177
2.4 Brake light switch F as of MY 2011 . . . 178
2.5 Checking the master brake cylinder for tightness . . . 179
2.6 Removing and installing master brake cylinder - left-hand drive . . . 181
2.7 Removing and installing master brake cylinder - right-hand drive . . . 185
2.8 Removing and installing brake servo unit - left-hand drive . . . 189
2.9 Removing and installing brake servo unit - right-hand drive . . . 191
2.10 Checking the non-return valve . . . 192
2.11 Removing and installing tandem pump for fuel and vacuum supply . . . 192
2.12 Removing and installing the vacuum pump for the vacuum supply . . . 193

3 Checking vacuum system . . . 194
3.1 Connecting vacuum gauge for brake servo VAS 6721 . . . 194
3.2 Checking vacuum generation . . . 195
3.3 Checking for leaks . . . 195
3.4 Vacuum generation with manual vacuum pump VAS 6213 . . . 197

4 Bleeding brake system . . . 198
4.1 Bleeding the hydraulic unit (vehicles with ESP) . . . 198
4.2 Bleeding the brake system using the brake filling and bleeding device , e.g. VAS 5234 VAS 5234 . . . 199
4.3 Bleeding the brake system of air without using the brake filling and bleeding device . . . 200
4.4 Change brake fluid . . . 201

5 Brake-power regulator . . . 202
5.1 Summary of components of brake-power regulator . . . 202
5.2 Inspecting, setting brake-power regulator and adjusting values . . . 203
5.3 Removing and installing brake-power regulator . . . 206