

Contents

69 - Passenger protection	1
1 Overview of retrofitting options	1
2 Notes and overview of components	2
2.1 General information	2
2.2 Overview of components	3
3 Deactivating/activating airbag on front passenger side (Audi A2 2001 ▶)	8
4 Retrofitting key-operated switch (Audi A3 1997 ▶ from week 27/1999 onwards)	9
4.1 Removing glove box	9
4.2 Installing key-operated switch	10
4.3 Installing new glove box	11
4.4 Installing warning lamp for airbag deactivated on front passenger side	12
5 Retrofitting key-operated switch (Audi A3 2004 ▶ including Audi A3 Sportback and Audi A3 Cabriolet 2008 ▶)	14
5.1 Removing and installing glove box	14
5.2 Converting glove box	16
5.3 Routing and securing glove box wiring harness	17
5.4 Installing key-operated switch	17
5.5 Installing warning lamp for airbag deactivated on front passenger side	18
6 Retrofitting key-operated switch (Audi A4 1995 ▶ from chassis no. 8DXA 200 001 onwards)	24
6.1 Removing glove box	24
6.2 Converting glove box	25
6.3 Installing key-operated switch	26
6.4 Installing glove box	26
6.5 Installing warning lamp for airbag deactivated on front passenger side	27
7 Retrofitting key-operated switch (Audi A4 2001 ▶ up to week 35/2004 including Audi S4 and Audi S4 Cabriolet)	29
7.1 Removing glove box	29
7.2 Converting glove box	31
7.3 Installing key-operated switch	31
7.4 Retrofitting wiring harness	32
7.5 Installing glove box	32
7.6 Installing warning lamp for airbag deactivated on front passenger side	33
8 Retrofitting key-operated switch (Audi A4 2001 ▶ from week 36/2004 onwards including Audi S4 and Audi S4 Cabriolet)	39
8.1 Removing glove box	39
8.2 Converting glove box	41
8.3 Installing key-operated switch	41
8.4 Retrofitting wiring harness	41
8.5 Installing glove box	41
8.6 Installing warning lamp for airbag deactivated on front passenger side	43
9 Retrofitting wiring harnesses 8E1 970 XXX (Audi A4 2001 ▶)	45
9.1 Notes on and preparation for retrofitting wiring harnesses (8E1 970 XXX)	45
9.2 Routing wiring harnesses (8E1 970 XXX)	46
9.3 Connecting wiring harnesses 8E1 970 XXX to multi-pin connector for airbag control unit J234	50
9.4 Assembly work, coding airbag control unit J234 and interrogating fault memories of control units	55
10 Retrofitting key-operated switch (Audi A4 Cabriolet 2003 ▶)	57
11 Retrofitting key-operated switch (Audi A6 1998 ▶ from week 36/1998 onwards including Audi Allroad, except vehicles with V8 engine)	58
11.1 Removing glove box	58



11.2	Converting glove box	59
11.3	Installing key-operated switch	60
11.4	Installing glove box	60
11.5	Installing warning lamp for airbag deactivated on front passenger side	62
12	Retrofitting key-operated switch (Audi A6 2005 ▶)	64
12.1	Removing glove box	64
12.2	Converting glove box	66
12.3	Installing glove box	68
12.4	Installing warning lamp for airbag deactivated on front passenger side	69
13	Retrofitting key-operated switch (Audi A8 1994 ▶, gradual introduction from approx. week 41/1998 onwards, with front and side or front and curtain airbag)	73
13.1	Removing glove box	73
13.2	Converting glove box	74
13.3	Installing key-operated switch	75
13.4	Installing glove box	76
13.5	Installing warning lamp for airbag deactivated on front passenger side	77
14	Retrofitting key-operated switch (Audi A8 2003 ▶)	79
14.1	Removing glove box	79
14.2	Converting glove box	82
14.3	Installing key-operated switch	82
14.4	Installing glove box	82
14.5	Installing warning lamp for airbag deactivated on front passenger side	83
14.6	Installing trim panel with switch module (right-side) with warning lamp for airbag deactivated on front passenger side	84
15	Retrofitting key-operated switch (Audi TT 1999 ▶, Coupé/Roadster)	85
16	Coding airbag control unit J234	86
17	Adapting airbag control unit J234 (Audi A6 2005 ▶)	87