



Contents

50 - Body - Front section	1
1 Body - front section	1
1.1 Front end with complementary parts - assembly overview	1
1.2 Front end with complementary parts - remove and install	2
1.3 Front end - service position	3
1.4 Front wing - assembly overview	4
1.5 Engine compartment upper partition panel - replacing	6
1.6 Spare wheel mechanism - assembly overview	8
55 - Bonnets	9
1 Bonnet	9
1.1 Assembly overview	9
1.2 Bonnet - remove and install	10
1.3 Bonnet - adjust	10
1.4 Bonnet hinge - remove and install	11
1.5 Bonnet latch operation cable - assembly overview	13
1.6 Bonnet latch Bowden cable - remove and install	13
1.7 Bonnet upper latch - remove and install	16
1.8 Bonnet lower latch - remove and install	16
2 Rear lid (Gol)	17
2.1 Assembly overview	17
2.2 Rear lid shock absorber - remove	18
2.3 Rear lid shock absorber - remove the gas	19
2.4 Rear lid trim - remove and install	19
2.5 Rear lid - remove and install	20
2.6 Rear lid hinge - remove and install	21
2.7 Rear lid - adjust	23
2.8 Housing with latch cylinder - assembly overview	26
2.9 Housing with Latch cylinder - remove and install	26
2.10 Latch cylinder - remove and install	28
2.11 Cylinder - assembly and disassembly	28
2.12 Door latch - remove and install	29
2.13 Rear lid unlocking motor V139 - remove and install	31
3 Rear lid (Voyage)	32
3.1 Assembly overview	32
3.2 Rear lid trim - remove and install	33
3.3 Rear lid - remove and install	34
3.4 Rear lid hinge - remove and install	36
3.5 Rear lid - adjust	38
3.6 Housing with latch cylinder - assembly overview	41
3.7 Housing with Latch cylinder - remove and install	41
3.8 Latch cylinder - remove and install	43
3.9 Latch cylinder - disassemble and assemble	43
3.10 Door latch - remove and install	43
3.11 Rear lid unlocking motor V139 - remove and install	44
4 Tailgate (Saveiro)	45
4.1 Tailgate buffer (►CP 122368) - adjust	45
4.2 Tailgate buffer (CP 122369 ►) - adjust	46
4.3 Tailgate lock (►CP 122368) - remove and install	47
4.4 Tailgate lock (CP 122369 ►) - remove and install	50
4.5 Rod driver - remove and install	53
4.6 Tailgate handle with cylinder - remove and install	56
4.7 Tailgate sustaining cable - remove and install	57



4.8	Latch cylinder - remove and install	60
4.9	Latch cylinder - disassemble and assemble	60
4.10	Tailgate damper - remove and install	60
4.11	Cargo cover damper - replace	62
4.12	Tailgate - remove and install	63
4.13	Tailgate - adjust	65
4.14	Bucket sealing membrane - remove and install	65
5	Fuel reservoir nozzle compartment and lid set	68
5.1	Fuel reservoir nozzle compartment lid (Gol and Voyage) - remove and install	68
5.2	Fuel reservoir nozzle compartment lid (Saveiro) - remove and install	69
57	Front doors/components/central lock	70
1	Front door	70
1.1	Tools	70
1.2	Assembly overview	71
1.3	Door - remove and install	72
1.4	Door - adjust	74
1.5	Door - disassemble and assemble	77
1.6	Door - replace	77
1.7	Front door arrester - adjust	77
1.8	Door limiter - remove and install	78
1.9	Internal handle - replace	79
1.10	Front door external handle and lock - assembly overview	80
1.11	Lock cylinder housing - remove and install	81
1.12	Latch cylinder - remove and install	82
1.13	Latch cylinder - disassemble and assemble	83
1.14	Door handle - remove and install	83
1.15	External door handle - replace	85
1.16	Door lock (► 02.09) - remove and install	85
1.17	Door lock (Saveiro , Gol, Voyage 03.09 ►) - remove and install	87
1.18	Lock button (locking rod) - remove and install	89
1.19	Door lock - replace	90
1.20	Lock Bowden cable - replace	90
1.21	Door sealing membrane - remove and install	91
1.22	Internal door trim - remove and install	93
2	Central locking	94
2.1	Central locking installation locations overview	95
2.2	Central control unit for convenience system J393 - remove	96
2.3	Battery of key with radio remote command (articulated) - remove and install	97
2.4	Adapting radio-commanded keys to centre control unit for convenience system J393	99
2.5	Key - synchronize	100
58	Rear passenger doors/components	101
1	Rear passenger doors	101
1.1	Rear passenger doors - assembly overview	101
1.2	Door - remove and install	102
1.3	Door - adjust	103
1.4	Rear passenger door - disassemble and assemble	105
1.5	Door - replace	105
1.6	Rear door arrester - adjust	106
1.7	Door limiter - remove and install	106
1.8	Internal handle - replace	108
1.9	Rear door external handle and lock - assembly overview	108
1.10	External handle housing - remove and install	109
1.11	External door handle - remove and install	110
1.12	External door handle - replace	112



1.13	Door lock - remove and install	112
1.14	Door lock - replace	116
1.15	Lock button (locking rod) - remove and install	116
1.16	Lock Bowden cable - replace	117
1.17	Door sealing membrane - remove and install	117
1.18	Internal door trim - remove and install	119
61	Folding cover/removable cover/canvas	121
1	Tonneau cover (Saveiro)	121
1.1	Assembly overview	121
1.2	Tonneau cover - remove and install	122
63	Bumpers	125
1	Front bumper	125
1.1	Front protector - assembly overview	125
1.2	Front protector - remove and install	125
1.3	Front protector support - assembly overview	128
2	Rear bumper (Gol)	129
2.1	Rear protector - assembly overview	129
2.2	Rear protector - remove and install	129
2.3	Rear protector support (► 03.11) - assembly overview	132
2.4	Foamed rear protector support (04.11 ►) - assembly overview	133
3	Rear bumper (Voyage)	134
3.1	Rear protector - assembly overview	134
3.2	Rear protector - remove and install	134
3.3	Rear protector support (► 03.11) - assembly overview	137
3.4	Foamed rear protector support (04.11 ►) - assembly overview	138
4	Rear bumper (Saveiro)	139
4.1	Support and side protector - assembly overview	139
4.2	Side protector - remove and install	139
4.3	Support and central protector - assembly overview	141
4.4	Central protector - remove and install	142
64	Windows	144
1	Glasses glued with adhesive	144
1.1	Tools	144
1.2	Auxiliary materials - Brazilian market	145
1.3	Auxiliary materials for the export market	146
1.4	Matching table	146
1.5	Stickers for engraving the VIS number on the windows (only for Brazil) - supply	146
1.6	Windscreen - assembly overview	147
1.7	Windscreen - remove	148
1.8	Windscreen - install	148
1.9	Rear window (Gol) - assembly overview	149
1.10	Undamaged rear window (Gol) - remove	149
1.11	Damaged rear window (Gol) - remove	150
1.12	Rear window (Gol) - install	151
1.13	Rear window (Voyage) - assembly overview	151
1.14	Undamaged rear window (Voyage) - remove	151
1.15	Damaged rear window (Voyage) - remove	152
1.16	Rear window (Voyage) - install	153
1.17	Rear door fixed window - assembly overview	153
1.18	Undamaged fixed rear door window - remove	154
1.19	Damaged fixed rear door window - remove	154
1.20	Fixed rear door window - install	154



1.21	Fixed rear side window (Saveiro) - assembly overview	155
1.22	Undamaged fixed rear side window (Saveiro) - remove	155
1.23	Damaged fixed rear side window (Saveiro) - remove	156
1.24	Fixed rear side window (Saveiro) - install	157
1.25	Fixed rear side window (Saveiro - single cab) - assembly overview	157
1.26	Fixed rear window (Saveiro - extended cab) - assembly overview	158
1.27	Sliding rear window (Saveiro - single cab) - assembly overview	159
1.28	Sliding rear window (Saveiro - extended cab) - assembly overview	160
1.29	Undamaged fixed or sliding rear window (Saveiro) - remove	160
1.30	Rear fixed or sliding window (Saveiro) - install	162
1.31	Undamaged glass - prepare for install	163
1.32	New glass - prepare for install	163
1.33	Body flange - prepare to install the window	164
1.34	Assembly instructions	164
1.35	Minimum adhesive drying time	166
1.36	Paint damage - repair	166
1.37	Cleaning in case of resulting adhesive residues	166
2	Door window glass	168
2.1	Front door window glass - assembly overview	168
2.2	Front door window glass - remove and install	168
2.3	Convenience system window drive mechanism (automatic window closing and opening mechanism) with force limiter (anti-crushing function)	169
2.4	Window drive mechanism - remove and install	171
2.5	Driver/passenger window control motor V147 / V148 - remove and install	172
2.6	Front door window crank - remove and install	173
2.7	Front door window channel - remove and install	173
2.8	Front door window internal trim - remove and install	174
2.9	Front door window external trim - replace	174
2.10	Rear door window glass - assembly overview	175
2.11	Rear door window glass - remove and install	175
2.12	Rear door window drive mechanism - remove and install	176
2.13	Left/right rear window control motor V26 / V27 - remove and install	177
2.14	Rear door window drive crank - remove and install	178
2.15	Rear door window channel - remove and install	178
2.16	Rear door window internal trim - remove and install	179
2.17	Rear door window external trim - replace	179
66	External equipment	180
1	Materials used and operational care required	180
1.1	Auxiliary materials for Brazilian market	180
1.2	Auxiliary materials for export market	180
1.3	Matching table	180
1.4	Paint damage - repair	181
1.5	Cleaning in case of dirt residues resulting from handling of polyurethane adhesive (PU)	181
1.6	Minimum adhesive drying time	181
2	Wheel arch protector	182
2.1	Front wheel arch protector - remove and install	182
2.2	Rear wheel arch protector - remove and install	183
3	External rearview mirror	184
3.1	External rearview mirror - assembly overview	184
3.2	External rearview mirror - assembly overview - continued	185
3.3	Exterior rearview mirror - remove and install	185
3.4	Mirror glass - remove and install	186
3.5	Mirror glass - remove and install	187
3.6	Turn signal (Blinker) - remove and install	188



4	External linings	189
4.1	Lower windscreen covering - assembly overview	189
4.2	Lower windscreen covering - remove and install	190
4.3	External linings on pillars and doors - replace	191
4.4	External B-pillar coverings (Saveiro - single cab) - replace	193
4.5	Footwell cover (Saveiro) - replace	195
5	Internal covering	197
5.1	Front wing side cover - remove and install	197
6	Side trims, roof	198
6.1	Side trims (Gol ► BT 003067 and Voyage ► AT 255034) - replace	198
6.2	Side trims (Gol BT 003068 ► and Voyage AT 255035 ►) - replace	200
6.3	Side trims (Saveiro Cross) - Assembly overview	202
6.4	Front door trim (Saveiro Cross) - replace	202
6.5	Rear side panel trim (Saveiro Cross) - replace	205
6.6	Decorative side stripe (Saveiro Trooper) - replace	208
6.7	Decorative stripe on the front and rear door (Gol Rallye) - replace	209
6.8	Decorative stripe on the front and rear door (Gol Rock in Rio) - replace	212
6.9	Decorative stripe on the front and rear door (Gol Rock in Rio) - replace	213
6.10	Rear cover trim (Voyage) - replace	214
6.11	Roof trim (► 07.08 - Gol and Voyage) - assembly overview	216
6.12	Roof trim (08.08 ► - Gol e Voyage) - assembly overview	217
6.13	Roof lining (Saveiro) - remove and install	218
6.14	Rear protector fixed window (Gol) - replace	219
6.15	Rear protector fixed window (Gol Vintage) - replace	221
6.16	Front protector fixed window (Gol Vintage) - replace	223
6.17	Decorative stripe and side lettering (Gol Vintage) - replace	226
7	Side member trim	231
7.1	Longitudinal member lower trim (Saveiro Cross) - assembly overview	232
7.2	Longitudinal member lower trim (Saveiro Cross) - replace	232
7.3	Longitudinal lower trim (Gol Rallye) - general overview of assembly	236
7.4	Longitudinal lower trim (Gol Rallye) - replace	236
8	Rear wing and side panel trim (Saveiro)	241
8.1	Front protector trim (Saveiro) - replace	241
8.2	Front protective trim (Gol Rallye) - remove and install	243
8.3	Front wing trim (Saveiro) - assembly overview	246
8.4	Front bumper trim (Saveiro) - replace	247
8.5	Front wing trim (Saveiro Cross) - assembly overview	249
8.6	Front wing trim (Saveiro Cross) - replace	249
8.7	Front wing trim (Gol Rallye) - replace	252
8.8	Rear side panel trim (Saveiro) - assembly overview	257
8.9	Rear side panel trim (Saveiro) - replace	257
8.10	Rear side panel trim (Saveiro Cross) - assembly overview	260
8.11	Rear side panel trim (Saveiro Cross) - replace	260
8.12	Rear side panel trim (Gol Rallye) - replace	263
8.13	Rear side protector trim (Saveiro) - replace	267
8.14	Front protective trim (Gol Rallye) - remove and install	269
9	Cargo compartment and frames protector (Saveiro)	273
9.1	Upper tailgate frame - replace	273
9.2	Cargo compartment upper frame - replace	274
9.3	Cargo compartment protection grid - remove and install	278
9.4	External B-pillar frame - replace	279
9.5	Rear window glass upper and lower frame - remove and install	282
9.6	Bedliner - remove and install	284
9.7	Cargo tying adjustable hooks track (vehicle without tonneau cover) - remove and install ..	287
9.8	Cargo tying adjustable hooks track (vehicle with tonneau cover) - remove and install .. .	288



9.9	Cargo compartment adjustable hooks - remove and install	290
10	Front grid, front protector grids, rear protector frames	291
10.1	Front grid and front protector grids - assembly overview	291
10.2	Front spoiler (Saveiro Cross and Gol Rallye) - replace	292
10.3	Front protector central grid (Saveiro Cross and Gol Rallye) - replace	294
10.4	Front protector side grid (Saveiro Cross and Gol Rallye) - remove and install	296
10.5	Lower rear protector frame (Saveiro Cross) - replace	298
10.6	Lower rear side protector frame (Saveiro Cross) - replace	301
10.7	Rear spoiler (Gol) - replace	303
11	Badges	306
11.1	Volkswagen Badge - replace	306
11.2	Model badge (Gol) - replace	307
11.3	Model badge (Voyage) - replace	307
11.4	(1.6 - Gol) version distich - replace	308
11.5	(1.6 - Voyage) version badge - replace	308
11.6	„Total flex“ badge - remove and install	309
11.7	Version badge (on door - Gol and Voyage) - replace	310
11.8	„TREND“ Badge (Saveiro) - replace	311
11.9	Sticker „I Trend“ (Gol 2012) - replace	312
11.10	Badge „Gol 25 anos“ on front wing - replace	313
11.11	Badge „Gol 25 anos“ on rear window - replace	315
11.12	„Saveiro“ Badge and „VW“ badge on tailgate - replace	316
11.13	„Saveiro Cross“ Badge and on tailgate - replace	318
11.14	„Seleção“ Badge (Gol Seleção) - replace	319
11.15	„Seleção“ Side Badge (Gol Seleção) - replace	320
11.16	Lettering „Rallye“ (Gol Rallye) - replace	321
11.17	Side lettering of the front wing (Gol Vintage) - replace	321
11.18	Lettering model „Vintage“ (Gol Vintage) - replace	322
11.19	Sticker „Rock in Rio“ (Gol Rock in Rio) - replace	323
11.20	„Blackgol“ badge on front door (Gol Blackgol) - replace	325
11.21	„Blackgol“ badge on rear lid (Gol Blackgol) - replace	326
12	Roof rack (Saveiro)	329
12.1	Roof rack (Single cab) - remove and install	329
12.2	Roof rack (Extended cab) - remove and install	332
12.3	Roof rack (Saveiro Cross) - remove and install	336
12.4	Roof rack extensor (Saveiro Cross) - remove and install	340
12.5	Roof rack extensor cover (Saveiro Cross) - remove and install	343
12.6	Cargo compartment rack (Saveiro Cross) - remove and install	344
13	Spoiler	348
13.1	Spoiler (Gol) - remove and install	348
13.2	Assembly overview	349
13.3	Observations for the execution of the removal and installation of the spoiler	350
13.4	Remove	350
13.5	Install	350
13.6	Spoiler (Voyage) - remove and install	352
13.7	Assembly overview	353
13.8	Observations for the execution of the removal and installation of the spoiler	354
13.9	Remove	354
13.10	Install	355
14	Saveiro Cross Components	358
14.1	Assembly overview	358
15	Gol Rallye Components	359
15.1	Assembly overview	359
16	Gol Vintage Components	360
16.1	Assembly overview	360