



## Contents

|   |           |
|---|-----------|
| <b>91 - Radio, telephone, navigation system</b> .....   | <b>1</b>  |
| <b>1 Communication Systems</b> .....  | <b>1</b>  |
| 1.1 Locating defects and indicating faults .....  | 1         |
| <b>2 Radio R</b> .....  | <b>2</b>  |
| 2.1 Radio R „Concept“ .....   | 2         |
| <b>3 CD Player R89</b> .....  | <b>10</b> |
| 3.1 "CD player" R89 „1 Din MID“ .....   | 10        |
| <b>4 Loudspeaker systems</b> .....  | <b>18</b> |
| 4.1 Front left loudspeaker for bass sounds R21 and/or Front right loudspeaker for bass sounds R23 - replacing .....         | 18        |
| 4.2 Rear left loudspeaker for bass sounds R15 and/or Rear right loudspeaker for bass sounds R17 (Gol) - replacing .....     | 18        |
| 4.3 Rear left loudspeaker for bass sounds R15 and/or Rear right loudspeaker for bass sounds R17 (Voyage) - replacing .....  | 19        |
| 4.4 Rear left loudspeaker for bass sounds R15 and/or Rear right loudspeaker for bass sounds R17 (Saveiro) - replacing ..... | 20        |
| 4.5 Left front treble speaker R20 and/or Right front treble speaker R22 (front tweeter) - replace .....                     | 21        |
| <b>5 Multifunction steering wheel</b> .....   | <b>23</b> |
| 5.1 Multifunction steering wheel - general information .....  | 23        |
| 5.2 Multifunction Steering Wheel (Version 1) - general overview of assembly .....   | 24        |
| 5.3 Command keys (Version 1) - remove and install .....   | 24        |
| 5.4 Multifunction Steering Wheel (version 2) - general overview of assembly .....   | 25        |
| 5.5 Command keys (Version 2) - remove and install .....   | 26        |
| 5.6 Multifunction steering wheel - adjust .....   | 27        |
| <b>6 Antenna system</b> .....   | <b>28</b> |
| 6.1 Antenna R11 - General overview of assembly .....  | 28        |
| 6.2 Antenna R11 - remove and install .....  | 28        |
| 6.3 Antenna cable (Gol/Voyage) - general overview of assembly .....   | 30        |
| 6.4 Antenna cable (Gol/Voyage) - remove and install .....   | 31        |
| 6.5 Antenna cable (Saveiro) - general overview of assembly .....  | 32        |
| 6.6 Antenna cable (Saveiro) - remove and install .....  | 33        |
| <b>7 Interference suppression measures</b> .....  | <b>35</b> |
| <b>8 External temperature sensor G17</b> .....  | <b>36</b> |
| 8.1 External temperature sensor G17 (Gol / Voyage) - general overview of assembly .....                                     | 36        |
| 8.2 External temperature sensor G17 - remove and install .....  | 37        |
| 8.3 External temperature sensor G17 - check .....   | 37        |
| 8.4 External temperature sensor G17 (Gol Rallye) - general overview of assembly .....                                       | 38        |
| 8.5 External temperature sensor G17 - remove and install .....  | 38        |
| 8.6 External temperature sensor G17 - check .....   | 39        |
| 8.7 Connection for external audio sources R199 (Gol Vintage) - remove and install .....                                     | 39        |