

Contents

	Page
- Survey of engines	1
Oil Change Service	9
Inspection Service	10
- Windscreen wiper and washer system and headlight washer system: adjust washer jet settings and check function	15
- Windscreen washer system: check washer jet settings and adjust if necessary	15
- Headlight washer system: check washer jet settings	18
- Wiper blades: check park position and check for damage	18
- Self-diagnosis: interrogate fault memory with fault reader V.A.G 1551	21
- Service interval display: reset	24
- Door arresters and lock cylinders: lubricate	30
- Sun roof: check function, clean guide rails and spray with lubricating spray	31
- Removing plenum chamber cover	31
- Battery: check electrolyte level and top up with distilled water if necessary	32
- Removing engine cover	34
- Engine (from above and below) and engine compartment: visual check for leaks and damage	38
- Windscreen / headlight washer system: top up fluid	39
- Cooling system: check antifreeze and top up coolant if necessary	40
- Coolant G11: Change (V8 petrol engines only)	44
- Air cleaner: clean housing and replace filter element	45
- Spark plugs: replace	47
- Hydraulic system: check for leaks, check fluid level and top up hydraulic fluid if necessary	54
- Fuel filter: replace (diesel and TDI engines)	56
- Fuel filter: drain off water (Diesel and TDI engines)	58
- Dust and pollen filter: replace	61
- Plenum chamber and water drain valves: check for dirt and clean if necessary	63
- Noise insulation: remove	64
- V-belt: check for damage and check tension; adjust tension if necessary	65
- V-belts: tensioning	66
- V-belt (not ribbed belt) for alternator: replace	70
- Ribbed belt: check for damage	72
- Ribbed belt: check tension; adjust if necessary	73
- V-belt and ribbed belt: replace (4-cyl. 5V engines)	74
- Ribbed belt: replace (V6 engines)	77
- Toothed belt for camshaft drive: check for damage and measure toothed belt width (4-cyl. TDI engines)	81
- Toothed belt for camshaft drive: check for damage and check tension (5-cylinder diesel and TDI engines)	82
- Toothed belt for injection pump: check for damage and check tension (5-cyl. TDI engines), tension toothed belt	85
- Toothed belt for camshaft drive: check for damage (2.6l 2V and 2.8l 2V engines only)	89
- Toothed belt: replace	90
- Manual gearbox/final drive: check oil level and top up if necessary	93
- Final drive (automatic gearbox): check oil level and top up if necessary	100
- Engine oil: drain or extract, change oil filter	104
- Brake system: visual check for leaks and damage	107
- Brake pads: check thickness	108
- Underseal: visual check for damage	112
- Track rod ends: check play, attachment and protective boots	112
- Tyres: check and correct condition, wear pattern, tread depth and inflation pressures	113
- Wheel bolts: tighten to specified torque	115
- Engine oil: fill	118
- Engine: check oil level	122
- Automatic gearbox: change ATF (except 01N gearbox)	123
- Idling speed: check and adjust if necessary (2.4 ltr diesel AAS only)	142
- Brake fluid level (depending on brake pad wear): checking	144
- Brake fluid: change brake fluid (every 24 months)	146
- Headlights: check settings and adjust if necessary	150
- Test drive: perform	154
- Vehicle data sticker	155
- Engine code and engine number	158
Lifting the vehicle	162
Tow-starting/towing	164
- Arbeitsabläufe Benzinmotoren	169
- Arbeitsabläufe Dieselmotoren	170

- Abgasuntersuchung Deutschland	171
- Arbeitsabläufe Benzinmotoren	172
- Störgröße vorbereiten	173
- Prüfgeräte	177
- Prüfablauf	179
- Prüfung mit Fehlerspeicher-Abfrage (V.A.G 1551) zur Lambda-Regelkreisprüfung	189
- Prüfung ohne Fehlerspeicher-Abfrage (V.A.G 1551) zur Lambda-Regelkreisprüfung	190
- Arbeitsablauf Dieselmotoren	231
- Prüfgeräte	232
- Prüfablauf	235