

## Contents

<b>20</b>	<b>Fuel supply system</b> .....	<b>1</b>
1	<b>Notes on performing work on fuel supply system</b> .....	1
1.1	Notes on performing work on fuel supply system .....	1
1.2	Safety precautions when working on fuel supply system .....	1
1.3	Rules for cleanliness .....	1
2	<b>Fuel supply system</b> .....	1
2.1	Fuel supply system .....	1
2.2	Exploded view of components: Fuel tank with attachments .....	2
2.3	Draining fuel tank .....	7
2.4	Removing and installing fuel tank with attachments .....	10
2.5	Exploded view of components: Fuel gauge sender .....	14
2.6	Checking fuel gauge sender -G .....	16
2.7	Removing and installing fuel gauge sender -G .....	18
3	<b>Servicing fuel filter</b> .....	20
3.1	Servicing fuel filter .....	20
3.2	Removing and installing fuel filter .....	22
4	<b>Bleeding fuel system - Vehicles with TDI engine</b> .....	24
4.1	Bleeding fuel system - Vehicles with TDI engine .....	24
5	<b>Checking fuel system for leaks</b> .....	26
5.1	Checking fuel system for leaks .....	26
6	<b>Servicing accelerator mechanism</b> .....	28
6.1	Servicing accelerator mechanism .....	28
6.2	Removing, installing and adjusting throttle cable - Vehicles with TD engine .....	28
6.3	Removing, installing and adjusting cable for cold starting aid - Vehicles with TD engine ..	31
6.4	Accelerator mechanism - Vehicles with TDI engine .....	32
6.5	Installing and adjusting accelerator position sender -G79 - Vehicles with TDI engine .....	33