

001 - Basic equipment and Audi A3 (1,8 l litre fuel injection engine, 92 kW, Motronic, 4-cylinder) engine codes AGN	1-26
1. Basic equipment and Audi A3 (1,8 l litre fuel injection engine, 92 kW, Motronic, 4-cylinder) engine codes AGN	1-3
2. Earth connections	4
3. Earth connections	5
4. Battery, starter, alternator, main fuse box/battery	6
5. Motronic control unit, fuel pump relay, injectors, ignition system, Hall sender	7
6. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	8
7. Motronic control unit, throttle valve control unit, ambient temperature sensor	9
8. Motronic control unit, lambda probe, air mass meter, inlet camshaft timing adjustment valve, activated charcoal filter system solenoid valve	10
9. Ignition/starter switch, X contact relief relay	11
10. Lighting switch, steering column switch - left	12
11. Switches and instruments - lighting control, headlight range control	13
12. Right steering column switch, windscreen washer/wiper system, rear window wiper	14
13. Tail lights, brake lights, reversing lights, rear fog light	15
14. Horn plate, heated rear window, cigarette lighter, illuminated ashtray	16
15. Fuse box, number plate light, glove box light, heated washer jets	17
16. Fuse box, headlights	18
17. Fuse box	19
18. Fuse box, diagnostic connector, provision for radio	20
19. Turn signals and hazard warning lights	21
20. Interior lights, luggage compartment lights, door contact switch	22
21. Dash panel insert, combi-processor in dash panel insert, handbrake warning	23
22. Dash panel insert, combi-processor in dash panel insert, rev. counter, speedometer, fuel gauge, fuel pump, coolant shortage indicator, oil pressure switch, analogue clock	24
23. Dash panel insert, combi-processor in dash panel insert, immobilizer reading coil, vehicle speed sender	25
24. Radiator fan, fresh air blower	26
002 - Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH	27-35
1. Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH	27-29
2. Battery, starter, alternator, main fuse box/battery	30
3. Simos control unit, fuel pump relay, injectors, ignition system, Hall sender	31
4. Simos control unit, knock sensor, engine speed sender, coolant temperature sender	32
5. Simos control unit, throttle valve control unit, ambient temperature sensor	33
6. Simos control unit, lambda probe, air mass meter, intake manifold change-over valve, activated charcoal filter system solenoid valve	34
7. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender	35
003 - Audi A3 (1.9 turbo-diesel, 66 kW, TDI, 4-cylinder), engine codes AGR	36-45
1. Audi A3 (1.9 turbo-diesel, 66 kW, TDI, 4-cylinder), engine codes AGR	36-38
2. Battery, starter, alternator, main fuse box/battery	39
3. Diesel direct injection system control unit, glow plugs (engine), glow plug relay, glow plugs (coolant), exhaust gas recirculation valve, charge pressure control solenoid valve	40
4. Diesel direct injection system control unit, air mass meter, diesel direct injection system relay, intake manifold temperature sender, accelerator pedal position sender, engine speed sender	41
5. Diesel direct injection system control unit, coolant temperature sender, modulating piston movement sender	42
6. Diesel direct injection system control unit	43
7. Diesel direct injection system control unit, brake pedal switch, clutch pedal switch	44
8. Dash panel insert, combi-processor in dash panel insert, fuel gauge sender, road speed sender, fuse box	45
004 - Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	46-52
1. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	46
2. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	47
3. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	48
4. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	49
5. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	50
6. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	51

interior monitoring	
7. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	52
005 - Anti-lock brake system (ABS and ABS with EDL)	53-55
1. Anti-lock brake system (ABS and ABS with EDL)	53
2. Anti-lock brake system (ABS and ABS with EDL)	54
3. Anti-lock brake system (ABS and ABS with EDL)	55
006 - Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	56-61
1. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	56
2. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	57
3. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	58
4. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	59
5. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	60
6. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	61
007 - Airbags for driver's seat and front passenger's seat with belt tensioners	62-63
1. Airbags for driver's seat and front passenger's seat with belt tensioners	62
2. Airbags for driver's seat and front passenger's seat with belt tensioners	63
008 - Electric sliding roof with automatic preselector	64-65
1. Electric sliding roof with automatic preselector	64
2. Electric sliding roof with automatic preselector	65
009 - Headlight washer system	66-68
1. Headlight washer system	66-67
2. Headlight washer system	68
010 - Trailer coupling	69-73
1. Trailer coupling	69-70
2. Trailer coupling	71
3. Trailer coupling	72
4. Trailer coupling	73
011 - Electric window lifters, 2-door (with roll back)	74-77
1. Electric window lifters, 2-door (with roll back)	74-75
2. Electric window lifters, 2-door (with roll back)	76
3. Electric window lifters, 2-door (with roll back)	77
012 - Heated seats	78-79
1. Heated seats	78
2. Heated seats	79
013 - Electric seat adjustment	80-83
1. Electric seat adjustment	80-81
2. Electric seat adjustment, driver's seat	82
3. Electric seat adjustment, front passenger's seat	83
014 - Air conditioner with automatic control	84-90
1. Air conditioner with automatic control	84-85
2. Air conditioner with automatic control	86
3. Air conditioner with automatic control	87
4. Air conditioner with automatic control	88
5. Air conditioner with automatic control	89
6. Air conditioner with automatic control	90
015 - Radio-beta	91-93
1. Radio-beta	91
2. Radio-beta	92
3. Radio-beta	93
016 - Radio-gamma, radio-delta with CD system	94-98
1. Radio-gamma, radio-delta with CD system	94-95
2. Radio-gamma, radio-delta with CD system	96
3. Radio-gamma, radio-delta with CD system	97
4. Radio-gamma, radio-delta with CD system	98
017 - Radio Bose system with and without CD changer	99-104
1. Radio Bose system with and without CD changer	99-100
2. Radio Bose system with and without CD changer	101
3. Radio Bose system with and without CD changer	102

4. Radio Bose system with and without CD changer	103
5. Radio Bose system with and without CD changer	104
018 - Four-speed automatic gearbox with selector lever lock	105-110
1. Four-speed automatic gearbox with selector lever lock	105-106
2. Four-speed automatic gearbox with selector lever lock	107
3. Four-speed automatic gearbox with selector lever lock	108
4. Four-speed automatic gearbox with selector lever lock	109
5. Four-speed automatic gearbox with selector lever lock	110
019 - Electrically adjustable and heated exterior mirrors, with folding function	111-114
1. Electrically adjustable and heated exterior mirrors, with folding function	111-112
2. Electrically adjustable and heated exterior mirrors, with folding function	113
3. Electrically adjustable and heated exterior mirrors, with folding function	114
020 - Telephone AEG (D-network)	115-118
1. Telephone AEG (D-network)	115-116
2. Telephone AEG (D-network)	117
3. Telephone AEG (D-network)	118
021 - Driver information system	119-122
1. Driver information system	119-120
2. On-board computer with auto-check system, ambient temperature indicator, washer fluid level indicator	121
3. Auto-check system	122
022 - Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	123-125
1. Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	123
2. Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	124
3. Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	125
023 - Ambient temperature and selector lever position indicator	126-127
1. Ambient temperature and selector lever position indicator	126
2. Ambient temperature and selector lever position indicator	127
024 - Fog lights	128-130
1. Fog lights	128-129
2. Fog lights	130
025 - Daytime driving lights	131-133
1. Daytime driving lights	131
2. Daytime driving lights	132
3. Daytime driving lights	133
026 - Heated door lock cylinder, driver's side	134-135
1. Heated door lock cylinder, driver's side	134
2. Heated door lock cylinder, driver's side	135
027 - Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AGU	136-145
1. Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AGU	136-138
2. Battery, starter, alternator, main fuse box/battery	139
3. Motronic control unit, fuel pump relay, injectors, Hall sender, altitude sender	140
4. Motronic control unit, knock sensors, engine speed sender, coolant temperature sender	141
5. Motronic control unit, throttle valve control unit, ambient temperature sensor	142
6. Motronic control unit, lambda probe, air mass meter, charge pressure control solenoid valve, activated charcoal filter system solenoid valve	143
7. Motronic control unit, ignition system	144
8. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	145
028 - Basic equipment and Audi A3 (1,8 l litre fuel injection engine, 92 kW, Motronic, 4-cylinder) engine codes AGN	146-172
1. Basic equipment and Audi A3 (1,8 l litre fuel injection engine, 92 kW, Motronic, 4-cylinder) engine codes AGN	146-149
2. Earth connections	150
3. Earth connections	151
4. Battery, starter, alternator, main fuse box/battery	152
5. Motronic control unit, fuel pump relay, injectors, ignition system, Hall sender	153
6. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	154
7. Motronic control unit, throttle valve control unit	155
8. Motronic control unit, lambda probe, air mass meter, inlet camshaft timing adjustment valve, Activated charcoal filter system solenoid valve, intake manifold change-over valve	156
9. Ignition/starter switch, X contact relief relay	157
10. Lighting switch, steering column switch - left	158
11. Switches and instruments - lighting control, headlight range control, windscreen washer/wiper system	159
12. Right steering column switch. windscreen washer/wiper system. rear window wiper	160

13. Tail lights, brake lights, reversing lights, rear fog light	161
14. Horn, heated rear window, cigarette lighter, illuminated ashtray	162
15. Fuse box, number plate light, glove box light, heated washer jets	163
16. Fuse box, headlights	164
17. Fuse box	165
18. Fuse box, diagnostic connector, provision for radio	166
19. Turn signals and hazard warning lights	167
20. Interior lights, luggage compartment lights, door contact switch	168
21. Dash panel insert, combi-processor in dash panel insert, handbrake warning	169
22. Dash panel insert, combi-processor in dash panel insert, rev. counter, speedometer, fuel gauge, fuel pump, coolant shortage indicator, oil pressure switch, analogue clock	170
23. Dash panel insert, combi-processor in dash panel insert, immobilizer reading coil, vehicle speed sender	171
24. Radiator fan, fresh air blower	172
029 - Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH/AKL	173-182
1. Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH/AKL	173-176
2. Battery, starter, alternator, main fuse box/battery	177
3. Simos control unit, fuel pump relay, injectors, ignition system, Hall sender	178
4. Simos control unit, knock sensor, engine speed sender, coolant temperature senders, intake manifold change-over valve	179
5. Simos control unit, throttle valve control unit, power steering pressure switch	180
6. Simos control unit, lambda probe, air mass meter, activated charcoal filter system solenoid valve	181
7. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender	182
030 - Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AGU	183-191
1. Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AGU	183-184
2. Battery, starter, alternator, main fuse box/battery	185
3. Motronic control unit, fuel pump relay, injectors, Hall sender, altitude sender	186
4. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	187
5. Motronic control unit, throttle valve control unit, ambient temperature sensor	188
6. Motronic control unit, lambda probe, air mass meter, charge pressure control solenoid valve, activated charcoal filter system solenoid valve	189
7. Ignition system	190
8. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	191
031 - Audi A3 (1.9 litre turbo- diesel engine, 66 kW, TDI, 4- cylinder), engine codes AGR/ALH	192-202
1. Audi A3 (1.9 litre turbo- diesel engine, 66 kW, TDI, 4- cylinder), engine codes AGR/ALH	192-194
2. Diesel direct injection system control unit, glow plugs (engine), glow plug relay, glow plugs (coolant), exhaust gas recirculation valve, charge pressure control solenoid valve	195
3. Diesel direct injection system control unit, air mass meter, diesel direct injection system relay, intake manifold temperature sender, accelerator pedal position sender, engine speed sender	196
4. Diesel direct injection system control unit, coolant temperature senders, modulating piston movement sender	197
5. Diesel direct injection system control unit	198
6. Diesel direct injection system control unit, brake pedal switch, clutch pedal switch	199
7. Radiator fan	200
8. Dash panel insert, combi-processor in dash panel insert, fuel gauge sender, road speed sender, fuse box	201
9. Dash panel insert, combi-processor in dash panel insert, fuel gauge sender, road speed sender, fuse box	202
032 - Air conditioner with automatic control, From model year 1998	203-208
1. Air conditioner with automatic control, From model year 1998	203
2. Air conditioner with automatic control	204
3. Air conditioner with automatic control	205
4. Air conditioner with automatic control	206
5. Air conditioner with automatic control	207
6. Air conditioner with automatic control	208
033 - Trailer coupling	209-213
1. Trailer coupling	209-210
2. Trailer coupling	211
3. Trailer coupling	212
4. Trailer coupling	213
034 - Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	214-216
1. Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	214
2. Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	215
3. Side airbags and airbags for driver's seat and front passenger's seat with belt tensioners	216

035 - Anti-lock brake system (ABS and ABS with EDL)	217-220
1. Anti-lock brake system (ABS and ABS with EDL)	217
2. Anti-lock brake system (ABS and ABS with EDL)	218
3. Anti-lock brake system (ABS and ABS with EDL)	219
4. Anti-lock brake system (ABS and ABS with EDL)	220
036 - Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	221-226
1. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	221
2. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	222
3. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	223
4. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	224
5. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	225
6. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	226
037 - Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	227-231
1. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	227
2. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	228
3. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	229
4. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	230
5. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	231
038 - Driver information system	232-236
1. Driver information system	232-233
2. On-board computer with auto-check system, ambient temperature indicator, washer fluid level indicator	234
3. On-board computer with auto-check system	235
4. Bulb monitoring device, rear	236
039 - Telephone AEG (D-network), without navigation system	237-239
1. Telephone AEG (D-network), without navigation system	237
2. Telephone AEG (D-network), without navigation system	238
3. Telephone AEG (D-network), without navigation system	239
040 - Telephone AEG (D-network), with navigation system	240-242
1. Telephone AEG (D-network), with navigation system	240
2. Telephone AEG (D-network), with navigation system	241
3. Telephone AEG (D-network), with navigation system	242
041 - Headlight washer system	243-245
1. Headlight washer system	243-244
2. Headlight washer system	245
042 - Mobile telephone, without navigation system	246-247
1. Mobile telephone, without navigation system	246
2. Mobile telephone, without navigation system	247
043 - Mobile telephone, with navigation system	248-249
1. Mobile telephone, with navigation system	248
2. Mobile telephone, with navigation system	249
044 - Parking aid	250-252
1. Parking aid	250
2. Parking aid	251
3. Parking aid	252
045 - Ambient temperature and selector lever position indicator	253-254
1. Ambient temperature and selector lever position indicator	253
2. Ambient temperature and selector lever position indicator	254
046 - Radio Concert, radio Chorus with CD changer	255-259
1. Radio Concert, radio Chorus with CD changer	255
2. Radio Concert, radio Chorus with CD changer	256
3. Radio Concert, radio Chorus with CD changer	257
4. Radio Concert. radio Chorus with CD changer	258

5. Radio Concert, radio Chorus with CD changer	259
047 - Radio Bose sound system	260-265
1. Radio Bose sound system	260
2. Radio Bose sound system	261
3. Radio Bose sound system	262
4. Radio Bose sound system	263
5. Radio Bose sound system	264
6. Radio Bose sound system	265
048 - Four-speed automatic gearbox with selector lever lock	266-271
1. Four-speed automatic gearbox with selector lever lock	266-267
2. Four-speed automatic gearbox with selector lever lock	268
3. Four-speed automatic gearbox with selector lever lock	269
4. Four-speed automatic gearbox with selector lever lock	270
5. Four-speed automatic gearbox with selector lever lock	271
049 - Navigation system	272-276
1. Navigation system	272
2. Navigation system	273
3. Navigation system	274
4. Navigation system	275
5. Navigation system	276
050 - Electric sliding roof with automatic preselector	277-278
1. Electric sliding roof with automatic preselector	277
2. Electric sliding roof with automatic preselector	278
051 - Cruise control system (for 1.8 litre Motronic, 4-cylinder)	279-281
1. Cruise control system (for 1.8 litre Motronic, 4-cylinder)	279
2. Cruise control system (for 1.8 litre Motronic, 4-cylinder)	280
3. Cruise control system (for 1.8 litre Motronic, 4-cylinder)	281
052 - Cruise control system (for 1.6 litre Simos, 4-cylinder)	282-284
1. Cruise control system (for 1.6 litre Simos, 4-cylinder)	282
2. Cruise control system (for 1.6 litre Simos, 4-cylinder)	283
3. Cruise control system (for 1.6 litre Simos, 4-cylinder)	284
053 - Automatic anti-dazzle interior mirror	285-286
1. Automatic anti-dazzle interior mirror	285
2. Automatic anti-dazzle interior mirror	286
054 - Provision for radio	287-288
1. Provision for radio	287
2. Provision for radio	288
055 - Fog lights	289-291
1. Fog lights	289-290
2. Fog lights	291
056 - Basic equipment and Audi A3 (1.8 litre fuel injection engine, 92 kW, Motronic, 4-cylinder - with manual throttle operation), engine codes AGN	292-317
1. Basic equipment and Audi A3 (1.8 litre fuel injection engine, 92 kW, Motronic, 4-cylinder - with manual throttle operation), engine codes AGN	292-294
2. Earth connections	295
3. Earth connections	296
4. Battery, starter, alternator, main fuse box/battery	297
5. Motronic control unit, fuel pump relay, injectors, ignition system, Hall sender	298
6. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	299
7. Motronic control unit, throttle valve control unit	300
8. Motronic control unit, lambda probe, air mass meter, inlet camshaft timing adjustment valve, activated charcoal filter system solenoid valve, intake manifold change-over valve	301
9. Ignition/starter switch, X contact relief relay	302
10. Lighting switch, steering column switch - left	303
11. Switches and instruments - lighting control, headlight range control, windscreen washer/wiper system	304
12. Right steering column switch, windscreen washer/wiper system, rear window wiper	305
13. Tail lights, brake lights, reversing lights, rear fog light	306
14. Horn, heated rear window, cigarette lighter, illuminated ashtray	307
15. Fuse box, number plate light, glove box light, heated washer jets	308
16. Fuse box, headlights	309
17. Fuse box	310
18. Fuse box, diagnostic connector, provision for radio	311
19. Turn signals and hazard warning lights	312
20. Interior lights, luggage compartment lights, door contact switch	313
21. Dash panel insert. combi-processor in dash panel insert. handbrake warning	314

22. Dash panel insert, combi-processor in dash panel insert, rev. counter, speedometer, fuel gauge, fuel pump, coolant shortage indicator, oil pressure switch, analogue clock	315
23. Dash panel insert, combi-processor in dash panel insert, immobilizer reading coil, vehicle speed sender	316
24. Radiator fan, fresh air blower	317
057 - Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH/AKL	318-326
1. Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH/AKL	318-320
2. Battery, starter, alternator, main fuse box/battery	321
3. Simos control unit, fuel pump relay, injectors, ignition system, Hall sender, intake manifold change-over valve	322
4. Simos control unit, knock sensor, engine speed sender, coolant temperature senders	323
5. Simos control unit, throttle valve control unit, power steering pressure switch	324
6. Simos control unit, lambda probe, air mass meter, activated charcoal filter system solenoid valve	325
7. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender	326
058 - Audi A3 (1.9 litre turbo- diesel engine, 66 kW, TDI, 4- cylinder), engine codes AGR/ALH	327-337
1. Audi A3 (1.9 litre turbo- diesel engine, 66 kW, TDI, 4- cylinder), engine codes AGR/ALH	327-329
2. Battery, starter, alternator, main fuse box/battery	330
3. Diesel direct injection system control unit, (glow plugs - engine), glow plug relay, glow plugs (coolant), exhaust gas recirculation valve, charge pressure control solenoid valve	331
4. Diesel direct injection system control unit, air mass meter, diesel direct injection system relay, intake manifold temperature sender, accelerator pedal position sender, engine speed sender	332
5. Diesel direct injection system control unit, coolant temperature senders, modulating piston movement sender	333
6. Diesel direct injection system control unit, cruise control system switch	334
7. Diesel direct injection system control unit, brake pedal switch, clutch pedal switch	335
8. Radiator fan	336
9. Dash panel insert, combi-processor in dash panel insert, fuel gauge sender, road speed sender, fuse box	337
059 - Airbags, side airbags and curtain airbags for driver's seat and front passenger's seat with belt tensioners	338-341
1. Airbags, side airbags and curtain airbags for driver's seat and front passenger's seat with belt tensioners	338
2. Airbags, side airbags and curtain airbags for driver's seat and front passenger's seat with belt tensioners	339
3. Airbags, side airbags and curtain airbags for driver's seat and front passenger's seat with belt tensioners	340
4. Airbags, side airbags and curtain airbags for driver's seat and front passenger's seat with belt tensioners	341
060 - Trailer coupling	342-346
1. Trailer coupling	342-343
2. Trailer coupling	344
3. Trailer coupling	345
4. Trailer coupling	346
061 - Anti-lock brake system (ABS, EDL and ASR)	347-350
1. Anti-lock brake system (ABS, EDL and ASR)	347
2. Anti-lock brake system (ABS, EDL and ASR)	348
3. Anti-lock brake system (ABS, EDL and ASR)	349
4. Anti-lock brake system (ABS, EDL and ASR)	350
062 - Ambient temperature and selector lever position indicator	351-352
1. Ambient temperature and selector lever position indicator	351
2. Ambient temperature and selector lever position indicator	352
063 - Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	353-358
1. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	353
2. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	354
3. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	355
4. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	356
5. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	357
6. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	358

064 - Parking aid	359-361
1. Parking aid	359
2. Parking aid	360
3. Parking aid	361
065 - Electrically adjustable and heated exterior mirrors with fold-in feature	362-365
1. Electrically adjustable and heated exterior mirrors with fold-in feature	362-363
2. Electrically adjustable and heated exterior mirrors with fold-in feature	364
3. Electrically adjustable and heated exterior mirrors with fold-in feature	365
066 - Driver information system	366-370
1. Driver information system	366-367
2. On-board computer with auto-check system, ambient temperature indicator, washer fluid level indicator	368
3. On-board computer with auto-check system	369
4. Bulb monitoring device, rear	370
067 - Cruise control system (for 1.6 litre Simos, 4-cylinder)	371-373
1. Cruise control system (for 1.6 litre Simos, 4-cylinder)	371
2. Cruise control system (for 1.6 litre Simos, 4-cylinder)	372
3. Cruise control system (for 1.6 litre Simos, 4-cylinder)	373
068 - Mobile telephone, with navigation system	374-375
1. Mobile telephone, with navigation system	374
2. Mobile telephone, with navigation system	375
069 - Mobile telephone, without navigation system	376-377
1. Mobile telephone, without navigation system	376
2. Mobile telephone, without navigation system	377
070 - Fog lights	378-380
1. Fog lights	378-379
2. Fog lights (not for 1.8 litre turbo-Motronic 154kW - S3)	380
071 - Daytime driving lights	381-383
1. Daytime driving lights	381
2. Daytime driving lights	382
3. Daytime driving lights	383
072 - Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	384-388
1. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	384
2. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	385
3. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	386
4. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	387
5. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	388
073 - Air conditioner with automatic control, From model year 1999	389-394
1. Air conditioner with automatic control, From model year 1999	389
2. Air conditioner with automatic control	390
3. Air conditioner with automatic control	391
4. Air conditioner with automatic control	392
5. Air conditioner with automatic control	393
6. Air conditioner with automatic control	394
074 - Cruise control system (for 1.8 litre Motronic, 4-cylinder)	395-397
1. Cruise control system (for 1.8 litre Motronic, 4-cylinder)	395
2. Cruise control system (for 1.8 litre Motronic, 4-cylinder)	396
3. Cruise control system (for 1.8 litre Motronic, 4-cylinder)	397
075 - Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AQA	398-408
1. Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AQA	398-400
2. Battery, starter, alternator, main fuse box/battery	401
3. Motronic control unit, fuel pump relay, injectors, Hall sender, charge pressure control solenoid valve, by-pass cut-off valve	402
4. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	403
5. Motronic control unit, throttle valve control unit, ambient temperature sensor, charge air pressure sender	404
6. Motronic control unit, accelerator pedal position senders, cruise control system switch, brake light switch, clutch pedal switch	405
7. Simos control unit, lambda probes with additional heater, air mass meter, activated charcoal filter system solenoid valve	406

8. Ignition system	407
9. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	408
076 - Electric windows, 2-door/4-door (with roll-back function), From model year 1999	409-413
1. Electric windows, 2-door/4-door (with roll-back function), From model year 1999	409
2. Electric windows, 2-door/4-door (with roll-back function)	410
3. Electric windows, 2-door/4-door (with roll-back function)	411
4. Electric windows, 2-door/4-door (with roll-back function)	412
5. Electric windows, 2-door/4-door (with roll-back function)	413
077 - Radiator fan control for 1.8 litre Motronic 154kW, 4-cylinder - S3, From model year 1999	414-415
1. Radiator fan control for 1.8 litre Motronic 154kW, 4-cylinder - S3, From model year 1999	414
2. Radiator fan control for 1.8 litre Motronic 154kW, 4-cylinder - S3	415
078 - Basic equipment and Audi A3 (1.8 litre fuel injection engine, 92 kW, Motronic, 4-cylinder - with manual throttle operation), engine codes AGN	416-443
1. Basic equipment and Audi A3 (1.8 litre fuel injection engine, 92 kW, Motronic, 4-cylinder - with manual throttle operation), engine codes AGN	416-419
2. Earth connections	420
3. Earth connections	421
4. Battery, starter, alternator, main fuse box/battery	422
5. Motronic control unit, fuel pump relay, injectors, ignition system, Hall sender	423
6. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	424
7. Motronic control unit, throttle valve control unit	425
8. Motronic control unit, lambda probe, air mass meter, inlet camshaft timing adjustment valve, Activated charcoal filter system solenoid valve, intake manifold change-over valve	426
9. Ignition/starter switch, X contact relief relay	427
10. Lighting switch, steering column switch - left	428
11. Switches and instruments, lighting control, windscreen washer/wiper system, headlight range control (not for 1.8 litre turbo-Motronic 154kW - S3)	429
12. Right steering column switch, windscreen washer/wiper system, rear window wiper	430
13. Tail lights, brake lights, reversing lights, rear fog light	431
14. Horn plate, heated rear window, cigarette lighter, illuminated ashtray	432
15. Fuse box, number plate light, glove box light, heated washer jets	433
16. Fuse box, headlights (not for 1.8 litre turbo-Motronic 154kW - S3)	434
17. Fuse box	435
18. Fuse box, diagnostic connector, provision for radio	436
19. Turn signals and hazard warning lights	437
20. Luggage compartment lights, door contact switch	438
21. Dash panel insert, combi-processor in dash panel insert, handbrake warning	439
22. Dash panel insert, combi-processor in dash panel insert, rev. counter, speedometer, fuel gauge, fuel pump, coolant shortage indicator, oil pressure switch, analogue clock	440
23. Dash panel insert, combi-processor in dash panel insert, oil level/oil temperature sender, warning lamps	441
24. Dash panel insert, combi-processor in dash panel insert, immobilizer reading coil, vehicle speed sender, warning lamps, belt warning	442
25. Radiator fan, fresh air blower	443
079 - Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH	444-453
1. Audi A3 (1,6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes AEH	444-447
2. Simos control unit, fuel pump relay, injectors, ignition system, intake manifold change-over valve	448
3. Simos control unit, knock sensor, engine speed sender, coolant temperature senders, Hall sender	449
4. Simos control unit, throttle valve control unit, power steering pressure switch	450
5. Simos control unit, lambda probe, air mass meter, activated charcoal filter system solenoid valve	451
6. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender	452
7. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender	453
080 - Audi A3 (1.9 litre turbo- diesel engine, 66 kW, TDI, 4- cylinder), engine codes AGR/ALH Audi A3 (1.9 litre turbo- diesel engine, 81 kW, TDI, 4- cylinder), engine codes AHF/ASV	454-464
1. Audi A3 (1.9 litre turbo- diesel engine, 66 kW, TDI, 4- cylinder), engine codes AGR/ALH Audi A3 (1.9 litre turbo- diesel engine, 81 kW, TDI, 4- cylinder), engine codes AHF/ASV	454-456
2. Battery, starter, alternator, main fuse box/battery	457
3. Diesel direct injection system control unit, (glow plugs - engine), glow plug relay, glow plugs (coolant), exhaust gas recirculation valve, charge pressure control solenoid valve	458
4. Diesel direct injection system control unit, air mass meter, diesel direct injection system relay, intake manifold temperature sender, accelerator pedal position sender, engine speed sender	459
5. Diesel direct injection system control unit. coolant temperature senders. modulatina piston	460

movement sender	
6. Diesel direct injection system control unit, cruise control system switch	461
7. Diesel direct injection system control unit, brake pedal switch, clutch pedal switch	462
8. Radiator fan	463
9. Dash panel insert, combi-processor in dash panel insert, fuel gauge sender, road speed sender, fuse box	464
081 - Audi A3 (1.6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes APF	465-476
1. Audi A3 (1.6 l litre fuel injection engine, 74 kW, Simos, 4-cylinder) engine codes APF	465-467
2. Simos control unit, fuel pump relay, injectors, Hall sender, intake manifold change-over valve, coolant temperature senders	468
3. Simos control unit, knock sensor, engine speed sender	469
4. Simos control unit, throttle valve control unit, valve and potentiometer for exhaust gas recirculation	470
5. Simos control unit, accelerator pedal position senders, cruise control system switch, brake light switch, clutch pedal switch	471
6. Simos control unit, lambda probes with additional heater, air mass meter, activated charcoal filter system solenoid valve	472
7. Simos control unit, ignition system, secondary air pump	473
8. Simos control unit, fuse box, radiator fan	474
9. Simos control unit, fuse box, radiator fan	475
10. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	476
082 - Audi A3 (1.8 litre fuel injection engine, 92 kW, Motronic, 4-cylinder) engine codes APG	477-487
1. Audi A3 (1.8 litre fuel injection engine, 92 kW, Motronic, 4-cylinder) engine codes APG	477-478
2. Battery, starter, alternator, main fuse box/battery	479
3. Motronic control unit, fuel pump relay, injectors, Hall sender, intake manifold change-over valve, inlet camshaft timing adjustment valve	480
4. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	481
5. Motronic control unit, throttle valve control unit, valve and potentiometer for exhaust gas recirculation	482
6. Motronic control unit, accelerator pedal position senders, cruise control system switch, brake light switch, clutch pedal switch	483
7. Simos control unit, lambda probes with additional heater, air mass meter, activated charcoal filter system solenoid valve	484
8. Motronic control unit, current supply relay	485
9. Motronic control unit, ignition system, secondary air pump, fuse box	486
10. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	487
083 - Audi A3 (1.8 litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AQA/ARZ	488-500
1. Audi A3 (1.8 litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AQA/ARZ	488-490
2. Battery, starter, alternator, main fuse box/battery	491
3. Motronic control unit, fuel pump relay, injectors, Hall sender, Hall sender, charge pressure control solenoid valve, divert air valve	492
4. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	493
5. Radiator fan	494
6. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	495
7. Simos control unit, lambda probes with additional heater, air mass meter, activated charcoal filter system solenoid valve	496
8. Motronic control unit, ignition system	497
9. Motronic control unit, current supply relay	498
10. Radiator fan	499
11. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	500
084 - Four-speed automatic gearbox with selector lever lock (01M)	501-506
1. Four-speed automatic gearbox with selector lever lock (01M)	501-502
2. Four-speed automatic gearbox with selector lever lock (01M)	503
3. Four-speed automatic gearbox with selector lever lock (01M)	504
4. Four-speed automatic gearbox with selector lever lock (01M)	505
5. Four-speed automatic gearbox with selector lever lock (01M)	506
086 - Headlights with gas discharge lamps and automatic headlight range control (for 1.8 litre turbo engine with Motronic, 154 kW, S3)	507-510
1. Headlights with gas discharge lamps and automatic headlight range control (for 1.8 litre turbo engine with Motronic, 154 kW, S3)	507-508
2. Headlights with gas discharge lamps and automatic headlight range control (for 1.8 litre turbo engine with Motronic, 154 kW, S3)	509

3. Headlights with gas discharge lamps and automatic headlight range control (for 1.8 litre turbo engine with Motronic, 154 kW, S3)	510
087 - Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	511-518
1. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	511-512
2. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	513
3. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	514
4. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	515
5. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring	516
6. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring, door warning lamps	517
7. Central locking system with interior lights switch-off delay and anti-theft alarm system with interior monitoring, door warning lamps	518
088 - Electrically adjustable interior and exterior mirrors with retraction function, automatic anti-dazzle interior and exterior mirrors	519-523
1. Electrically adjustable interior and exterior mirrors with retraction function, automatic anti-dazzle interior and exterior mirrors	519-520
2. Electrically adjustable interior and exterior mirrors with retraction function, automatic anti-dazzle interior and exterior mirrors	521
3. Electrically adjustable interior and exterior mirrors with retraction function, automatic anti-dazzle interior and exterior mirrors	522
4. Electrically adjustable interior and exterior mirrors with retraction function, automatic anti-dazzle interior and exterior mirrors	523
089 - Electronic stability program	524-529
1. Electronic stability program	524-525
2. Electronic stability program	526
3. Electronic stability program	527
4. Electronic stability program	528
5. Electronic stability program	529
090 - Driver information system	530-534
1. Driver information system	530-531
2. On-board computer with auto-check system, ambient temperature indicator, washer fluid level indicator	532
3. On-board computer with auto-check system	533
4. Bulb monitoring device, rear	534
091 - Haldex coupling for four-wheel drive	535-538
1. Haldex coupling for four-wheel drive	535-536
2. Haldex coupling for four-wheel drive	537-538
092 - Mobile telephone, with navigation system	539-540
1. Mobile telephone, with navigation system	539
2. Mobile telephone, with navigation system	540
093 - Air conditioner with automatic control	541-548
1. Air conditioner with automatic control	541-542
2. Air conditioner with automatic control	543
3. Air conditioner with automatic control	544
4. Air conditioner with automatic control	545
5. Air conditioner with automatic control	546
6. Air conditioner with automatic control	547
7. Air conditioner with automatic control	548
094 - Navigation system	549-551
1. Navigation system	549
2. Navigation system	550
3. Navigation system	551
095 - Radio Bose sound system	552-557
1. Radio Bose sound system	552
2. Radio Bose sound system	553
3. Radio Bose sound system	554
4. Radio Bose sound system	555
5. Radio Bose sound system	556
6. Radio Bose sound system	557
096 - Radio Concert. radio Chorus with CD changer	558-562

1. Radio Concert, radio Chorus with CD changer	558
2. Radio Concert, radio Chorus with CD changer	559
3. Radio Concert, radio Chorus with CD changer	560
4. Radio Concert, radio Chorus with CD changer	561
5. Radio Concert, radio Chorus with CD changer	562
097 - Provision for radio	563-565
1. Provision for radio	563
2. Provision for radio	564
3. Provision for radio	565
098 - Daytime driving lights and fog lights (for 1.8 litre turbo-Motronic 154kW, 4-cylinder - S3)	566-569
1. Daytime driving lights and fog lights (for 1.8 litre turbo-Motronic 154kW, 4-cylinder - S3)	566-567
2. Daytime driving lights and fog lights (for 1.8 litre turbo-Motronic 154kW, 4-cylinder - S3)	568
3. Daytime driving lights and fog lights (for 1.8 litre turbo-Motronic 154kW, 4-cylinder - S3)	569
099 - Telephone (Nokia), with navigation system	570-572
1. Telephone (Nokia), with navigation system	570
2. Telephone (Nokia), with navigation system	571
3. Telephone (Nokia), with navigation system	572
100 - Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	573-579
1. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	573-574
2. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	575
3. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	576
4. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors	577
5. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors, door warning lamps	578
6. Central locking system with interior lights switch-off delay, reading lights and illuminated make-up mirrors, door warning lamps	579
101 - Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AGU	580-588
1. Audi A3 (1,8 l litre fuel injection engine, 110 kW, Motronic, 4-cylinder) engine codes AGU	580-581
2. Battery, starter, alternator, main fuse box/battery	582
3. Motronic control unit, fuel pump relay, injectors, Hall sender, altitude sender	583
4. Motronic control unit, knock sensors, engine speed sender, coolant temperature senders	584
5. Motronic control unit, throttle valve control unit, ambient temperature sensor	585
6. Motronic control unit, lambda probe, air mass meter, charge pressure control solenoid valve, activated charcoal filter system solenoid valve	586
7. Ignition system	587
8. Dash panel insert, combi-processor in dash panel insert, fuel pump, fuel gauge sender, road speed sender, fuse box	588
102 - Electric seat adjustment / seat heating for Recaro sport seats	589-597
1. Electric seat adjustment / seat heating for Recaro sport seats	589-590
2. Backrest adjustment and lumbar support adjustment for driver's seat	591
3. Height adjustment for driver's seat, side airbag	592
4. Backrest adjustment and lumbar support adjustment for front passenger's seat	593
5. Height adjustment for front passenger's seat, side airbag	594
6. Adjuster for heated driver's seat and front passenger's seat	595
7. Seat heating for driver's seat	596
8. Seat heating for front passenger's seat	597
201 - -Fitting Locations: Fitting Locations 1997 Model Year	598-602
1. Position of fuses in fuse box	598
2. Position of fuses in fuse box	599
3. 13-point relay carrier, Micro-central electrics	600
4. Main fuse box/battery	601
5. -Fitting Locations: Fitting Locations 1997 Model Year	602
202 - -Fitting Locations: Fitting Locations: 1998 Model Year	603-604
1. Position of fuse in fuse box	603
2. Position of fuse in fuse box	604
203 - -Fitting Locations: Fitting Locations: 1999 Model Year	605-606
1. Position of fuses in fuse box	605
2. Position of fuses in fuse box	606
204 - -Fitting Locations: Fitting Locations: Model Year 2000	607-608
1. Position of fuses in fuse box	607
2. Position of fuses in fuse box	608

401 - -Fault Finding Programme: Checking speed signal	609-613
1. Checking speed signal	609
2. -Fault Finding Programme: Checking speed signal	610
3. -Fault Finding Programme: Checking speed signal	611
4. -Fault Finding Programme: Checking speed signal	612
5. -Fault Finding Programme: Checking speed signal	613
402 - -Fault Finding Programme: Fault finding on electric headlight range control	614-617
1. Fault finding on electric headlight range control	614
2. -Fault Finding Programme: Fault finding on electric headlight range control	615
3. -Fault Finding Programme: Fault finding on electric headlight range control	616
4. -Fault Finding Programme: Fault finding on electric headlight range control	617
403 - -Fault Finding Programme: Heated lock cylinder does not work	618-619
1. Heated lock cylinder does nor work	618
2. -Fault Finding Programme: Heated lock cylinder does not work	619
404 - -Fault Finding Programme: Electrically adjustable and heated exterior mirror	620-621
1. Electrically adjustable and heated exterior mirror	620
2. -Fault Finding Programme: Electrically adjustable and heated exterior mirror	621
405 - -Fault Finding Programme: Heated seats	622-625
1. Heated seats	622
2. -Fault Finding Programme: Heated seats	623
3. -Fault Finding Programme: Heated seats	624
4. -Fault Finding Programme: Heated seats	625
406 - -Fault Finding Programme: Electric sliding roof does not work	626
1. Electric sliding roof does not work	626
407 - -Fault Finding Programme: Electric window lifters	627-632
1. Electric window filters	627
2. -Fault Finding Programme: Electric window lifters	628
3. -Fault Finding Programme: Electric window lifters	629
4. -Fault Finding Programme: Electric window lifters	630
5. -Fault Finding Programme: Electric window lifters	631
6. -Fault Finding Programme: Electric window lifters	632
408 - -Fault Finding Programme: Diagnostic wiring	633-639
1. Engine control unit does not answer	633
2. -Fault Finding Programme: Diagnostic wiring	634
3. -Fault Finding Programme: Diagnostic wiring	635
4. Control unit does not answer	636
5. -Fault Finding Programme: Diagnostic wiring	637
6. Testing diagnostic cable V.A.G 1551/3	638
7. -Fault Finding Programme: Diagnostic wiring	639
409 - -Fault Finding Programme: Headlight washer system	640-642
1. Headlight washer system	640
2. -Fault Finding Programme: Headlight washer system	641
3. -Fault Finding Programme: Headlight washer system	642