

## Contents

<b>24</b>	<b>Mixture preparation, Injection</b> .....	<b>1</b>
1	<b>Servicing Motronic injection system</b> .....	1
1.1	Servicing Motronic injection system .....	1
1.2	Safety precautions .....	1
1.3	Rules for cleanliness .....	1
1.4	Technical data .....	2
1.5	Exploded view of fitting locations .....	2
1.6	Checking fuel pressure regulator and holding pressure .....	12
1.7	Checking injection quantity, freedom from leaks and spray pattern of injectors .....	14
1.8	Wiring and component check using test box V.A.G 1598/31 .....	15
1.9	Replacing Motronic control unit -J220 .....	20
1.10	Exploded view of intake manifold .....	26
1.11	Removing and installing intake manifold .....	28
2	<b>Removing and installing lambda probe upstream of catalytic converter, bank 1 (right)</b> . . .	<b>33</b>
2.1	Removing and installing lambda probe upstream of catalytic converter, bank 1 (right) . . .	33
2.2	Removing and installing lambda probe upstream of catalytic converter, bank 2 (left) . . . . .	35
2.3	Removing and installing lambda probe downstream of catalytic converter, bank 1 (right) . .	38
2.4	Removing and installing lambda probe downstream of catalytic converter, bank 2 (left) . . .	43
<b>28</b>	<b>Ignition system</b> .....	<b>49</b>
1	<b>Checking ignition system</b> .....	<b>49</b>
1.1	Checking ignition system .....	49
1.2	General notes on ignition system .....	49
1.3	Safety precautions .....	49
1.4	Ignition system technical data .....	49