Contents

Zinc-coated body parts		ody parts	4
	Contents		6
	Adhesive bond	Adhesive bonds	
	Anti-corrosion measures		8
	Technical data		9
	Basic instructions on body repairs		10
	Security check of procon-ten system		13
	Bodywork dimensions		14
	Straightening	jig	20
	List of body re	pair groups	22
	Symbols for w	relding operations	24
	50 74 55 12	Renewing front wheel housing with side member	26
	50 79 55 12	Renewing front inner side member (part section)	28
	50 81 55 50	Renewing cross member-bulkhead	30
	51 03 55 12	Renewing roof	32
	51 37 55 12	Renewing hinge pillar (part section)	34
	51 41 55 12	B-pillar part section	36
	51 45 55 00	Renewing outer side member	38
	51 73 55 50	Renewing floor panel (part section)	40
	53 05 55 00	Renewing rear panel	42
	53 48 55 62	Renewing rear side member with floor panel (part section)	44
	53 55 55 00	Renewing side panel	46
	53 69 55 50	Wheel housing (part section)	48
	55 21 55 00	Front cover (part section)	50