

Contents

01 - Self-diagnosis, Electrical check	1
1 Self-diagnosis function	1
1.1 Self-diagnosis function	1
1.2 Technical data of self-diagnosis	2
2 Locations of electrical/electronic components	3
2.1 Locations of electrical/electronic components	3
3 Performing self-diagnosis	20
3.1 Performing self-diagnosis	20
3.2 Safety precautions	20
3.3 Connecting fault reader V.A.G 1551 (or V.A.G 1552) and selecting functions	21
3.4 List of selectable functions	23
3.5 Interrogating fault memory	23
3.6 Fault table	24
3.7 Erasing fault memory	32
3.8 Initiating basic setting	33
3.9 Read measured value block	34
3.10 Test table	36
4 Electrical test	47
4.1 Electrical test	47
4.2 Test table	50