

Contents

24 - Mixture preparation - injection	1
1 Servicing Motronic injection system	1
1.1 Safety precautions	1
1.2 Rules for cleanliness	1
1.3 When working on the fuel supply/injection system, pay careful attention to the following "6 rules":	1
1.4 Removing and installing air cleaner	7
1.5 Intake manifold - exploded view	9
1.6 Removing and installing intake manifold	10
1.7 Bleeding fuel system	13
1.8 Checking fuel pressure regulator and residual pressure	14
1.9 Checking injection quantity and spray pattern of injectors; checking for leaks	15
1.10 Wiring and component check with adapter lead, 121-pin V.A.G 1598/31 (test box)	19
1.11 Renewing engine control unit J623	22
1.12 Removing and installing air mass meter	24
2 Removing and installing Lambda probes	26
2.1 Removing and installing Lambda probe after catalytic converter G130 - bank 1 (right-side)	29
2.2 Removing and installing Lambda probe 2 after catalytic converter G131 - bank 2 (left-side)	30
28 - Ignition system	33
1 Checking ignition system	33
1.1 General notes on ignition system	33
1.2 Safety precautions	33
1.3 Technical data	33
2 Removing and installing ignition coils	34