

001 - Audi A8 4.2 I fuel injection engine (221 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1997	1-33
1. Audi A8 4.2 I fuel injection engine (221 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1997	1
2. Audi A8 4.2 I fuel injection engine (221 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1997	2
3. Audi A8 4.2 I fuel injection engine (221 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1997	3
4. Earth connections	4
5. Battery, starter, alternator, starter inhibitor relay	5
6. Motronic control unit, ignition coils, injectors, fuse	6
7. Motronic control unit, final output stage ignition coils, injectors	7
8. Motronic control unit, fuel pump relay, ignition coils	8
9. Motronic control unit, Motronic current supply relay, ignition coils for output stages, lambda probes with heating	9
10. Motronic control unit, automatic gearbox control unit, lambda probe 2, immobilizer	10
11. Motronic control unit, throttle valve potentiometer, air mass meter	11
12. Motronic control unit, Hall senders, engine speed sender, control element fuse	12
13. Engine cooling	13
14. Dash panel insert, fuel gauge, fuel pump, coolant and oil pressure control, selector lever position indicator	14
15. Dash panel insert, brake pad/lining wear indicator, warning lamps	15
16. Dash panel insert, rev. counter, warning lamps	16
17. Dash panel insert, digital clock, diagnosis connection	17
18. Dash panel insert, main beam warning lamp, doors closed warning lamp	18
19. Dash panel insert, coolant temperature gauge, speedometer, warning lamps	19
20. Ignition/starter switch, lighting switch, X contact relief relay	20
21. Fuse carrier 1, bulb monitoring device, headlight, side light, fog lights	21
22. Fuse carrier 1, bulb monitoring device, tail light, brake lights, number plate light, high level brake	22
23. Headlight range control, rear fog light, fog light switch and rear fog light	23
24. Turn signal switch, hazard warning light switch, hazard warning light relay	24
25. Intermittent wiper switch, windscreen wiper and washer system, headlight washer system	25
26. Heated rear window, heated washer jets, reversing lights	26
27. Horn, fresh air blower, Thermotronic control unit	27
28. Interior light, reading lights	28
29. Footwell lights, entry lights, entry and footwell lighting relay, door warning lamp	29
30. Door contact switch, illuminated make-up mirrors	30
31. Cigarette lighter, luggage compartment lights	31
32. Cigarette lighter, rear, rear window lifter isolation switch	32
33. Illumination for dash panel and rear vents, glove box light	33
002 - Audi A8 3.7 I fuel injection engine (170 kW - Motronic - 8-cylinder) engine code AEW, Model year 1997	34-47
1. Audi A8 3.7 I fuel injection engine (170 kW - Motronic - 8-cylinder) engine code AEW, Model year 1997	34
2. Audi A8 3.7 I fuel injection engine (170 kW - Motronic - 8-cylinder) engine code AEW, Model year 1997	35
3. Battery, starter, alternator, starter inhibitor relay	36
4. Motronic control unit, ignition coils, injectors, ignition coil fuses	37
5. Motronic control unit, final output stage for ignition coils	38
6. Motronic control unit, throttle valve potentiometer, air mass meter, knock sensors	39
7. Motronic control unit, Hall senders, engine speed sender, control element fuse	40
8. Motronic control unit, fuel pump relay, ignition coils	41
9. Motronic control unit, Motronic current supply relay, ignition coils for output stages, lambda probes with heating	42
10. Motronic control unit, lambda probes 2, immobilizer	43
11. Engine cooling	44
12. Dash panel insert, fuel gauge, fuel pump, coolant and oil pressure control	45
13. Dash panel insert, rev. counter, selector lever position indicator, warning lamps	46
14. Dash panel insert, speedometer	47
003 - Audi A8 2.8 I fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ACK, Model year 1997	48-61
1. Audi A8 2.8 I fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ACK, Model year 1997	48
2. Audi A8 2.8 I fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ACK, Model year 1997	49

3. Audi A8 2.8 l fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ACK, Model year 1997	50
4. Earth connections	51
5. Battery, starter, alternator, starter inhibitor relay	52
6. Motronic control unit, ignition system, injectors, Hall sender, fuses	53
7. Motronic control unit, knock sensors, throttle valve control unit, engine speed sender	54
8. Motronic control unit, hall sender 2, immobilizer control unit	55
9. Motronic control unit, lambda probe heater, inlet camshaft timing adjustment valves	56
10. Motronic control unit, fuel pump relay, air mass meter	57
11. Engine cooling	58
12. Dash panel insert, fuel gauge sender, fuel pump, coolant and oil pressure control	59
13. Dash panel insert, warning lamp, handbrake warning switch, selector lever position indicator, coolant temperature gauge	60
14. Dash panel insert, digital clock, diagnosis connection, warning lamps, speedometer sender	61
004 - Provision for radio	62-65
1. Provision for radio	62-63
2. Provision for radio	64
3. Provision for radio	65
005 - Audi S8 4.2 l fuel injection engine (250 kW - Motronic - 8-cylinder) engine code AHC, Model year 1997	66-79
1. Audi S8 4.2 l fuel injection engine (250 kW - Motronic - 8-cylinder) engine code AHC, Model year 1997	66
2. Audi S8 4.2 l fuel injection engine (250 kW - Motronic - 8-cylinder) engine code AHC, Model year 1997	67
3. Battery, starter, alternator, reversing light switch	68
4. Motronic control unit, ignition coils, injectors, ignition coil fuses	69
5. Motronic control unit, final output stage for ignition coils	70
6. Motronic control unit, throttle valve potentiometer, air mass meter, knock sensors	71
7. Motronic control unit, Hall senders, engine speed sender, control element fuse	72
8. Motronic control unit, fuel pump relay, ignition coils	73
9. Motronic control unit, Motronic current supply relay, output stage for ignition coils, lambda probe heater	74
10. Motronic control unit, lambda probes 2, immobilizer	75
11. Engine cooling	76
12. Dash panel insert, fuel gauge, fuel pump, coolant and oil pressure control	77
13. Dash panel insert, rev. counter, warning lamps	78
14. Dash panel insert, speedometer, diagnosis connection	79
006 - Automatic gearbox (01V) 6 cylinder engines 2.8 l, 142 kW, ACK, Model year 1997	80-85
1. Automatic gearbox (01V) 6 cylinder engines 2.8 l, 142 kW, ACK, Model year 1997	80
2. Automatic gearbox (01V) 6 cylinder engines 2.8 l, 142 kW, ACK, Model year 1997	81
3. Automatic gearbox control unit, solenoid valves, kick-down switch	82
4. Automatic gearbox control unit, multi-function switch	83
5. Automatic gearbox control unit, Tiptronic switch	84
6. Brake light switch, starter inhibitor relay, reversing light	85
007 - Automatic gearbox (01L) with 8-cylinder-engines 4.2 l, 250 kW, AKH*, Model year 1997	86-91
1. Automatic gearbox (01L) with 8-cylinder-engines 4.2 l, 250 kW, AKH*, Model year 1997	86
2. Automatic gearbox (01L) with 8-cylinder-engines 4.2 l, 250 kW, AKH*, Model year 1997	87
3. Automatic gearbox control unit, solenoid valves, kick-down switch	88
4. Automatic gearbox control unit, multi-function switch	89
5. Automatic gearbox control unit, Tiptronic switch	90
6. Brake light switch, starter inhibitor relay, reversing light	91
008 - Anti-lock brake system (ABS) with electronic differential lock (EDL) and traction control system (ASR), Model year 1997	92-96
1. Anti-lock brake system (ABS) with electronic differential lock (EDL) and traction control system (ASR), Model year 1997	92
2. Anti-locking brake system	93
3. Anti-locking brake system	94
4. Anti-locking brake system	95
5. Anti-locking brake system	96
009 - Airbag	97-100
1. Airbag	97
2. Airbags and belt tensioners for driver and front passenger	98
3. Side airbag for front and rear seats	99
4. Rear belt tensioner igniter, belt switches	100
010 - Servotronic	101-103
1. Servotronic	101-102

2. Servotronic	103
011 - Cruise control system petrol engines	104-106
1. Cruise control system petrol engines	104
2. Cruise control system	105
3. Cruise control system petrol engines	106
012 - Central locking with remote control and anti-theft alarm system with interior monitoring, Model year 1997	107-114
1. Central locking with remote control and anti-theft alarm system with interior monitoring, Model year 1997	107
2. Central locking, interior locking switch	108
3. Contact switch in lock cylinder for tailgate/bootlid/anti-theft alarm system/central locking system, door handle switch	109
4. Anti-theft alarm system horn, tailgate/bootlid contact switch for anti-theft alarm	110
5. Anti-theft alarm system contact switch	111
6. Luggage compartment release switch	112
7. Door contact switch	113
8. Interior monitor, ultra-sonic sensors control unit	114
013 - Audio - steering wheel, Model year 1997	115-116
1. Audio - steering wheel, Model year 1997	115
2. Audio - steering wheel	116
014 - Electric window lifter, Model year 1997	117-122
1. Electric window lifter, Model year 1997	117
2. Electric window lifter, rear window lifter isolation switch, fuses	118
3. Electric window lifter	119
4. Front left window lifter	120
5. Window lifter - front right and rear left	121
6. Rear right window lifter	122
015 - Electrically adjustable and heated exterior mirrors with or without retraction function, Model year 1997	123-124
1. Electrically adjustable and heated exterior mirrors with or without retraction function, Model year 1997	123
2. Electrically adjustable and heated exterior mirrors with or without retraction function	124
016 - Trailer coupling, Model year 1997	125-130
1. Trailer coupling, Model year 1997	125
2. Trailer coupling, Model year 1997	126
3. Trailer coupling	127
4. Trailer coupling	128
5. Trailer coupling	129
6. Trailer coupling	130
017 - Electric seat, mirror, steering column and belt height adjustment with memory function, Model year 1997	131-141
1. Electric seat, mirror, steering column and belt height adjustment with memory function, Model year 1997	131
2. Electric seat, mirror, steering column and belt height adjustment with memory function, memory operating unit	132
3. Electric seat, mirror, steering column and belt height adjustment with memory function, mirror adjustment on driver's side	133
4. Electric seat, mirror, steering column and belt height adjustment with memory function, mirror adjustment on front passenger's side	134
5. Electric seat, mirror, steering column and belt height adjustment with memory function, steering column adjustment	135
6. Electric seat, mirror, steering column and belt height adjustment with memory function, belt height adjustment, left	136
7. Electric seat, mirror, steering column and belt height adjustment with memory function, backrest adjustment, left	137
8. Electric seat, mirror, steering column and belt height adjustment with memory function, driver's seat adjustment	138
9. Electric seat, mirror, steering column and belt height adjustment with memory function, height adjustment driver's seat	139
10. Electric seat, mirror, steering column and belt height adjustment with memory function, lumbar support adjustment for driver's and front passenger's seat	140
11. Electric seat, mirror, steering column and belt height adjustment with memory function, front passenger's seat adjustment	141
018 - Electric seat adjustment	142-146
1. Electric seat adjustment	142-143
2. Electric seat adjustment	144

3. Electric seat adjustment	145
4. Electric seat adjustment	146
019 - Automatic anti-dazzle interior mirror, Model year 1997	147-148
1. Automatic anti-dazzle interior mirror, Model year 1997	147
2. Automatic anti-dazzle interior mirror	148
020 - Electric sliding sunroof with automatic selection, Model year 1997	149-150
1. Electric sliding sunroof with automatic selection, Model year 1997	149
2. Electric sliding sunroof with automatic selection	150
021 - Air conditioner with automatic control, Model year 1997	151-160
1. Air conditioner with automatic control, Model year 1997	151
2. Air conditioner with automatic control, Model year 1997	152
3. Air conditioner	153
4. Air conditioner	154
5. Air conditioner	155
6. Air conditioner	156
7. Air conditioner	157
8. Air conditioner	158
9. Air conditioner	159
10. Air conditioner, engine cooling	160
022 - Air conditioner with auxiliary heater, Model year 1997	161-173
1. Air conditioner with auxiliary heater, Model year 1997	161
2. Air conditioner with auxiliary heater, Model year 1997	162
3. Air conditioner with auxiliary heater	163
4. Air conditioner with auxiliary heater	164
5. Air conditioner with auxiliary heater	165
6. Air conditioner with auxiliary heater	166
7. Air conditioner with auxiliary heater	167
8. Air conditioner with auxiliary heater	168
9. Air conditioner with auxiliary heater	169
10. Air conditioner with auxiliary heater	170
11. Air conditioner with auxiliary heater	171
12. Air conditioner with auxiliary heater	172
13. Air conditioner with auxiliary heater	173
023 - Headlights with gas discharge lamps, Model year 1997	174-178
1. Headlights with gas discharge lamps, Model year 1997	174
2. Headlights with gas discharge lamps, Model year 1997	175
3. Headlights with gas discharge lamps	176
4. Headlights with gas discharge lamps	177
5. Headlights with gas discharge lamps	178
024 - Daytime driving lights with fog lights, Model year 1997	179-184
1. Daytime driving lights with fog lights, Model year 1997	179
2. Daytime driving lights with fog lights, Model year 1997	180
3. Daytime driving lights with fog lights	181
4. Daytime driving lights with fog lights	182
5. Daytime driving lights with fog lights	183
6. Daytime driving lights with fog lights	184
025 - Electric seat adjustment and seat heating, Recaro sport seats, Model year 1997	185-193
1. Electric seat adjustment and seat heating, Recaro sport seats, Model year 1997	185
2. Electric seat adjustment, driver's seat with memory, memory operating unit	186
3. Electric backrest adjustment, driver's seat	187
4. Electric seat adjustment, driver's seat with memory	188
5. Electric height adjustment, driver's seat	189
6. Elektropneumatic lumbar support adjustment, driver- and passenger's seat	190
7. Electric seat adjustment, front passenger's seat adjustment	191
8. Heated sport seats, driver's seat	192
9. Heated sport seats, front passenger's seat	193
026 - Electric seat adjustment rear seats, Model year 1997	194-199
1. Electric seat adjustment rear seats, Model year 1997	194
2. Rear head restraint adjustment switch, seat adjustment fuse	195
3. Adjustable front passenger's seat switch, adjustable rear seat switch, right, rear window lifter isolation switch	196
4. Electric seat and head restraint adjustment rear seat, left	197
5. Electric seat and head restraint adjustment rear seat, right	198
6. Lumbar support adjustment, rear seats	199
027 - Tailgate/bootlid	200-201
1. Tailgate/bootlid	200

2. Tailgate/bootlid	201
028 - Radio stereo system with passive loudspeakers, Model year 1997	202-204
1. Radio stereo system with passive loudspeakers, Model year 1997	202
2. Radio stereo system with passive loudspeakers	203
3. Radio stereo system with passive loudspeakers	204
029 - Telephone, AEG	205-208
1. Telephone, AEG	205-206
2. Telephone, AEG	207
3. Telephone, AEG	208
030 - Radio gamma, delta sound system, radio-Bose sound system with and without CD changer	209-214
1. Radio gamma, delta sound system, radio-Bose sound system with and without CD changer	209-210
2. Radio gamma, delta sound system, radio-Bose sound system with and without CD changer	211
3. Radio gamma, delta sound system, radio-Bose sound system with and without CD changer	212
4. Radio gamma, delta sound system, radio-Bose sound system with and without CD changer	213
5. Radio gamma, delta sound system, radio-Bose sound system with and without CD changer	214
031 - Navigation system	215-221
1. Navigation system	215-216
2. Operating electronics control unit, navigation	217
3. Operating electronics control unit, navigation system operating unit	218
4. Navigation control unit, operating electronics control unit	219
5. Navigation control unit, operating electronics control unit	220
6. Navigation control unit	221
032 - Mobile phone	222-225
1. Mobile phone	222-223
2. Mobile phone	224
3. Mobile phone	225
033 - Card-system for Italy, Model year 1997	226-227
1. Card-system for Italy, Model year 1997	226
2. Card-system for Italy	227
034 - Audi A8 / S8 4.2 l fuel injection engine (220 / 250 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1998	228-260
1. Audi A8 / S8 4.2 l fuel injection engine (220 / 250 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1998	228
2. Audi A8 / S8 4.2 l fuel injection engine (220 / 250 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1998	229
3. Audi A8 / S8 4.2 l fuel injection engine (220 / 250 kW - Motronic - 8-cylinder) engine code ABZ, Model year 1998	230
4. Earth connections	231
5. Battery, starter, alternator, starter inhibitor relay	232
6. Motronic control unit, ignition coils, injectors, fuse	233
7. Motronic control unit, final output stage ignition coils, injectors	234
8. Motronic control unit, fuel pump relay, ignition coils	235
9. Motronic control unit, Motronic current supply relay, ignition coils for output stages, lambda probes with heating	236
10. Motronic control unit, automatic gearbox control unit, lambda probe 2, immobilizer	237
11. Motronic control unit, throttle valve potentiometer, air mass meter	238
12. Motronic control unit, Hall senders, engine speed sender, control element fuse	239
13. Engine cooling	240
14. Dash panel insert, fuel gauge, fuel pump, coolant and oil pressure control, selector lever position indicator	241
15. Dash panel insert, brake pad/lining wear indicator, warning lamps	242
16. Dash panel insert, rev. counter, warning lamps	243
17. Dash panel insert, digital clock, radio wave controlled clock, diagnosis connection	244
18. Dash panel insert, main beam warning lamp, doors closed warning lamp	245
19. Dash panel insert, coolant temperature gauge, speedometer, warning lamps	246
20. Ignition/starter switch, lighting switch, X contact relief relay	247
21. Fuse carrier 1, bulb monitoring device, headlight, side light, fog lights	248
22. Fuse carrier 1, bulb monitoring device, tail light, brake lights, number plate light, high level brake	249
23. Headlight range control, rear fog light, fog light switch and rear fog light	250
24. Turn signal switch, hazard warning light switch, hazard warning light relay	251
25. Intermittent wiper switch, windscreen wiper and washer system, headlight washer system	252
26. Heated rear window, heated washer jets, reversing lights	253
27. Horn, fuses 1 and 3 in fuse carrier	254
28. Interior light, reading lights	255
29. Footwell lights. entry lights. entry and footwell lighting relays. door warning lamp	256



30. Door contact switch, illuminated make-up mirrors	257
31. Cigarette lighter, luggage compartment lights	258
32. Cigarette lighter, rear, rear window lifter isolation switch	259
33. Illumination for dash panel and rear vents, glove box light	260
035 - Audi A8 3.7 l fuel injection engine (170 kW - Motronic - 8-cylinder) engine code AEW, Model year 1998	261-274
1. Audi A8 3.7 l fuel injection engine (170 kW - Motronic - 8-cylinder) engine code AEW, Model year 1998	261
2. Audi A8 3.7 l fuel injection engine (170 kW - Motronic - 8-cylinder) engine code AEW, Model year 1998	262
3. Battery, starter, alternator, starter inhibitor relay	263
4. Motronic control unit, ignition coils, injectors, ignition coil fuses	264
5. Motronic control unit, final output stage for ignition coils	265
6. Motronic control unit, throttle valve potentiometer, air mass meter, knock sensors	266
7. Motronic control unit, Hall senders, engine speed sender, control element fuse	267
8. Motronic control unit, fuel pump relay, ignition coils	268
9. Motronic control unit, Motronic current supply relay, ignition coils for output stages, lambda probes with heating	269
10. Motronic control unit, lambda probes 2, immobilizer	270
11. Engine cooling	271
12. Dash panel insert, fuel gauge, fuel pump, coolant and oil pressure control	272
13. Dash panel insert, rev. counter, selector lever position indicator, warning lamps	273
14. Dash panel insert, speedometer, diagnosis connection	274
036 - Audi A8 2.8 l fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ALG, Model year 1998	275-288
1. Audi A8 2.8 l fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ALG, Model year 1998	275
2. Audi A8 2.8 l fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ALG, Model year 1998	276
3. Audi A8 2.8 l fuel injection engine (142 kW - Motronic - 6-cylinder) engine code ALG, Model year 1998	277
4. Earth connections	278
5. Battery, starter, alternator, starter inhibitor relay	279
6. Motronic control unit, ignition system, injectors, Hall sender, fuses	280
7. Motronic control unit, knock sensors, throttle valve control unit, engine speed sender	281
8. Motronic control unit, hall sender 2, immobilizer control unit	282
9. Motronic control unit, lambda probe heater, inlet camshaft timing adjustment valves	283
10. Motronic control unit, fuel pump relay, air mass meter, secondary air pump	284
11. Engine cooling	285
12. Dash panel insert, fuel gauge sender, fuel pump, coolant and oil pressure control	286
13. Dash panel insert, warning lamps, handbrake warning switch, selector lever position indicator, coolant temperature gauge	287
14. Dash panel insert, digital clock, diagnosis connection, warning lamps, speedometer sender	288
037 - Audi A8 2,5 l turbo-diesel engine (110 kW, 6-cylinder), engine codes AFB, Model year 1998	289-301
1. Audi A8 2,5 l turbo-diesel engine (110 kW, 6-cylinder), engine codes AFB, Model year 1998	289
2. Audi A8 2,5 l turbo-diesel engine (110 kW, 6-cylinder), engine codes AFB, Model year 1998	290
3. Battery, starter, alternator, alternator cut-in relay	291
4. Glow plugs, glow plug relay, diesel direct injection system control unit, electro/hydraulic engine mounting, exhaust gas recirculation valve, charge pressure control solenoid valve	292
5. Diesel direct injection system control unit, diesel direct injection system relay, coolant temperature sender, fuse, air mass meter, needle lift sender, oil temperature sender	293
6. Diesel direct injection system control unit, cruise control system	294
7. Diesel direct injection system control unit, engine speed sender, intake manifold pressure sender, injection pump control unit	295
8. Diesel direct injection system control unit, additional heater control unit, low fuel level sender, fuel pump relay	296
9. Diesel direct injection system control unit, idling switch, accelerator pedal position sender, diagnosis connection, control unit and reading coil immobilizer	297
10. Engine cooling	298
11. Dash panel insert, fuel gauge, coolant and oil pressure control, warning lamps	299
12. Dash panel insert, rev. counter, coolant temperature gauge, warning lamps	300
13. Dash panel insert, speedometer	301
038 - Automatic gearbox (01V) 6 cylinder engines 2.8 l, 142 kW, ALG, Model year 1998	302-308
1. Automatic gearbox (01V) 6 cylinder engines 2.8 l, 142 kW, ALG, Model year 1998	302
2. Automatic gearbox (01V) 6 cylinder engines 2.8 l, 142 kW, ALG, Model year 1998	303
3. Automatic gearbox control unit. fuse. diagnosis connection	304

4. Automatic gearbox control unit, solenoid valves, kick-down switch	305
5. Automatic gearbox control unit, multi-function switch	306
6. Automatic gearbox control unit, Tiptronic switch	307
7. Brake light switch, starter inhibitor relay, reversing light	308
039 - Central locking with remote control and anti-theft alarm system with interior monitoring, Model year 1998	309-316
1. Central locking with remote control and anti-theft alarm system with interior monitoring, Model year 1998	309
2. Central locking, interior locking switch	310
3. Contact switch in lock cylinder for tailgate/bootlid/anti-theft alarm system/central locking system, door handle switch	311
4. Anti-theft alarm system horn, tailgate/bootlid contact switch for anti-theft alarm	312
5. Anti-theft alarm system contact switch	313
6. Luggage compartment release switch	314
7. Door contact switch	315
8. Interior monitor, ultra-sonic sensors control unit	316
040 - Anti-lock brake system (ABS) with electronic differential lock (EDL), traction control system (ASR/TCS) and electronic stability program (ESP), Model year 1998	317-322
1. Anti-lock brake system (ABS) with electronic differential lock (EDL), traction control system (ASR/TCS) and electronic stability program (ESP), Model year 1998	317
2. ABS with EDL control unit, traction control system switch, ABS hydraulic pump fuse, ABS valves fuse	318
3. ABS with EDL control unit, speed sensors, brake light switch, hydraulic pump	319
4. ABS with EDL control unit, ABS hydraulic unit, return flow pump relay, relay for solenoid valves	320
5. ABS with EDS control unit, steering angle sender, lateral acceleration, brake pressure and yaw rate	321
6. ABS with EDL control unit	322
041 - Daytime driving lights with fog lights, Model year 1998	323-328
1. Daytime driving lights with fog lights, Model year 1998	323
2. Daytime driving lights with fog lights, Model year 1998	324
3. Daytime driving lights with fog lights	325
4. Daytime driving lights with fog lights	326
5. Daytime driving lights with fog lights	327
6. Daytime driving lights with fog lights	328
042 - Air conditioner with automatic control, Model year 1998	329-339
1. Air conditioner with automatic control, Model year 1998	329
2. Air conditioner with automatic control, Model year 1998	330
3. Air conditioner	331
4. Air conditioner	332
5. Air conditioner	333
6. Air conditioner	334
7. Air conditioner	335
8. Air conditioner	336
9. Air conditioner	337
10. Air conditioner, engine cooling petrol engines	338
11. Air conditioner, engine cooling diesel engines	339
043 - Airbag	340-343
1. Airbag	340
2. Airbags and belt tensioners for driver and front passenger	341
3. Side airbag for front and rear seats	342
4. Rear belt tensioner igniter, belt switches	343
044 - Navigation system	344-350
1. Navigation system	344-345
2. Operating electronics control unit, navigation	346
3. Operating electronics control unit, navigation system operating unit	347
4. Navigation control unit, operating electronics control unit, magnetic field sender	348
5. Navigation control unit, operating electronics control unit	349
6. Navigation control unit	350
045 - Telephone, AEG, Model year 1998	351-353
1. Telephone, AEG, Model year 1998	351
2. Telephone, AEG	352
3. Telephone, AEG	353
046 - Electric sliding sunroof with automatic selection, Model year 1998	354-355
1. Electric sliding sunroof with automatic selection, Model year 1998	354
2. Electric sliding sunroof with automatic selection	355
047 - Trailer couplina. Model year 1998	356-361

1. Trailer coupling, Model year 1998	356
2. Trailer coupling, Model year 1998	357
3. Trailer coupling	358
4. Trailer coupling	359
5. Trailer coupling	360
6. Trailer coupling	361
048 - Electric seat adjustment rear seats, Model year 1998	362-367
1. Electric seat adjustment rear seats, Model year 1998	362
2. Rear head restraint adjustment switch, seat adjustment fuse	363
3. Adjustable front passenger's seat switch, adjustable rear seat switch, right, rear window lifter isolation switch	364
4. Electric seat and head restraint adjustment rear seat, left	365
5. Electric seat and head restraint adjustment rear seat, right	366
6. Lumbar support adjustment, rear seats	367
049 - Servotronic	368-370
1. Servotronic	368-369
2. Servotronic	370
050 - Anti-lock brake system (ABS) with electronic differential lock (EDL) and traction control system (ASR)	371-376
1. Anti-lock brake system (ABS) with electronic differential lock (EDL) and traction control system (ASR)	371-372
2. Anti-locking brake system	373
3. Anti-locking brake system	374
4. Anti-locking brake system	375
5. Anti-locking brake system	376
051 - Air conditioner with auxiliary heater, Model year 1998	377-390
1. Air conditioner with auxiliary heater, Model year 1998	377
2. Air conditioner with auxiliary heater, Model year 1998	378
3. Air conditioner with auxiliary heater	379
4. Air conditioner with auxiliary heater	380
5. Air conditioner with auxiliary heater	381
6. Air conditioner with auxiliary heater	382
7. Air conditioner with auxiliary heater	383
8. Air conditioner with auxiliary heater	384
9. Air conditioner with auxiliary heater	385
10. Air conditioner with auxiliary heater	386
11. Air conditioner with auxiliary heater	387
12. Air conditioner with auxiliary heater	388
13. Engine cooling petrol engines	389
14. Engine cooling diesel engine	390
052 - Radio Bose system Concert with and without CD changer	391-396
1. Radio Bose system Concert with and without CD changer	391-392
2. Radio Bose system Concert with and without CD changer	393
3. Radio Bose system Concert with and without CD changer	394
4. Radio Bose system Concert with and without CD changer	395
5. Radio Bose system Concert with and without CD changer	396
053 - Radio stereo system: Chorus, Concert	397-402
1. Radio stereo system: Chorus, Concert	397-398
2. Radio stereo system: Chorus, Concert	399
3. Radio stereo system: Chorus, Concert	400
4. Radio stereo system: Chorus, Concert	401
5. Radio stereo system: Chorus, Concert	402
054 - Automatic anti-dazzle interior and exterior mirrors, Model year 1998	403-404
1. Automatic anti-dazzle interior and exterior mirrors, Model year 1998	403
2. Automatic anti-dazzle interior and exterior mirrors	404
055 - Headlights with gas discharge lamps and automatic headlight range control, Model year 1998	405-411
1. Headlights with gas discharge lamps and automatic headlight range control, Model year 1998	405
2. Headlights with gas discharge lamps and automatic headlight range control, Model year 1998	406
3. Starter inhibitor relay, lighting switch	407
4. X contact relief relay, ignition/starter switch	408
5. Gas discharge lamps control unit	409
6. Control unit for headlight range control, vehicle level senders	410
7. Headlight range control motors	411
056 - Driver information system, Model year 1998	412-419
1. Driver information system, Model year 1998	412
2. Driver information svstem. Model vear 1998	413



3. Ignition/starter switch, lighting switch, X contact relief relay	414
4. Fuse carrier 1, bulb monitoring device, headlight, side light, fog lights	415
5. Fuse carrier 1, bulb monitoring device, tail light, brake lights, high level brake	416
6. Fog light switch, number plate light	417
7. Dash panel insert	418
8. Ambient temperature, gear indicator, ambient temperature indicator	419
057 - Multi-function steering wheel, Model year 1998	420-423
1. Multi-function steering wheel, Model year 1998	420
2. Multi-function steering wheel	421
3. Multi-function steering wheel	422
4. Multi-function steering wheel	423
058 - Tailgate/bootlid	424-425
1. Tailgate/bootlid	424
2. Tailgate/bootlid	425
059 - Heated steering wheel, Model year 1998	426-427
1. Heated steering wheel, Model year 1998	426
2. Heated steering wheel	427
060 - Heated front seats and rear seat	428-432
1. Heated front seats and rear seat	428-429
2. Heated seat, driver's seat	430
3. Heated seat, front passenger's seat	431
4. Heated seats, rear seat	432
061 - Ultrasonic parking aid, Model year 1998	433-435
1. Ultrasonic parking aid, Model year 1998	433
2. Ultrasonic parking aid	434
3. Ultrasonic parking aid	435
062 - Electric head restraint and lumbar support adjustment for rear seats	436-440
1. Electric head restraint and lumbar support adjustment for rear seats	436-437
2. Head restraint adjustment switch, seat adjustment fuse	438
3. Electric head restraint adjustment for rear seats	439
4. Electric lumbar support adjustment for rear seats	440
063 - Cruise control system petrol engines	441-443
1. Cruise control system petrol engines	441
2. Cruise control system	442
3. Cruise control system	443
064 - Radio navigation system (RNS)	444-451
1. Radio navigation system (RNS)	444-445
2. Radio navigation system	446
3. Radio navigation system	447
4. Radio navigation system	448
5. Radio navigation system	449
6. Radio navigation system	450
7. Radio navigation system	451
065 - Steering wheel with Tiptronic	452-455
1. Steering wheel with Tiptronic	452-453
2. Steering wheel with Tiptronic	454
3. Steering wheel with Tiptronic	455
066 - Electrically operated rear roller blind	456-457
1. Electrically operated rear roller blind	456
2. Electrically operated rear roller blind	457
067 - Mobile phone	458-461
1. Mobile phone	458-459
2. Mobile phone	460
3. Mobile phone	461
068 - Telephone	462-466
1. Telephone	462-463
2. Telephone	464
3. Telephone	465
4. Telephone	466