

Contents

	Page
Survey of engines	1
Delivery Service	5
Oil Change Service	8
Inspection Service	9
All switches, electrical equipment, displays and other driver-operated controls: check function	13
Windscreen wiper and washer system and headlight washer system: adjust washer jet settings and check function	15
Windscreen washer system: check washer jet settings and adjust if necessary	15
Headlight washer system: check washer jet settings	17
Wiper blades: check park position and check for damage	18
Adjust clock	21
Air conditioner: check function	21
Radio: activate anti-theft coding by entering fixed code number	22
Self-diagnosis: interrogate fault memory with VAS 5051 or V.A.G 1551	23
Door arresters and lock cylinders: lubricate	28
Door lock: lubricate rotary latch	28
Convertible top locking mechanism, stoppers and guides on convertible top frame: lubricate	29
Battery: check electrolyte level and top up with distilled water if necessary	33
Battery: check no-load voltage before starting the engine for the first time	35
Battery: check security of battery cables (only applies to vehicles kept in stock for long periods) ..	37
Removing engine cover	38
Engine (from above and below) and engine compartment: visual check for leaks and damage	40
Windscreen / headlight washer system: top up fluid	41
Cooling system: check antifreeze and top up coolant if necessary	41
Air cleaner: clean housing and replace filter element	47
Spark plugs: replace	49
Hydraulic system: check for leaks, check fluid level and top up hydraulic fluid if necessary	53
Fuel filter: replace (TDI engines)	55
Fuel filter: drain water (TDI engines)	57
Dust and pollen filter: replace	59
Noise insulation: remove	61
V-belt: check for damage and check tension; adjust tension if necessary	62
V-belts: tension	64
V belt (not ribbed belt) for alternator: replace	72
Ribbed belt: check for damage	74
Ribbed belt: check tension; adjust if necessary	75
V-belt and ribbed belt: replace (4-cylinder 5V engines ADR)	77
Ribbed belt: replace (6-cyl. engines)	82
Toothed belt for camshaft drive: check for damage and measure belt width (TDI engines)	85
Toothed belt for camshaft drive: check for damage (6-cyl. engines)	87
Toothed belt: replace	88
Transport locks: remove locking elements for front suspension struts	90
Manual gearbox/final drive: check oil level and top up if necessary	91
Final drive (automatic gearbox): check oil level and top up if necessary	93
Engine oil: drain or extract, change oil filter	94
Brake system: visual check for leaks and damage	97
Brake pads: check thickness	99
Underseal: visual check for damage	101
Track rod ends: check play, attachment and protective boots	101
Tyres: check and correct condition, wear pattern, tread depth and inflation pressures	102
Wheel bolts: tighten to specified torque	105
Engine oil: fill	109
Engine: check oil level	112
Automatic gearbox 097: renewing ATF	113
Brake fluid level (depending on brake pad wear): check	119
Brake fluid: change brake fluid (every 24 months)	121
Headlights: check settings and adjust if necessary	125
Test drive: perform	131

Vehicle data sticker	133
Engine code and engine number	135
Lifting the vehicle	138
Tow-starting/towing.....	140
Arbeitsabläufe Benzinmotoren	145
Arbeitsabläufe Dieselmotoren	145
Abgasuntersuchung Deutschland	146
Arbeitsabläufe Benzinmotoren	147
Störgröße vorbereiten	148
Prüfgeräte	153
Prüfablauf.....	155
Prüfung mit Fehlerspeicher-Abfrage (V.A.G 1551) zur Lambda-Regelkreisprüfung.....	163
Prüfung ohne Fehlerspeicher-Abfrage (V.A.G 1551) zur Lambda-Regelkreisprüfung	165
Arbeitsabläufe Dieselmotoren	190
Prüfgeräte	191
Prüfablauf.....	194