

## Contents

<b>27 - Starter, current supply, CCS</b>	<b>1</b>
<b>1 Battery</b>	<b>1</b>
1.1 Checking battery	1
1.2 Charging battery	3
<b>92 - Windscreen wash/wipe system</b>	<b>7</b>
<b>1 Washer fluid lines</b>	<b>7</b>
1.1 Pulling off and fitting washer fluid hoses	7
1.2 Repairing smooth tube	7
1.3 Repairing corrugated tube	8
<b>97 - Wiring</b>	<b>10</b>
<b>1 Wires and lines</b>	<b>10</b>
1.1 Repairing wiring harnesses	10
1.2 Repairing fibre optic cables	26
1.3 Repair of aerial wires	31
<b>2 Cleaning contact surfaces</b>	<b>37</b>
2.1 Cleaning battery clamp and battery terminal	37
2.2 Anti-corrosion treatment of contact surfaces	38
2.3 Cleaning terminals	39
2.4 Cleaning threaded connections	40
<b>3 Connector housing</b>	<b>41</b>
3.1 Dismantling connector housings	41
3.2 Repairing contacts in connector housings	41
<b>4 ESD workplace</b>	<b>42</b>
4.1 Repair notes on ESD workplace	42