

Contents

91 - Communication	1
1 Radio	1
1.1 Layout - radio	1
1.2 Layout - radio, USA	1
1.3 Overview of fitting locations - radio	3
1.4 Overview of fitting locations - radio, USA	4
1.5 Pin assignment for radio symphony	5
1.6 Pin assignment for radio symphony, USA	7
1.7 Pin assignment for satellite radio R146 , USA	9
1.8 Removing and installing radio R	10
1.9 Removing and installing, activating satellite radio R146 , USA	11
2 Sound system	15
2.1 Layout - sound system	15
2.2 Overview of fitting locations - loudspeakers	18
2.3 Overview of fitting locations - sound amplifiers	19
2.4 Pin assignment for digital sound package control unit J525 (Standard)	21
2.5 Pin assignment for digital sound package control unit J525 (Bang & Olufsen)	22
2.6 Removing and installing digital sound package control unit J525 (Standard, Coupé)	23
2.7 Removing and installing digital sound package control unit J525 (Standard, Spyder)	24
2.8 Removing and installing digital sound package control unit J525 (Bang & Olufsen, Coupé)	25
2.9 Removing and installing digital sound package control unit J525 (Bang & Olufsen, Spyder)	26
2.10 Removing and installing front bass loudspeakers	27
2.11 Removing and installing rear mid-range and bass loudspeaker (Coupé)	27
2.12 Removing and installing rear mid-range and bass loudspeaker (Spyder)	28
2.13 Removing and installing front treble loudspeaker (Coupé)	28
2.14 Removing and installing front treble loudspeaker (Spyder)	28
2.15 Removing and installing rear treble loudspeaker (Coupé)	29
2.16 Removing and installing rear treble loudspeaker (Spyder)	30
2.17 Removing and installing centre mid-range and treble loudspeaker R158	30
2.18 Removing and installing front mid-range loudspeakers	31
2.19 Removing and installing middle loudspeaker R148 (up to model year 2011)	31
2.20 Removing and installing middle loudspeaker R148 (from model year 2012 onwards)	32
3 Telephone system	34
3.1 Layout - telephone	34
3.2 Layout - telephone, USA	37
3.3 Overview of fitting locations - telephone system	40
3.4 Overview of fitting locations - telephone system, USA	41
3.5 Exploded view - microphone unit	42
3.6 Overview of seat belt microphones	42
3.7 Pin assignment for mobile phone pre-installation	43
3.8 Pin assignment for mobile phone pre-installation, USA	44
3.9 Pin assignment for aerial amplifier for mobile telephone R86 , up to model year 2008	45
3.10 Pin assignment for aerial amplifier for mobile telephone R86 , from model year 2009 onwards	46
3.11 Pin assignment for pre-fitted components for mobile phone installation	47
3.12 Pin assignment for control unit for seat belt microphone J886	47
3.13 Pin assignment for Bluetooth hands-free system	48
3.14 Pin assignment for Bluetooth hands-free system, USA	49
3.15 Removing and installing telephone bracket R126	49
3.16 Removing and installing telephone transmitter and receiver unit R36	51
3.17 Removing and installing aerial amplifier for mobile telephone R86	52

3.18	Removing and installing microphone unit in front roof module R164	52
3.19	Removing and installing telephone microphone R38	53
3.20	Removing and installing control unit for seat belt microphone J886	54
4	Navigation system	56
4.1	Layout - navigation system	56
4.2	Layout - navigation system, USA	57
4.3	Overview of fitting locations - navigation system	59
4.4	Overview of fitting locations - navigation system, USA	60
4.5	Pin assignment for navigation system with CD drive control unit J401	61
4.6	Pin assignment for navigation system with CD drive control unit J401 , USA	64
4.7	Removing and installing navigation system with CD drive control unit J401	67
5	Navigation system - RNS-JP4, Japan	69
5.1	Layout - navigation system RNS-JP4, Japan	69
5.2	Pin assignment - RNS-JP4, Japan	70
5.3	Overview of fitting locations - navigation system, RNS-JP4, Japan	71
6	Navigation system - RNS-JP5, Japan	74
6.1	Layout - navigation system RNS-JP5, Japan	74
6.2	Pin assignment - RNS-JP5, Japan	76
6.3	Overview of fitting locations - navigation system RNS-JP5, Japan	78
7	Navigation system - RNS-JP6, Japan	81
7.1	Layout - navigation system RNS-JP6, Japan	81
7.2	Pin assignment - RNS-JP6, Japan	83
7.3	Overview of fitting locations - navigation system RNS-JP6, Japan	85
8	CD changer R41	88
8.1	Layout - CD changer R41	88
8.2	Pin assignment for CD changer R41	88
8.3	Removing and installing CD changer R41 (Coupé)	89
8.4	Removing and installing CD changer R41 (Spyder)	90
9	Connection for external audio sources R199	92
9.1	Layout - connection for external audio sources R199	92
9.2	Pin assignment for connection for external audio sources R199	92
9.3	Removing and installing connection for external audio sources R199 (AMI) (Coupé)	93
9.4	Removing and installing connection for external audio sources R199 (AMI) (Spyder)	94
9.5	Removing and installing connection for external audio sources R199 - AUX IN	95
10	Multi-function steering wheel	97
10.1	Layout - multi-function steering wheel	97
10.2	Overview - multi-function steering wheel, up to model year 2012	97
10.3	Exploded view - multi-function steering wheel, 3-spoke steering wheel, from model year 2013 onwards	99
10.4	Removing and installing multifunction buttons, up to model year 2012	99
10.5	Removing and installing multifunction buttons - 3-spoke steering wheel (from model year 2013 onwards)	100
10.6	Removing and installing tiptronic switches, up to model year 2012	102
10.7	Removing and installing tiptronic switches, from model year 2013 onwards	103
11	Reversing camera system	105
11.1	Layout - reversing camera system	105
11.2	Overview of fitting locations - reversing camera system	107
11.3	Pin assignment for reversing camera system control unit J772	107
11.4	Removing and installing reversing camera system control unit J772	108
11.5	Removing and installing reversing camera R189	109
11.6	Calibrating reversing camera system	110
12	Aerial systems	116
12.1	Layout - aerial systems	116
12.2	Overview of fitting locations - aerial systems	116
12.3	Pin assignment for aerial amplifier	118

12.4	Removing and installing aerial amplifier 2 R111 / aerial amplifier 3 R112	119
12.5	Removing and installing aerial amplifier R24 / aerial amplifier 4 R113	119
12.6	Removing and installing GPS aerial R50	120
12.7	Removing and installing radio, telephone and navigation system aerial R52 (Coupé)	120
12.8	Removing and installing radio, telephone and navigation system aerial R52 (Spyder)	121
12.9	Removing and installing aerial selection control unit J515	122
12.10	Removing and installing radio and telephone aerial R51 (Coupé)	122
12.11	Removing and installing radio and telephone aerial R51 (Spyder)	123