

Contents

44 - Wheels, tyres, vehicle geometry	1
1 Safety information	1
2 Determining the correct wheel and tyre combinations	2
2.1 Determining the correct wheel and tyre combinations according to NEDC - without tyre package	2
2.2 Determining the correct wheel and tyre combinations according to NEDC - with tyre package	3
2.3 Determining the correct wheel and tyre combinations according to WLTP	5
3 Explanation of version code (D2)	7
3.1 Explanation of version code (D2) - Audi TT (FV)	7
3.2 Explanation of version code (D2) - Audi TT RS (FV)	10
4 Wheels, tyres	13
4.1 Tightening torque for wheel bolts	13
5 Possible wheel and tyre combinations - Audi TT (8J)	14
5.1 Wheel and tyre combinations - Audi TT (8J), model years 2007 to 2009	14
5.2 Wheel and tyre combinations - Audi TT (8J), model year 2010	17
5.3 Wheel and tyre combinations - Audi TT (8J), model years 2011 to 2014	19
5.4 Wheel and tyre combinations - Audi TTS (8J), model years 2008 to 2009	22
5.5 Wheel and tyre combinations - Audi TTS (8J), model year 2010	23
5.6 Wheel and tyre combinations - Audi TTS (8J), model years 2011 to 2014	23
5.7 Wheel and tyre combinations - Audi TT RS (8J), model year 2009	24
5.8 Wheel and tyre combinations - Audi TT RS (8J), model year 2010	24
5.9 Wheel and tyre combinations - Audi TT RS (8J), model years 2011 to 2014	25
5.10 Wheel and tyre combinations - Audi TT RS plus (8J), model years 2011 to 2014	26
6 Possible wheel and tyre combinations - Audi TT (FV)	27
6.1 Possible wheel and tyre combinations - Audi TT (FV)	27
6.2 Possible wheel and tyre combinations - Audi TT RS (FV)	38
7 Wheel assignment	40
7.1 Wheel assignment - Audi TT (8J)	40
7.2 Wheel assignment - Audi TT RS (8J)	50
7.3 Wheel assignment - Audi TT (FV)	52
7.4 Wheel assignment - Audi TT RS (FV)	53
8 Temporary spare wheel	54
8.1 Temporary spare wheel - Audi TT (8J)	54
8.2 Temporary spare wheel - Audi TT (FV)	54
9 Recommended tyres - Audi TT (8J)	55
9.1 Recommended summer tyres	55
9.2 Recommended all-season tyres	55
9.3 Recommended winter tyres	55
10 Tyre pressures	57
10.1 Tyre pressures - Audi TT (8J)	57
10.2 Tyre pressures - Audi TT (FV)	61