

Contents

91 - Radio, telephone, navigation	1
1 Sound system	1
1.1 Layout - sound system	1
1.2 Overview of fitting locations - sound system	4
1.3 Removing and installing digital sound package control unit/amplifier	7
1.4 Removing and installing rear treble loudspeakers R14 / R16	8
1.5 Removing and installing front treble loudspeakers R20 / R22	9
1.6 Removing and installing centre loudspeaker	9
1.7 Removing and installing front mid-range loudspeakers	10
1.8 Removing and installing rear mid-range and bass loudspeakers	11
1.9 Removing and installing front bass loudspeakers R21 / R23	12
1.10 Removing and installing rear mid-range loudspeaker	12
1.11 Pin assignment	13
2 Aerial systems	19
2.1 Layout - aerial systems	19
2.2 Overview of fitting locations - aerial systems	20
2.3 Removing and installing aerial amplifiers	23
2.4 Removing and installing aerial module	26
2.5 Removing and installing GPS aerial	30
2.6 Removing and installing roof aerial	30
2.7 Pin assignment	33
3 Radio	36
3.1 Layout - radio	36
3.2 Overview of fitting locations - radio	40
3.3 Overview - radio	48
3.4 Removing and installing radio	49
3.5 Removing and installing digital radio	51
3.6 Pin assignment	52
4 DVD/CD changer	58
4.1 Exploded view - CD changer	58
4.2 Pin assignment	58
4.3 Removing and installing CD changer	58
5 Telephone system	60
5.1 Layout - telephone	60
5.2 Overview of fitting locations - telephone system	64
5.3 Exploded view - microphone unit	68
5.4 Removing and installing microphone unit in front roof module R164	68
5.5 Removing and installing aerial amplifier for mobile telephone R86	68
5.6 Removing and installing telephone bracket R126	69
5.7 Removing and installing telephone transmitter and receiver unit	70
5.8 Pin assignment	71
6 Navigation system	77
6.1 Layout - navigation system	77
6.2 Overview of fitting locations - navigation system	90
6.3 Pin assignment	104
6.4 Removing and installing control unit for navigation system	116
7 TV system	119
7.1 Layout - TV system	119
7.2 Overview of fitting locations - TV system	121
7.3 Pin assignment	123
7.4 Removing and installing TV tuner	125
8 Multi-function steering wheel	127

8.1	Layout - multi-function steering wheel	127
8.2	Exploded view - multi-function steering wheel	127
8.3	Removing and installing multifunction buttons in steering wheel E441 / E440	129
8.4	Removing and installing tiptronic switches in steering wheel E439 / E438	129
9	Connection for external multimedia devices	131
9.1	Connectors on connection for external audio sources	131
9.2	Removing and installing connection for external audio sources R199	133